




SWEEPSTER

BY PALADIN

OPERATOR'S AND PARTS MANUAL S26 & S30 Series MRHL / CTC 222, 225, 226

Hydraulic Windrow Sweepers



Serial Number: _____

Model Number: _____

**Manual Number: 51-4179
Release Date: October 2013
Serial Number: 0906001 & Up
Rev. 2**

NOTES

TABLE OF CONTENTS

PREFACE.....	4
SAFETY STATEMENTS.....	4
GENERAL SAFETY PRECAUTIONS.....	4-7
DECALS.....	8-9
INSTALLATION.....	10-13
OPERATION.....	14-20
MAINTENANCE SCHEDULE.....	21
MAINTENANCE.....	22-23
TROUBLESHOOTING.....	24-27
PRODUCT SPECIFICATIONS.....	28-30
BOLT TORQUE SPECIFICATIONS.....	31
HYDRAULIC TORQUE SPECIFICATIONS.....	32-33
WARRANTY.....	34
BRUSH HEADS.....	36-43
CORE.....	44
BEARING.....	45
MOTOR ASSEMBLY.....	46
222/225 WITH QUICK ATTACH MOUNTING.....	47
226 WITH QUICK ATTACH MOUNTING.....	48-49
MANUAL ANGLE KIT.....	50
MRHL POWER PACK.....	52-53
ELECTRIC WIRING HARNESS.....	54-56
DIRT DEFLECTOR KITS S26 & S30.....	57
HYDRAULIC SWING / NO VALVE.....	58
HYDRAULIC SWING WITH ELECTRIC VALVE.....	59-60

PREFACE

GENERAL INFORMATION

This product was carefully designed and manufactured to give you many years of dependable service. Only minor maintenance (such as cleaning and lubricating) is required to keep it in top working condition. Be sure to observe all maintenance procedures and safety precautions in this manual and on any safety decals located on the product and on any equipment on which the attachment is mounted.

WARNING!  **Never let anyone operate this unit without reading the “Safety Precautions” and “Operating Instructions” sections of this manual. Always choose hard, level ground to park the vehicle on and set the brake so the unit cannot roll.**

Unless noted otherwise, right and left sides are determined from the operator’s control position when facing the attachment.

NOTE: The illustrations and data used in this manual were current (according to the information available to us) at the time of printing, however, we reserve the right to redesign and change the attachment as may be necessary without notification.

BEFORE OPERATION

The primary responsibility for safety with equipment falls to the operator. Make sure the equipment is operated only by trained individuals that have read and understand this manual. If there is any portion of this manual or function you do not understand, contact your local authorized dealer or manufacturer to obtain further assistance. Keep this manual available for reference. Provide this manual to any new owners and/or operator’s.

SAFETY ALERT SYMBOL



This is the “Safety Alert Symbol” used by this industry. This symbol is used to warn of possible injury. Be sure to read all warnings carefully. They are included for your safety and the safety of others working with you.

SERVICE

Use only manufacturer replacement parts. Substitute parts may not meet the required standards. Record the model and serial number of your unit on the cover of this manual. The parts department needs this information to insure that you receive the correct parts.

SOUND AND VIBRATION

“Sound pressure levels and vibration data for this attachment are influenced by many different parameters; some items are listed below (not inclusive):

- prime mover type, age, condition, with or without cab enclosure and configuration
- operator training, behavior, stress level
- job site organization, working material condition, environment

Based on the uncertainty of the prime mover, operator, and job site, it is impossible to get precise machine and operator sound pressure levels, or vibration levels for this attachment.”

NOTE: A list of all Paladin Patents can be found at <http://www.paladinattachments.com/patents.asp>.

SAFETY STATEMENTS

DANGER!



THIS SIGNAL WORD IS USED WHERE SERIOUS INJURY OR DEATH WILL RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.

WARNING!



THIS SIGNAL WORD IS USED WHERE SERIOUS INJURY OR DEATH COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.

CAUTION!



THIS SIGNAL WORD IS USED WHERE MINOR INJURY COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.

NOTICE!

NOTICE INDICATES A PROPERTY DAMAGE MESSAGE.



THIS SYMBOL BY ITSELF OR USED WITH A WARNING WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.

GENERAL SAFETY PRECAUTIONS

WARNING!



READ MANUAL PRIOR TO INSTALL

Improper installation, operation, or maintenance of this equipment could result in serious injury or death. Operators and maintenance personnel should read this manual as well as all manuals related to this equipment and the prime mover thoroughly before beginning installation, operation, or maintenance. **FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL AND THE PRIME MOVERS MANUAL.**

WARNING!



READ AND UNDERSTAND ALL SAFETY STATEMENTS

Read all safety decals and safety statements in all manuals prior to operating or working on this equipment. Know and obey all OSHA regulations, local laws and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing or operating this equipment.



KNOW YOUR EQUIPMENT

Know your equipment's capabilities, dimensions and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to assure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued or excessively worn parts. Make certain all safety decals are in place and are legible. Keep decals clean, and replace them if they become worn and hard to read.

WARNING!



PROTECT AGAINST FLYING DEBRIS

Always wear proper safety glasses, goggles or a face shield when driving pins in or out or when operation causes dust, flying debris, or any other hazardous material.

GENERAL SAFETY PRECAUTIONS

WARNING! LOWER OR SUPPORT RAISED EQUIPMENT



Do not work under raised booms without supporting them. Do not use support material made of concrete blocks, logs, buckets, barrels or any other material that could suddenly collapse or shift positions. Make sure support material is solid, not decayed, warped, twisted, or tapered. Lower booms to ground level or onto blocks. Lower booms and attachments to the ground before leaving the cab or operator's station.

WARNING! USE CARE WITH HYDRAULIC FLUID PRESSURE




Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your prime movers operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a sound piece of cardboard or wood when searching for hydraulic leaks.

DO NOT USE YOUR HANDS!

SEE ILLUSTRATION.



WARNING! DO NOT MODIFY MACHINE OR ATTACHMENTS



Modifications may weaken the integrity of the attachment and may impair the function, safety, life and performance of the attachment. When making repairs, use only the manufacturer's genuine parts, following authorized instructions. Other parts may be substandard in fit and quality. Never modify any ROPS (Roll Over Protection System) equipment or device. Any modifications must be authorized in writing by the manufacturer.

GENERAL SAFETY PRECAUTIONS

WARNING! SAFELY MAINTAIN AND REPAIR EQUIPMENT



- Do not wear loose clothing, or any accessories that can catch in moving parts. If you have long hair, cover or secure it so that it does not become entangled in the equipment.
- Work on a level surface in a well-lit area.
- Use properly grounded electrical outlets and tools.
- Use the correct tool for the job at hand. Make sure they are in good condition for the task required.
- Wear the protective equipment specified by the tool manufacturer.

WARNING! SAFELY OPERATE EQUIPMENT



- Do not operate equipment until you are completely trained by a qualified operator in how to use the controls, know its capabilities, dimensions, and all safety requirements. See your prime movers manual for these instructions.
- Keep all step plates, grab bars, pedals, and controls free of dirt, grease, debris, and oil.
 - Never allow anyone to be around the equipment when it is operating.
 - Do not allow riders on the attachment or the prime mover.
 - Do not operate the equipment from anywhere other than the correct operators position.
 - Never leave equipment unattended with the engine running or with this attachment in a raise position.
 - Do not alter or remove any safety feature from the prime mover or this attachment.
 - Know your work site safety rules as well as traffic rules and flow. When in doubt on any safety issue, contact your supervisor or safety coordinator for an explanation.

WARNING! EXPOSURE TO RESPIRABLE CRYSTALLINE SILICA DUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.



It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of any attachment that may cause high levels of dust.

WARNING! REMOVE PAINT BEFORE WELDING OR HEATING.



Hazardous fumes/dust can be generated when paint is heated by welding, soldering or using a torch. Do all work outside or in a well ventilated area and dispose of paint and solvent properly. Remove paint before welding or heating.


When sanding or grinding paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

WARNING! END OF LIFE DISPOSAL.



At the completion of the useful life of the unit, drain all fluids and dismantle by separating the different materials (rubber, steel, plastic, etc.). Follow all federal, state and local regulations for recycling and disposal of the fluid and components.

DECALS



Use part numbers to order replacements for lost or damaged decals. Be sure to read all decals before operating the attachment. They contain information you need to know for both safety and longevity.

Placement or replacement of Safety Decals

1. Clean the area of application with nonflammable solvent, and then wash the same area with soap and water.
2. Allow the surface to fully dry.
3. Remove the backing from the safety sign, exposing the adhesive surface.
4. Apply the safety sign to the position shown in the diagram above and smooth out any bubbles.


Instructions

1. Keep all safety signs clean and legible.
2. Replace all missing, illegible, or damaged safety signs.
3. Replacement parts, for parts with safety signs attached, must also have safety signs attached.
4. Safety signs are available, free of charge, from your dealer.


DECALS



4. 41043



7. 50-0721



8. 50-0722



9. 50-0724



10. 50-0726

Item	Part	Qty	Description
4.	41043	1	Decal, Warning, Hazardous Dust
7.	50-0721	2	Label Warning, Crush Hazard
8.	50-0722	1	Label, Warning, Misuse Hazard
9.	50-0724	1	Label, Warning, High Pressure Fluid Hazard
10.	50-0726	2	Label, Warning, Flying Objects & Entanglement

INSTALLATION

Make sure that all clamps, guards, and shields are installed correctly.

NOTICE! *S26/S30 Series sweepers are designed to fit tractors and loaders with hydraulic capacities of 10-20 gpm and up to 2400 psi.*

MRHL

To attach the mounting/swing assembly to a loader with a quick attach mounting, follow these instructions:

1. Remove the bucket or other attachment from the loader.
2. Center the mounting/swing assembly in front of the loader
3. Attach the mounting/swing assembly to the loader's quick attach. Lock the quick attach.
4. Level the mounting/swing assembly with the loader's tilt cylinders. Then, adjust the loader height until the assembly is 12 inches (305 mm) above the ground.

NOTICE! *The mounting/swing assembly must be level for the sweeper to operate properly when angled.*

5. Position the brush head assembly in front of the mounting/swing assembly.
6. Attach the brush head assembly to the front of the swing plate with 2, 1/2 inch carriage bolts, flat washers, lock washers and nuts.
7. Install the spring-chain assembly. To do so:

NOTICE! Refer to figure 2 during installation.

- a. Connect a spring to each end of a 26-link chain.
 - b. Place a 26-link chain on each spring.
 - c. Attach the free ends of the 26-link chains to the brackets on the mounting frame.
 - d. Loop the other end of the spring-chain assembly over the outside slots on the brush head upright.
8. Install the 36-link transport chain by placing 1 end in the center slot of the brush head upright and the other end on the bracket on the mounting frame.
 9. Refer to Leveling.

INSTALLATION




figure 1




figure 2

MRHL Power Pack

The hydraulic tank can be mounted in 1 of 2 positions:

- On 3-point arms or
- Above the 3-point hitch attachment.

If you wish to use another attachment on the hitch, mount the tank above it. Otherwise, mount the tank on the 3-point arms.

On 3-Point Hitch Arms

Refer to figure 1 during installation.

1. Connect the mounting bracket to the hitch arms with hitch pins. Secure with ring pins.
2. Connect the hitch's top link to ears on the mounting bracket.
3. Fasten 2 mounting plates to the mounting bracket's bottom channel. Use 2, 1/2 inch carriage bolts, flat washers, lock washers and nuts.
4. Place the tank on top of the mounting plates and bolt in place with 4, 3/8 inch carriage bolts, lock washers and nuts.
5. Go to Installation: Pumps & Hoses.

Above 3-Point Hitch

Refer to figure 2 during installation.

1. Connect the attachment, the mounting bracket ears and the hitch's top link.
2. Assemble the support arms using 4, 3/8 inch cap screws, flat washers, lock washers and nuts.
3. Connect support arms to the hitch arms (with pins used on the hitch) and to the mounting bracket.
4. Level mounting bracket from front to back and from left to right by adjusting the support arms.
5. Install the tank on the mounting bracket with 4 carriage bolts.
6. Go to Installation: Pumps & Hoses.

INSTALLATION

Pump & Hoses

1. Install the relief valve and fittings on the pump.
(Refer to figure 3 during installation.)
 - The 1 5/16 inch - 1 1/4 inch barb fitting goes in the pump inlet.
 - Place fittings on the pump outlet in this order: 1 1/16 inch - 3/4 inch elbow fitting in the outlet opening. 3/4 inch - 3/4 inch nipple fitting on the elbow fitting, relief valve on the nipple and 3/4 inch elbow fitting on the relief valve.
2. Slide the pump onto the tractor PTO shaft. Make sure that the relief valve is on the left-hand side.
3. Fasten the 10-link chain to the bottom threaded hole on the right-hand side of the pump. Bolt the other end of the chain to the tractor. The chain must be attached to a position on the tractor that is above and forward of the connection on the pump. The chain must also be taught. (Refer to figure 4)

NOTICE! This chain holds the pump on the shaft and prevents it from spinning during operation.

NOTE! For steps 4 through 8 refer to figure 5.




figure 3




figure 4




figure 5

INSTALLATION

Leveling

1. Drive the unit to a level, paved area.
2. Move stands to highest position.
3. Swing the brush head assembly straight ahead, and then lower it so the bristle tips are 2 inches (51mm) above the ground.
4. On both sides of the brush head assembly, measure from the brush frame to the ground.
 - If the measurements are equal, proceed to step 5.
 - If the measurements are not equal, loosen the outer bolts on the mounting assembly and adjust the height of 1 end until the measurements are the same. Tighten the hardware.
5. Angle the brush head assembly to the right. Measure from each side of the brush frame to the ground. Then swing the brush head assembly to the left. Measure from each end of the brush frame to the ground.
 - If all 4 measurements are the same, the brush head assembly is level.
 - If the measurements are not equal, proceed to step 6.
6. Adjust the brush head using the loader's tilt cylinders.
 - If the measurements resemble figure 1, tilt the brush head forward with the cylinders.
 - If the measurements resemble figure 2, retract the tilt cylinders.
 - If the measurements resemble figure 3, loosen hardware that attaches the swing assembly to the brush head assembly; lower the left-hand side of the brush head until both sides are an equal distance above the ground. Tighten the hardware.
7. Repeat steps 4 and 5 until the brush head is level.




figure 1




figure 2




figure 3

OPERATION

Intended Use

This sweeper is designed solely for use in construction cleanup, road maintenance and similar operations. Use in any other way is considered contrary to intended use. Compliance with and strict adherence to operation, service and repair conditions, as specified by the manufacturer, are essential elements of intended use.

CAUTION! **A SWEEPER IS A DEMANDING MACHINE.** Only fully trained operators or trainee operators under supervision of a fully trained person should use machine.



Before operating sweeper:

- Learn sweeper and prime mover controls in off-road location.
- Be sure you are in a safe area, away from traffic or other hazards.
- Check hardware holding sweeper to host machine, making sure it is tight.
- Replace damaged or fatigued hardware.
- Make sure hydraulic hardware and fittings are tight.
- Replace damaged or fatigued fittings or hoses.
- Check tire pressures.
- Check tire ratings to be sure they match the prime mover load. Weigh sweeper end of prime mover to insure proper tire rating.
- Remove all property that could be damaged by flying debris from sweeping area.
- Be sure all persons not operating the sweeper are clear of sweeper discharge area.
- Always wear proper apparel, long sleeved shirt buttoned at cuffs; safety glasses, goggles or face shield; ear protection; and dust mask.

While operating sweeper:

- When operating sweeper, adhere to all government rules, local laws and other professional guidelines for your sweeping application.
- Before leaving operators area for any reason, lower sweeper to ground. Stop prime mover engine, set brakes, remove key from ignition.
- Minimize flying debris - use slowest rotating speed that will do the job.

OPERATION

- Keep hands, feet, hair and other loose clothing away from all moving parts.
- Leave brush hood (shield) and all other shields and safety equipment in place when operating sweeper and primer mover.
- Be aware of extra weight and width a sweeper adds. Reduce travel speed accordingly.
- When sweeping on rough terrain, reduce speed to avoid “bouncing” the sweeper. Loss of steering can result.
- Never sweep toward people, buildings, vehicles or other objects that can be damaged by flying debris.
- Only operate sweeper while you are in the seat of the prime mover. Seat belt must be fastened while you operate prime mover. Only operate controls while the engine is running. Protective glasses must be worn while you operate prime mover and while you operate sweeper.
- Operate sweeper slowly in open area, check for proper operation of all controls and all protective devices. Note any repairs needed. Report any needed repairs.

Before Each Use

Perform daily maintenance as indicated in Maintenance Schedule.

Run prime mover and sweeper at low idle. Check for hydraulic leaks or other problems, make corrections, if necessary, before using sweeper.

WARNING! **AVOID SERIOUS INJURY.** Check for large objects that could harm operator or others if thrown by sweeper. Remove items before operating.



During Use

Carry sweeper low to ground so operator has good visibility and stability. Avoid sudden movements from one side to the other side when you carry a sweeper.

Avoid excessive downward pressure on brush sections to prevent excessive wear. A 2 to 4 inch (5-10 cm) wide pattern is sufficient for most applications. Ensure that motor and bearing plates are equally adjusted to prevent uneven wear pattern.

OPERATION

Brush Pattern Adjustment

A properly leveled brush offers the best sweeper performance. If your unit has optional casters, see Option - Casters. To check the brush pattern for all other units:

1. Move the sweeper to a dusty, flat surface.
2. Set the prime mover's parking brake. Leave the engine running.
3. Start the sweeper at a slow speed; then, lower it completely to the surface so the bristle tips touch the ground. Run the sweeper in a stationary position for 10 seconds.
4. Raise the sweeper and back away; switch off the engine and remove the key. The brush pattern left in the dust should be 2-4 inches wide, running the length of the brush. (Compare the swept area with figure 4.)
5. If necessary, adjust the brush pattern with the spring-chain assembly (figure 5).
 - a. Raise the sweeper.
 - b. Tighten the transport chain (figure 5) or lift cable and lower the sweeper so it supports weight.
 - c. Move the spring-chain forward in the swing assembly chain holder to lower the brush head assembly or backward in the holder to raise it.

Transport Chain

NOTE! Units with a lift cable do not have a transport chain.

The transport chain supports the weight of the brush head assembly during transport between work sites and during adjustment of the spring-chain assemblies. It should remain slack during sweeping.

To adjust the transport chain:

1. Raise the sweeper.
2. Tighten the transport chain.
3. Lower the sweeper so the transport chain supports the weight of the sweeper.




figure 4




figure 5

OPERATION

Operating Tips

NOTICE! *Avoid sweeper damage. Do not ram into piles. Use a dozer blade for this type of job.*



Snow

High brush speeds and slow ground speeds are needed to sweep snow effectively. Start at 3/4 throttle and the lowest gear of the prime mover. For wet and/or deep snow, increase to almost full throttle. This helps keep snow from packing up inside the brush hood.

In deep snow you may need to make more than one pass to get down to a clean surface.

To keep snow from blowing back onto a swept area, always sweep so the wind is at your back or so it follows the brush angle.

Dirt & Gravel

To keep dust at a minimum, plan your sweeping for days when it is overcast and humid or after it has rained. Also, sweep so the wind blows at your back or in the direction the brush head is angled.

Low brush speeds and moderate ground speeds work best for cleaning debris from hard surfaces. Brush speeds that are too fast tend to raise dust because of the aggressive sweeper action.

To sweep gravel, use just enough brush speed to “roll” the gravel, not throw it.

Heavy Debris

For 2 inches (51mm) or more of heavy debris, a maximum brush speed in the low range and ground speeds of less than 5 mph (8 kph) are recommended.

Thatch

Low brush speeds and low prime mover speeds do the best thatching job.

To prevent the brush from pulling itself into the ground, adjust the spring-chain assembly so the bristle tips barely touch the grass.

If the brush pulls into the grass and stalls while sweeping, use the lift to raise the brush. **Do not** increase throttle to override a stall out.

Use a combination of brush speeds and ground speeds that rolls up a neat windrow.

To keep thatch from blowing back into a swept area, sweep with the wind at your back or in the direction the brush is angled.

OPERATION

WARNING! Never raise the sweeper more than a few feet off the ground. The sweeper can tip back or the prime mover can tip over causing death or serious injury.



- Before leaving the operator's area for any reason, lower the sweeper to the ground. Stop the prime mover engine, set the parking brake and remove the key from the ignition.
- Minimize flying debris - use the slowest rotating speed that will do the job. See Operating Tips
- Keep hands, feet, hair and loose clothing away from all moving parts.
- Leave the brush hood (shield) and all other shields and safety equipment in place when operating the sweeper and prime mover.
- Be aware of the extra weight and width a sweeper adds. Reduce travel speed accordingly. See Operating the Sweeper.
- When sweeping on rough terrain, reduce speed to avoid "bouncing" the sweeper. Loss of steering can result.
- Never sweep toward people, buildings, vehicles or other objects that can be damaged by flying debris.
- Only operate the sweeper while you are in the operating position. The safety restraint must be fastened while you operate the prime mover. Only operate the controls while the engine is running. Protective glasses must be worn while you operate the prime mover and while you operate the sweeper.
- While you operate the sweeper slowly in an open area, check for proper operation of all controls and all protective devices. Note any needed repairs during operation of the sweeper. Report any needed repairs.

CAUTION! Do not modify the sweeper in any way. Personal injury could result. If you have questions, contact your dealer or SWEEPSTER.



Repair or adjust the sweeper in a safe area, away from traffic and other hazards.

Before adjusting or servicing - lower the sweeper to the ground, set parking brake, shut down the prime mover and remove the key from the ignition.

OPERATION

Storage

NOTICE! *Do not store the sweeper with weight on the brush. Weight will deform the bristles, destroying the sweeping effectiveness. To avoid this problem, place the sweeper on blocks or use storage stands.*

Do not store polypropylene brushes in direct sunlight. The material can deteriorate and crumble before the bristles are worn out.

Keep polypropylene brush material away from intense heat or flame.

General Storage:

Storage:

- Clean the unit thoroughly, removing all snow, dirt and grease.
- Inspect for visible signs of wear, breakage or damage. Order any parts required and make the necessary repairs to avoid delays upon removal from storage.
- Tighten loose nuts, capscrews and hydraulic connections.
- Coat exposed portions of the cylinder rods with grease.
- Lubricate grease fittings.
- Seal hydraulic system from contaminants and secure all hydraulic hoses off the ground to help prevent damage.
- Store unit in a dry and protected place. Leaving the unit outside will materially shorten its life.

Additional Precautions for Long Term Storage:

- Touch up all unpainted surfaces with paint to avoid rust.
- Check antifreeze properties and drain fluids as appropriate.

Removal from Storage:

- Remove cover.
- Wash unit and replace any damage and/or missing parts.
- Lubricate grease fittings.
- Check hydraulic hoses for damage and replace as necessary.

OPERATION

LIFT POINTS

Lifting points are identified by lifting decals where required. Lifting at other points is unsafe and can damage attachment. Do not attach lifting accessories around cylinders or in any way that may damage hoses or hydraulic components.

- Attach lifting accessories to unit at recommended lifting points, if marked.
- Bring lifting accessories together to a central lifting point.
- Lift gradually, maintaining the equilibrium of the unit.

WARNING!  **USE LIFTING ACCESSORIES (CHAINS, SLINGS, ROPES, SHACKLES AND ETC.) THAT ARE CAPABLE OF SUPPORTING THE SIZE AND WEIGHT OF YOUR ATTACHMENT. Secure all lifting accessories in such a way to prevent unintended disengagement. Failure to do so could result in the attachment falling and causing serious personal injury or death.**

TIE DOWN POINTS

Tie down points are identified by tie down decals where required. Securing to trailer at other points is unsafe and can damage attachment. Do not attach tie down accessories around cylinders or in any way that may damage hoses or hydraulic components.

- Attach tie down accessories to unit as recommended, if marked.
- Check unit stability before transporting.

WARNING!  **VERIFY THAT ALL TIE DOWN ACCESSORIES (CHAINS, SLINGS, ROPES, SHACKLES AND ETC.) ARE CAPABLE OF MAINTAINING ATTACHMENT STABILITY DURING TRANSPORTING and are attached in such a way to prevent unintended disengagement or shifting of the unit. Failure to do so could result in serious personal injury or death.**

MAINTENANCE SCHEDULE

Schedule

For best sweeper performance, follow this maintenance schedule.

Part	Schedule				
	Daily	Every 50 hr.	Every 100 hr	Every 500 hr	See Prime Mover Manual
Brush Head Assembly: Check brush pattern (See Adjustments: Brush Pattern)	✓				
Hardware: Check and tighten if necessary	✓				
Hydraulic Filter Element: Change			✓		
Hydraulic Fittings & Hoses: Inspect for leaks or damage; repair or replace when necessary	✓				
Hydraulic Oil: Check level; add as needed	✓				
Change; Use ISO VG-46 oil				✓	
Prime Mover Air Cleaner: Clean or replace					✓
Swing Plate: Grease with EP2 or equivalent		✓			

Hydraulic System

NOTICE! *To prevent hydraulic system contamination, change hydraulic oil and filters at regularly scheduled intervals.*

Worn Section Standard				Reference Information	
Section OD, New	Ring ID	Section OD, Worn	Exposed Bristle, Worn	Bristle Length	Exposed Bristle, New
24	6.38	17	3.8	8.50	7.5
26	8.00	18	4.0	9.00	8.0
32	10.00	22	5.0	11.00	10.0
36	10.00	24	6.0	13.00	12.0
36	10.63	25	6.0	12.69	11.4
46	19.38	34	6.0	13.31	12.1

MAINTENANCE

Replacing Brush Sections

1. Remove motor mount lynch pins. Retain pins for reinstallation. Remove motor mount.
2. Remove motor assembly from core. Do not tangle hoses.
3. Remove bearing mount lynch pins. Retain pins for reinstallation.
4. Remove core from brush head assembly.
5. Remove retaining plate from core assembly.
6. Remove old sections.
7. Install new sections by doing the following:
 - a. Number the drive locations on the core as 1, 2, and 3 (figure 1)
 - b. Slide the first section onto the core with the drive pins on either side of the tube 1 (figure 2). Make sure that the drive pins face up.
 - c. Place the second section on the core with the drive pins on either side of tube 2. Be sure the drive pins face down.
 - d. Put the third section on with the drive pins around tube 3. Be sure the drive pins face up.
 - e. Slide sections on until the core is full, making sure to alternate the tubes used and the direction of the drive pins.
8. Re-attach the section retaining plate.
9. Place the core back into the brush frame.
10. Slide motor assembly back into the core taking care not to tangle hoses.
11. Re-attach motor mount with pins removed in first step.
12. Re-attach the bearing plate with pins removed from step 3.

MAINTENANCE




figure 1




figure 2



TROUBLESHOOTING

Brush Head

Problem	Possible Causes	Possible Solution
Brush rotates wrong direction	Hoses installed incorrectly	Switch hoses at brush head tubes
Brush slows or stops when sweeping	Brush pattern too wide	Adjust brush pattern to 2-4 inches (51-102mm) wide: see Maintenance: Adjusting Brush Pattern
	Travel speed too fast	Travel no more than 5 mph (8 kph) while sweeping
	Trying to sweep too much material at once	Make several passes with sweeper
	Relief pressure set too low	Set relief pressure to 2000 psi (138.0 bars)
	Pump has failed	Contact dealer to repair or replace
	Filter plugging	Change or clean filter
	Hydraulic motor is failing	Test hydraulic system: see Troubleshooting: Hydraulic Problems
Brush head assembly "bounces" during sweeping	Spring-chain assembly too loose	Adjust spring-chain assembly, see: Adjusting Spring-Chain Assembly
	Travel speed too fast and/or brush speed too slow	Find correct combination of ground and brush speeds: do not travel at more than 5 mph (8 kph)
	Core is bent	Replace core
Brush wears into cone shape	Sweeper is not level	Level sweeper before each use, see: Leveling
	Tires on prime mover at different pressures or are different sizes	Check tire sizes and rating: make corrections as necessary
Brush wears very quickly	Brush pattern too wide	Adjust pattern to 2-4 inches (51-102mm) wide, see: Setting Brush Pattern

Spring-Chain Assemblies

Problem	Possible Causes	Possible Solution
Springs on spring-chain assemblies stretching	Transport chain too loose when traveling between job sites	Adjust according to Adjustment: Transport Chain
	Travel speeds too fast when sweeping	Do not travel at speeds over 5 mph (8kph)

TROUBLESHOOTING

Hydraulic System

Problem	Possible Causes	Possible Solution
Hydraulic system overheats	Hydraulic oil level too low	Add hydraulic oil to tank until it comes to 2 inches (51mm) from top
	Restriction in hoses	Remove bends in hoses; remove obstructions inside hoses
	Host pump flow rate exceeds maximum gpm rating for broom. Back pressure exceeds BTU removal by heat exchanger	Contact host manufacturer for proper flow control method
Hydraulic quick couplers leak	Quick coupler poppet is unseated	Reseat poppet; replace quick coupler if poppet is beyond repair
Hydraulic motor seals leak	Flow rate exceeds maximum gpm rating for broom. Hydraulic pressure exceeds maximum psi rating for broom	Contact Sweepster
	Motor is failing	High number of hours on motor; Contact dealer to rebuild or replace
Hydraulic oil flows from breather cap on hydraulic tank	Hydraulic tank too full	Drain hydraulic tank until level is 2 inches (51mm) from top

TROUBLESHOOTING

Hydraulic Problems

If hydraulic problems - which include the brush failing to rotate, the brush slowing or stopping when making contact with the sweeping surface or swing/lift cylinders not functioning - occur, complete all the following checks on the hydraulic system.

WARNING! Avoid serious injury.



Test components must have a minimum rating of 3000 psi (206.0 bars). Otherwise, components could rupture, causing serious injury. Open the gate valve before beginning any tests.

Do not operate the hydraulic system more than 5 seconds with pressure over 2000 psi (138.0 bars). Higher pressures can rupture hydraulic components and cause serious injury.

Testing Relief Setting

1. Add a flow meter, pressure gauge and gate valve on the pressure side of the sweeper hydraulic system.
2. Raise the sweeper. Then, engage the brush.
3. Shut the gate valve and note the reading on the pressure gauge.

CAUTION! Avoid pump damage. Do not run test for more than 5 seconds.

4. Refer to the prime mover manual for proper relief setting. If the pressure gauge reading does not match manufacturer's recommendations, take the prime mover to your dealer for repair.
5. Go to Testing Pump or Prime Mover Hydraulics.

Testing Power Pack Hydraulic Pump

Complete the following steps to test the pump on units with a power pack.

1. Place a pressure gauge, flow gauge and gate valve between the pump and the pressure line on the brush frame.
2. Make sure the prime mover is in Neutral with the parking brake on. Start the prime mover at idle and engage the sweeper.
3. Raise engine speed to normal operating rpm.

TROUBLESHOOTING


4. Note the reading on the flow gauge. Then, shut the gate valve. Note the reading on the pressure gauge.
 - If the flow gauge reads at least 10 gpm (.63 lps) and the pressure gauge reached 2000 psi (138.0 bars), the pump is functioning properly.
 - If the flow and/or pressure did not reach the proper reading, the pump has failed. Take it to your dealer to have it rebuilt or replaced.
5. Remove the pressure gauge, flow gauge and gate valve and reconnect hoses.
6. Go to Testing Brush Head Motors.

Testing Brush Head Motors

1. Place a pressure gauge and flow gauge between the sweeper or prime mover hydraulic tank and the return line on the brush frame.
2. Make sure the prime mover is in Neutral with the parking brake on. Start the prime mover at idle and engage the sweeper. Then, adjust the brush to the maximum sweeping pattern.
3. When the brush stalls, note the reading on the flow gauge. If it is 3 gpm (.19 lps) or more, the motor(s) need(s) to be replaced.

PRODUCT SPECIFICATIONS


222 Brush Head



222 Brush Head							
	22248	22249	22259	22260	22261	22272	22273
A. Overall Height	27.1 inches (68.8 cm)						
B Overall Width @ 0°	59.4 inches (151 cm)	71.4 inches (181 cm)			83.4 inches (212 cm)		
C. Overall Length @ 0°	54.4 inches (138 cm)						
D. Sweeping Width @ 0°	48 inches (122 cm)	60 inches (152 cm)			72 inches (183 cm)		
E. Overall Length @30°	60.7 inches (154 cm)	63.7 inches (162 cm)			66.7 inches (169 cm)		
F. Overall Width @ 30°	60 inches (152 cm)	72 inches (183 cm)			84 inches (213 cm)		
G. Sweeping Width @30°	41.5 inches (105 cm)	52 inches (132 cm)			60.4 inches (153 cm)		
H. Center of Gravity	26.5 inches (67.3 cm)	27.5 inches (69.9 cm)			28.5 inches (72.4 cm)		
Weight	370 lbs (168 kg)		405 lbs (184 kg)			440 lbs (200 kg)	
Flow Range	8-15 gpm (30-57 lpm)	10-18 gpm (38-68 lpm)	4-10 gpm (15-38 lpm)	8-15 gpm (30-57 lpm)	10-18 gpm (38-68 lpm)	8-15 gpm (30-57 lpm)	10-18 gpm (38-68 lpm)
Maximum Pressure	3000 psi (206 bar)						
Maximum Articulation	30 Degrees						
Brush Diameter	26 inches (66 cm)						

PRODUCT SPECIFICATIONS


225 Brush Head



225 Brush Head						
	22560	22561	22572	22573	22659	22585
A. Overall Height	32 inches (81.3 cm)					
B Overall Width @ 0°	70.3 inches (178.6 cm)	82.3 inches (209 cm)		94.3 inches (239.5 cm)		
C. Overall Length @ 0°	58.3 inches (148.1 cm)					
D. Sweeping Width @ 0°	48 inches (122 cm)	60 inches (152 cm)		72 inches (183 cm)		
E. Overall Length @30°	67.1 inches (170.4 cm)	70.1 inches (178.1 cm)		73.1 inches (185.7 cm)		
F. Overall Width @ 30°	70.7 inches (179.6 cm)	81.1 inches (206 cm)		91.5 inches (232.4 cm)		
G. Sweeping Width @30°	52 inches (132 cm)	62.4 inches (159 cm)		72.8 inches (185 cm)		
H. Center of Gravity	29.1 inches (73.9 cm)	30 inches (76.2 cm)		30.8 inches (78.2 cm)		
Weight	445 lbs (202 kg)		485 lbs (220 kg)		525 lbs (238 kg)	
Flow Range	8-15 gpm (30-57 lpm)	10-18 gpm (38-68 lpm)	8-15 gpm (30-57 lpm)	10-18 gpm (38-68 lpm)	8-15 gpm (30-57 lpm)	10-18 gpm (38-68 lpm)
Maximum Pressure	3000 psi (206 bar)					
Maximum Articulation	30 Degrees					
Brush Diameter	30 inches (76 cm)					

PRODUCT SPECIFICATIONS

226 Brush Head



226 Brush Head					
	22640	22641	22646	22647	22659
A. Overall Height	27.8 inches (70.6 cm)				
B Overall Width @ 0°	53.4 inches (135.6 cm)		59.4 inches (150.9 cm)		71.4 inches (181.4 cm)
C. Overall Length @ 0°	54.4 inches (138 cm)				
D. Sweeping Width @ 0°	42 inches (107 cm)		48 inches (122 cm)		60 inches (152 cm)
E. Overall Length @30°	57.4 inches (145.8 cm)		58.9 inches (149.6 cm)		61.9 inches (157.2 cm)
F. Overall Width @ 30°	54 inches (137.2 cm)		60 inches (152 cm)		72 inches (183 cm)
G. Sweeping Width @30°	36.3 inches (92 cm)		41.5 inches (105 cm)		52 inches (132 cm)
H. Center of Gravity	27.2 inches (69.1 cm)		27.7 inches (70.4 cm)		28.7 inches (72.9 cm)
Weight	318 lbs (144 kg)		335 lbs (152 kg)		370 lbs (168 kg)
Flow Range	4-8 gpm (15-30 lpm)	6-12 gpm (23-45 lpm)	4-8 gpm (15-30 lpm)	6-12 gpm (23-45 lpm)	6-12 gpm (23-45 lpm)
Maximum Pressure	3000 psi (206 bar)				
Maximum Articulation	30 Degrees				
Brush Diameter	26 inches (66 cm)				

BOLT TORQUE SPECIFICATIONS

GENERAL TORQUE SPECIFICATION TABLES

Use the following charts when determining bolt torque specifications when special torques are not given. Always use grade 5 or better when replacing bolts.

SAE BOLT TORQUE SPECIFICATIONS

NOTE: The following torque values are for use with extreme pressure lubricants, plating or hard washer applications increase torque 15% when using hardware that is unplated and either dry or lubricated with engine oil.

Bolt Size		SAE GRADE 5 TORQUE				SAE GRADE 8 TORQUE				Bolt head identification marks as per grade. NOTE: Manufacturing Marks Will Vary
		Pounds Feet		Newton-Meters		Pounds Feet		Newton-Meters		
Inches	Millimeters	UNC	UNF	UNC	UNF	UNC	UNF	UNC	UNF	
1/4	6.35	8	9	11	12	10	13	14	18	<p>GRADE 2</p>  <p>GRADE 5</p>  <p>GRADE 8</p> 
5/16	7.94	14	17	19	23	20	25	27	34	
3/8	9.53	30	36	41	49	38	46	52	62	
7/16	11.11	46	54	62	73	60	71	81	96	
1/2	12.70	68	82	92	111	94	112	127	152	
9/16	14.29	94	112	127	152	136	163	184	221	
5/8	15.88	128	153	174	207	187	224	254	304	
3/4	19.05	230	275	312	373	323	395	438	536	
7/8	22.23	340	408	461	553	510	612	691	830	
1	25.40	493	592	668	803	765	918	1037	1245	
1-1/8	25.58	680	748	922	1014	1088	1224	1475	1660	
1-1/4	31.75	952	1054	1291	1429	1547	1700	2097	2305	
1-3/8	34.93	1241	1428	1683	1936	2023	2312	2743	3135	
1-1/2	38.10	1649	1870	2236	2535	2686	3026	3642	4103	

METRIC BOLT TORQUE SPECIFICATIONS

NOTE: The following torque values are for use with metric hardware that is unplated and either dry or lubricated with engine oil. Reduce torque 15% when using hardware that has extreme pressure lubricants, plating or hard washer applications.


Bolt head identification marks as per grade.		
		

Size of Bolt	Grade No.	Pitch (mm)	Pounds Feet	Newton-Meters	Pitch (mm)	Pounds Feet	Newton-Meters
M6	5.6	1.0	3.6-5.8	4.9-7.9	-	-	-
	8.8		5.8-4	7.9-12.7		-	-
	10.9		7.2-10	9.8-13.6		-	-
M8	5.6	1.25	7.2-14	9.8-19	1.0	12-17	16.3-23
	8.8		17-22	23-29.8		19-27	25.7-36.6
	10.9		20-26	27.1-35.2		22-31	29.8-42
M10	5.6	1.5	20-25	27.1-33.9	1.25	20-29	27.1-39.3
	8.8		34-40	46.1-54.2		35-47	47.4-63.7
	10.9		38-46	51.5-62.3		40-52	54.2-70.5
M12	5.6	1.75	28-34	37.9-46.1	1.25	31-41	42-55.6
	8.8		51-59	69.1-79.9		56-68	75.9-92.1
	10.9		57-66	77.2-89.4		62-75	84-101.6
M14	5.6	2.0	49-56	66.4-75.9	1.5	52-64	70.5-86.7
	8.8		81-93	109.8-126		90-106	122-143.6
	10.9		96-109	130.1-147.7		107-124	145-168
M16	5.6	2.0	67-77	90.8-104.3	1.5	69-83	93.5-112.5
	8.8		116-130	157.2-176.2		120-138	162.6-187
	10.9		129-145	174.8-196.5		140-158	189.7-214.1
M18	5.6	2.0	88-100	119.2-136	1.5	100-117	136-158.5
	8.8		150-168	203.3-227.6		177-199	239.8-269.6
	10.9		175-194	237.1-262.9		202-231	273.7-313
M20	5.6	2.5	108-130	146.3-176.2	1.5	132-150	178.9-203.3
	8.8		186-205	252-277.8		206-242	279.1-327.9
	10.9		213-249	288.6-337.4		246-289	333.3-391.6

HYDRAULIC TORQUE SPECIFICATIONS

Face Seal: Assembly, Tube to Fitting

NOTICE - *Face seal fittings have the most reliable sealing method and therefore, should be used whenever possible.*



Installation

1. Make sure threads and sealing surfaces are free of burrs, nicks, scratches, or foreign materials.
2. Install proper SAE O-ring to end of fitting if not already installed. Ensure O-ring is fully seated and retained properly.
3. Lubricate O-ring with a light coating of clean hydraulic oil.
4. Position tube and nut squarely on face seal of fitting and tighten nut finger tight.
5. Using appropriate torquing device, tighten to given torque rating from the table below.

Torque Values

SAE Dash Size	Tube Side Thread Size	In-lbs	Ft-lbs
-4	9/16 - 18	220 ± 10	18 ± 1
-6	11/16 - 16	320 ± 25	27 ± 2
-8	13/16 - 16	480 ± 25	40 ± 2
-10	1 - 14	750 ± 35	63 ± 3
-12	1 3/16 - 12	1080 ± 45	90 ± 4
-16	1 7/16 - 12	1440 ± 90	120 ± 8
-20	1 11/16 - 12	1680 ± 90	140 ± 8
-24	2 - 12	1980 ± 100	165 ± 8


NOTE - ft-lb may be converted to Newton Meters by multiplying by 1.35582.

NOTE - in-lbs may be converted to Newton Meters by multiplying by 0.11298.

HYDRAULIC TORQUE SPECIFICATIONS

Straight Thread O-ring Fitting: Assembly, Fitting to Port


NOTE - Straight thread o-ring fittings are utilized to adapt hydraulic systems to motors, pumps, cylinders, and valves.



Installation (Adjustable Fitting)

1. Make sure threads and sealing surfaces are free of burrs, nicks, scratches, or any foreign materials.
2. Install proper SAE o-ring on port end of fitting if not already installed. Ensure o-ring is fully seated and retained properly.
3. Lubricate o-ring with a light coating of clean hydraulic oil.
4. Back off nut as far as possible and push washer up as far as possible. (figure 4 & 5)
5. Screw fitting into port. Hand tighten fitting until backup washer contacts face of port. (figure 6)
6. To position the fitting, unscrew to desired position, but not more than one full turn.
7. Hold fitting in position with wrench. Using appropriate torquing device, tighten nut to given torque rating from table. (figure 7)

Fitting Size	SAE Port Thread Size	In-lbs	Ft-lbs
-4	7/16 - 20	190 ± 10	16 ± 1
-6	9/16 - 18	420 ± 15	35 ± 1
-8	3/4 - 14	720 ± 25	60 ± 2
-10	7/8 - 14	1260 ± 50	105 ± 5
-12	1 1/16 - 12	1680 ± 75	140 ± 6
-16	1 5/16 - 12	2520 ± 100	210 ± 8
-20	1 5/8 - 12	3100 ± 150	260 ± 12
-24	1 7/8 - 12	3800 ± 150	315 ± 12



NOTE - ft-lb may be converted to Newton Meters by multiplying by 1.35582.
NOTE - in-lbs may be converted to Newton Meters by multiplying by 0.11298.

WARRANTY

Limited Warranty

Except for the Excluded Products as described below, all new products are warranted to be free from defects in material and/or workmanship during the Warranty Period, in accordance with and subject to the terms and conditions of this Limited Warranty.

1. Excluded Products. The following products are excluded from this Limited Warranty:

(a) Any cable, part that engages with the ground (i.e. sprockets), digging chain, bearing, teeth, tamping and/or demolition head, blade cutting edge, pilot bit, auger teeth and broom brush that either constitutes or is part of a product.

(b) Any product, merchandise or component that, in the opinion of Paladin Light Construction¹, has been (i) misused; (ii) modified in any unauthorized manner; (iii) altered; (iv) damaged; (v) involved in an accident; or (vi) repaired using parts not obtained through Paladin Light Construction.

2. Warranty Period. The Limited Warranty is provided only to those defects that occur during the Warranty Period, which is the period that begins on the first to occur of: (i) the date of initial purchase by an end-user, (ii) the date the product is first leased or rented, or (iii) the date that is six (6) months after the date of shipment by Paladin Light Construction as evidenced by the invoiced shipment date (the "Commencement Date") and ends on the date that is twelve (12) months after the Commencement Date.

3. Terms and Conditions of Limited Warranty. The following terms and conditions apply to the Limited Warranty hereby provided:

(a) Option to Repair or Replace. Paladin Light Construction shall have the option to repair or replace the product.

(b) Timely Repair and Notice. In order to obtain the Limited Warranty, (i) the product must be repaired within thirty (30) days from the date of failure, and (ii) a claim under the warranty must be submitted to Paladin Light Construction in writing within thirty (30) days from the date of repair.

(c) Return of Defective Part or Product. If requested by Paladin Light Construction, the alleged defective part or product shall be shipped to Paladin Light Construction at its manufacturing facility or other location specified by Paladin Light Construction, with freight PRE-PAID by the claimant, to allow Paladin Light Construction to inspect the part or product.

Claims that fail to comply with any of the above terms and conditions shall be denied.

LIMITATIONS AND EXCLUSIONS.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY BASED ON A COURSE OF DEALING OR USAGE OF TRADE.

IN NO EVENT SHALL PALADIN LIGHT CONSTRUCTION BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES.

IN NO EVENT SHALL PALADIN LIGHT CONSTRUCTION BE LIABLE FOR ANY LOSS OR CLAIM IN AN AMOUNT IN EXCESS OF THE PURCHASE PRICE, OR, AT THE OPTION OF PALADIN LIGHT CONSTRUCTION, THE REPAIR OR REPLACEMENT, OF THE PARTICULAR PRODUCT ON WHICH ANY CLAIM OF LOSS OR DAMAGE IS BASED. THIS LIMITATION OF LIABILITY APPLIES IRRESPECTIVE OF WHETHER THE CLAIM IS BASED ON BREACH OF CONTRACT, BREACH OF WARRANTY, NEGLIGENCE OR OTHER CAUSE AND WHETHER THE ALLEGED DEFECT IS DISCOVERABLE OR LATENT.

¹Attachment Technologies Inc., a subsidiary of Paladin Brands Holding, Inc. (PBHI) is referred to herein as Paladin Light Construction.


NOTES

BRUSH HEAD 222 STANDARD

Assembly 28-10305

Item	Part	Qty	Description
1.	03-2490	1	Clamp, Hose, Double, Rubber Coat
4.	03-5620	2	Hose, .5 x 72, TC, 8FF-12FF (4-5 ft)
	03-5111	2	Hose, 5 x 84, TC, 8FF-12FF (6 ft)
5.	07-0018	4	Screw, HHC, Gr8, 3/8-16 x 1
6.	07-0156	2	Washer, Flat, Gr8, 1/2
7.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
8.	07-0209	1	Clip, Hairpin, 16ga x 1 3/8
9.	07-1718	4	Washer, Lock, Split, Medium, 3/8
10.	07-1762	2	Washer, Lock, Split, Medium, 1/2
11.	07-1764	2	Nut, Hex, Gr8, 1/2-13
12.	07-2952	12	Screw, HFH, CL10.9, M6-1 x 20
13.	07-3279	4	Washer, Flat, Gr8, 3/8
14.	07-3617	12	Nut, Insert, Hex, M6 x 1
15.	07-3654	4	Nut, Gr8, 3/8-16
16.	07-3708	2	Bolt, Carriage, Gr5, 1/2-13 x 1 1/2
17.	07-3736	1	Washer, Flat, CL8.8, M8
18.	07-3747	6	Washer, Lock, Split, Medium, M10
19.	07-4046	2	Pin, Clevis, 3/4 x 2
20.	07-4522	4	Clip, Hairpin, .162 x 3.43
21.	07-4523	8	Cap, Tube, Vinyl, 1 x .51, Black
22.	07-4539	1.5ft	Sleeve, Hose, 3/4, Partek, Bulk
23.	07-6488	1	Pin, Clevis, 3/8 x 5 1/2
24.	07-6769	6	Screw, HHC, CL10.9, M10-1.5 x 16mm
25.	13-13457	1	Sheet, Side, Hood, Left
26.	13-13458	1	Sheet, Side, Hood, Right
27.	13-13525	1	Plate, Mounting
28.	13-14083	6	Stud, Mounting, Motor
29.	13-16178-4	1	Sheet, Hood (4 ft)
	13-16178-5	1	Sheet, Hood (5 ft)
	13-16178-6	1	Sheet, Hood (6 ft)
30.	13-16638-4	1	Weld, Brush Head Frame (4 ft)
	13-16638-5	1	Weld, Brush Head Frame (5 ft)
	13-16638-6	1	Weld, Brush Head Frame (6 ft)
31.	13-9818	4	Tube, Round, Stand
32.	P852608	6	Washer, Hard, 1/2
33.	RHW8068	6	Pin, Lynch, .25-1.56

BRUSH HEAD 222 STANDARD




BRUSH HEAD 222 WITH HEAVY DUTY STANDS

Assembly 28-10835

Item	Part	Qty	Description
1.	03-2490	1	Clamp, Hose, Double, Rubber Coat
2.	03-5620	2	Hose, .5 x 72, TC, 8FF-12FF (4-5 ft)
	03-5111	2	Hose, 5 x 84, TC, 8FF-12FF (6 ft)
4.	07-0018	4	Screw, HHC, Gr8, 3/8-16 x 1
5.	07-0156	2	Washer, Flat, Gr8, 1/2
6.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
7.	07-0209	1	Clip, Hairpin, 16ga x 1 3/8
8.	07-1718	4	Washer, Lock, Split, Medium, 3/8
9.	07-1762	2	Washer, Lock, Split, Medium, 1/2
10.	07-1764	2	Nut, Hex, Gr8, 1/2-13
11.	07-2952	12	Screw, HFH, CL10.9, M6-1 x 20
12.	07-3279	4	Washer, Flat, Gr8, 3/8
13.	07-3617	12	Nut, Insert, Hex, M6 x 1
14.	07-3654	4	Nut, Gr8, 3/8-16
15.	07-3708	2	Bolt, Carriage, Gr5, 1/2-13 x 1 1/2
16.	07-3736	1	Washer, Flat, CL8.8, M8
17.	07-3747	6	Washer, Lock, Split, Medium, M10
18.	07-4046	2	Pin, Clevis, 3/4 x 2
19.	07-4522	4	Clip, Hairpin, .162 x 3.43
20.	07-4539	1.5ft	Sleeve, Hose, 3/4, Partek, Bulk
21.	07-6488	1	Pin, Clevis, 3/8 x 5 1/2
22.	07-6769	6	Screw, HHC, CL10.9, M10-1.5 x 16mm
23.	13-13457	1	Sheet, Side, Hood, Left
24.	13-13458	1	Sheet, Side, Hood, Right
25.	13-13525	1	Plate, Mounting
26.	13-14083	6	Stud, Mounting, Motor
27.	13-16178-4	1	Sheet, Hood (4 ft)
	13-16178-5	1	Sheet, Hood (5 ft)
	13-16178-6	1	Sheet, Hood (6 ft)
28.	13-16638-4	1	Weld, Brush Head Frame (4 ft)
	13-16638-5	1	Weld, Brush Head Frame (5 ft)
	13-16638-6	1	Weld, Brush Head Frame (6 ft)
29.	13-17877	4	Tube, Round, Stand, Heavy Duty
30.	P852608	6	Washer, Hard, 1/2
31.	RHW8068	6	Pin, Lynch, .25-1.56

BRUSH HEAD 222 WITH HEAVY DUTY STANDS




BRUSH HEAD 225

Item	Part	Qty	Description
1.	03-2490	1	Clamp, Hose, Double, Rubber Coat
4.	03-5620	2	Hose, .5 x 72, TC, 8FF-12FF (4-5 ft)
	03-5111	2	Hose, 5 x 84, TC, 8FF-12FF (6-7 ft)
5.	07-0018	4	Screw, HHC, Gr8, 3/8-16 x 1
6.	07-0156	2	Washer, Flat, Gr8, 1/2
7.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
8.	07-0209	1	Clip, Hairpin, 16ga x 1 3/8
9.	07-1718	4	Washer, Lock, Split, Medium, 3/8
10.	07-1762	2	Washer, Lock, Split, Medium, 1/2
11.	07-1764	2	Nut, Hex, Gr8, 1/2-13
12.	07-2952	12	Screw, HFH, CL10.9, M6-1 x 20
13.	07-3279	4	Washer, Flat, Gr8, 3/8
14.	07-3617	12	Nut, Insert, Hex, M6 x 1
15.	07-3654	4	Nut, Gr8, 3/8-16
16.	07-3708	2	Bolt, Carriage, Gr5, 1/2-13 x 1 1/2
17.	07-3736	1	Washer, Flat, CL8.8, M8
18.	07-3747	6	Washer, Lock, Split, Medium, M10
19.	07-4046	2	Pin, Clevis, 3/4 x 2
20.	07-4522	4	Clip, Hairpin, .162 x 3.43
21.	07-4523	8	Cap, Tube, Vinyl, 1 x .51, Black
22.	07-4539	1.5ft	Sleeve, Hose, 3/4, Partek, Bulk
23.	07-6488	1	Pin, Clevis, 3/8 x 5 1/2
24.	07-6769	6	Screw, HHC, CL10.9, M10-1.5 x 16mm
25.	13-13457	1	Sheet, Side, Hood, Left
26.	13-13458	1	Sheet, Side, Hood, Right
27.	13-13525	1	Plate, Mounting
28.	13-14083	6	Stud, Mounting, Motor
29.	13-16178-4	1	Sheet, Hood (4 ft)
	13-16178-5	1	Sheet, Hood (5 ft)
	13-16178-6	1	Sheet, Hood (6 ft)
	13-16178-7	1	Sheet, Hood (7 ft)
30.	13-16638-4	1	Weld, Brush Head Frame (4 ft)
	13-16638-5	1	Weld, Brush Head Frame (5 ft)
	13-16638-6	1	Weld, Brush Head Frame (6 ft)
	13-16638-7	1	Weld, Brush Head Frame (7 ft)
31.	13-9818	4	Tube, Round, Stand
32.	P852608	6	Washer, Hard, 1/2
33.	RHW8068	6	Pin, Lynch, .25-1.56

BRUSH HEAD 226


Item	Part	Qty	Description
1.	03-2490	1	Clamp, Hose, Double, Rubber Coat
2.	03-4562	2	Hose, .5 x 60, 8FF-8FF, 4.25K
5.	07-0018	4	Screw, HHC, Gr8, 3/8-16 x 1
7.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
8.	07-0209	1	Clip, Hairpin, 16ga x 1 3/8
9.	07-1718	4	Washer, Lock, Split, Medium, 3/8
12.	07-2952	12	Screw, HFH, CL10.9, M6-1 x 20
13.	07-3279	4	Washer, Flat, Gr8, 3/8
14.	07-3617	12	Nut, Insert, Hex, M6 x 1
15.	07-3654	4	Nut, Gr8, 3/8-16
17.	07-3736	1	Washer, Flat, CL8.8, M8
18.	07-3747	6	Washer, Lock, Split, Medium, M10
19.	07-4046	2	Pin, Clevis, 3/4 x 2
20.	07-4522	4	Clip, Hairpin, .162 x 3.43
21.	07-4523	8	Cap, Tube, Vinyl, 1 x .51, Black
22.	07-4539	1.5ft	Sleeve, Hose, 3/4, Partek, Bulk
23.	07-6488	1	Pin, Clevis, 3/8 x 5 1/2
24.	07-6769	6	Screw, HHC, CL10.9, M10-1.5 x 16mm
25.	13-13457	1	Sheet, Side, Hood, Left
26.	13-13458	1	Sheet, Side, Hood, Right
28.	13-14083	6	Stud, Mounting, Motor
29.	13-16178-42	1	Sheet, Hood (3.5 ft)
	13-16178-4	1	Sheet, Hood (4 ft)
	13-16178-5	1	Sheet, Hood (5 ft)
30.	13-16638-42	1	Weld, Brush Head Frame (3.5 ft)
	13-16638-4	1	Weld, Brush Head Frame (4 ft)
	13-16638-5	1	Weld, Brush Head Frame (5 ft)
31.	13-9818	4	Tube, Round, Stand
32.	P852608	6	Washer, Hard, 1/2
33.	RHW8068	6	Pin, Lynch, .25-1.56

CORE




Item	Part	Qty	Description
1.	07-3617	3	Nut, Insert, Hex, M6 x 1
2.	07-3730	3	Washer, Lock, Split, Medium, M6
3.	07-3731	3	Screw, HHC, CL10.9, M6-1 x 30mm
4.	13-15657-42	1	Weld, Core, 8, 3.5 ft
	13-15657-4	1	Weld, Core, 8, 4 ft
	13-15657-5	1	Weld, Core, 8, 5 ft
	13-15657-6	1	Weld, Core, 8, 6 ft
	13-15657-7	1	Weld, Core, 8, 7 ft
5.	13-15662	1	Plate, Section Retainer, 8

BEARING



Item	Part	Qty	Description
1.	07-2950	3	Bolt, Carriage, CL8.8, M8-1.25 x 20mm
2.	07-3737	3	Nut, Hex, CL10, M8-1.25
3.	07-3738	4	Washer, Lock, Split, Medium, M8
4.	07-3747	6	Washer, Lock, Split, Medium, M10
5.	07-3749	6	Screw, HHC, CL10.9, M10-1.5 x 30mm
6.	07-3777	1	Screw, HHC, CL10.9, M8-1.25 x 20
7.	08-0008	2	Bearing, Flange, 3 Bolt
8.	08-0037	1	Bearing, 7/8 Hex, without Hub
9.	13-11903	1	Washer, .34 x 1.88 x 10ga
10.	13-16923	1	Weld, Hex, Shaft, Idler, Bolt-In
11.	13-17015	1	Plate, Mounting, Bearing

MOTOR ASSEMBLY



Replacement Part for 03-6445

- 03-6469 Seal Kit
- 07-7529 Replacement Key
- 07-8215 Motor Shaft Nut

Replacement Part for 03-6444

- 03-6468 Seal Kit
- 07-7529 Replacement Key
- 07-8215 Motor Shaft Nut

Replacement Part for 03-6446

- 03-6468 Seal Kit
- 07-1948 Replacement Key
- 07-8214 Motor Shaft Nut

Replacement Part for 03-6447

- 03-6467 Seal Kit
- 07-1948 Replacement Key
- 07-8214 Motor Shaft Nut

Item Part Qty Description

1.	03-3481	2	Fitting, 10MB-8MF
2.	03-6445	1	Motor, 14.5 CID (MRHL) (Serial # 1234001 & Up)
	03-5614	1	Motor, 14.2 CID (MRHL) (Serial # 1233199 & Down)
	03-6444	1	Motor, 17.1 CID (MRHL) (Serial # 1234001 & Up)
	03-5612	1	Motor, 18.3 CID (MRHL) (Serial # 1233199 & Down)
	03-6446	1	Motor, 8.0 CID (CTC/MRHL) (Serial # 1234001 & Up)
	03-5615	1	Motor, 7.9 CID (CTC) (Serial # 1233199 & Down)
	03-6447	1	Motor, 11.9 CID (CTC) (Serial # 1234001 & Up)
	03-5616	1	Motor, 12.2 CID (CTC) (Serial # 1233199 & Down)
3.	07-3747	6	Washer, Lock, Split, Medium, M10
4.	07-3749	6	Screw, HHC, CL10.9, M10-1.5 x 30mm
5.	07-3754	4	Washer, Flat, CL10.9, M12
6.	07-3755	4	Nut, Hex, CL10.9, M12-1.75
7.	07-3756	4	Washer, Lock, Split, Medium, M12
8.	07-6683	4	Screw, HHC, CL10.9, M12-1.75 x 65mm
9.	13-15206	1	Hub, Hex, 2 1/2 x 1 1/4 Tapered Bore x 3.75 (MRHL)
	13-18135	1	Hub, Hex, Drive (CTC/MRHL) (Serial # 1234001 & Up)
	13-15205	1	Hub, Hex, Drive (CTC) (Serial # 1233199 & Down)
10.	13-16225	1	Plate, Receiver, Hex, 2.5
11.	13-17016	1	Plate, Mounting, Motor

Replacement Part for 03-5614

- 03-5503 Seal Kit
- 07-7286 Replacement Key

Replacement Part for 03-5612

- 03-5503 Seal Kit
- 07-7286 Replacement Key
- 07-4568 Motor Shaft Nut

Replacement Part for 03-5615

- 03-5211 Seal Kit
- 07-0794 Replacement Key


Replacement Part for 03-5616

- 03-5211 Seal Kit
- 07-0794 Replacement Key

Not Shown:


- 07-4568 1 Nut, Motor, Shaft

222/225 WITH QUICK ATTACH MOUNTING



Item	Part	Qty	Description
1.	07-0066	1	Screw, HHC, Gr 8, 5/8-11 x 2
2.	07-0237	2	Spring, Tens, 1-13/32 x 6
3.	07-0387	2	Chain, 3/16, 26 Links
4.	07-1294	1	Nut, Hex, Gr 8, 5/8-11
5.	07-1759	1	Chain, 3/16, 36 Links
6.	07-1872	1	Washer, Lock, Split, 5/8
7.	11-1277	1	Weld, Plate, Swing, MRHL
8.	11-7479	1	Bushing, 1 x 5/8 x 7/16
9.	Varies	1	Weld, Frame, Mounting (Contact Sweepster for correct frame for your application)


226 WITH QUICK ATTACH MOUNTING 11-17602



226 WITH QUICK ATTACH MOUNTING 11-17602

Item	Part	Qty	Description
1.	03-1919	2	Fitting, 8MF-8MF
2.	03-3515	2	Fitting, 12MB-8MF
3.	03-3896	2	Hose, .5 x 36, 8FF-8FF, 3K, TC
4.	07-0209	1	Clip, Hairpin, 16ga x 1 3/8
5.	07-0237	2	Spring, Tension, 1 13/32 x 6
6.	07-1294	1	Nut, Hex, Gr8, 5/8-11
7.	07-1872	1	Washer, Lock, Split, Medium, 5/8
8.	07-2843	2	Pin, Klik, 3/16 x 1 5/8
9.	07-3013	2	Bushing, Caster
10.	07-3015	8	Spacer, Caster
11.	07-3112	2	Fitting, Zerk, 1/4-28, Self-Tap
12.	07-3120	1	Washer, Flat, Gr8, 5/8
13.	07-3433	1	Screw, HHC, Gr8, 5/8-11 x 1 1/2
14.	07-3676	2	Screw, HHC, Gr8, 1/2-13 x 5
15.	07-4037	2	Nut, Hex, Nylock, Gr8, 1/2-13
16.	07-4367	2	Wheel, Caster, 6.25 x 5/8, Black
17.	07-6488	1	Pin, Clevis, 3/8 x 5 1/2
18.	07-7077	1	Pin, Quick Release, Shoulder Type
19.	08-0131	4	Bearing, Caster
20.	11-7479	1	Bushing, 1 x 5/8 x 7/16
21.	Varies	1	Weld, Mounting (Contact Sweepster for correct mounting)
22.	13-16680	1	Weld, Swing, with Casters
23.	13-16911	1	Chain, 3/16, 48 Links
24.	13-4291	2	Weld, Caster Fork
25.	P272670	1	Coupler
26.	P272671	1	Coupler

MANUAL ANGLE KIT 11-5819




Item	Part	Qty	Description
1.	07-0210	2	Clip, Hairpin, 14Ga x 1 3/4
2.	07-2105	1	Pin, Lock, 3/8 Square Bail
5.	13-4193	1	Tube, Link, Outer
6.	13-4194	1	Tube, Link, Inner

NOTES

MRHL POWER PACK 11-7692

Service Part for 03-0691 Pump
03-0597A Seal Kit



MRHL POWER PACK 11-7692

Item	Part	Qty	Description
1.	03-0129	1	Valve, Relief, 3/4 Ports
2.	03-0691	1	Pump, PTO, 12gpm
3.	03-0710	1	Fitting, Barb, HP, 90°, 1 1/4, 1 5/16MOR
4.	03-0711	1	Fitting, Barb, HP, 90°, 1 1/4, 1MP
5.	03-0744	1	Filter, Element, 25 Micron, Spin-On
6.	03-0745	1	Filter, Base, Spin-On
7.	03-0834	1	Fitting, Nipple, HP, Hex, 3/4MP, 1/2MP
8.	03-1182-2	1	Fitting, Plug, BP, Square, 1/4P
9.	03-1920	2	Fitting, 12MF-12MF
10.	03-1943	3	Fitting, 12MF-12MP
11.	03-3478	1	Fitting, 8MF-8MP
12.	03-3750	1	Fitting, 8MF-12MP
13.	03-3787	1	Elbow, 90°, 12FF-12MB
14.	03-4709	1	Gauge, Sight Window, 1 inch
15.	03-4923	2	Hose, .75 x 156, 12FF-12FF, 3K
16.	03-5044	1	Hose, .5 x 50, 8FF-8FF90, 3K
17.	07-0156	2	Washer, Flat, Gr8, 1/2
18.	07-0245	1	Cap, Breather
19.	07-0246	1	Chain, 1/4 x 13 Links
20.	07-0285	2	Pin, Link, Gr2
21.	07-1192	2	Clamp, T-Bolt, 1 1/4
22.	07-1718	10	Washer, Lock, Split, Medium, 3/8
23.	07-1730	4	Bolt, Carriage, Gr5, 3/8 x 1 1/2
24.	07-1762	2	Washer, Lock, Split, Medium, 1/2
25.	07-1764	2	Nut, Hex, Gr8, 1/2-13
26.	07-3279	3	Washer, Flat, Gr8, 3/8
27.	07-3654	9	Nut, Hex, Gr8, 3/8-16
28.	07-3655	6	Screw, HHC, Gr8, 3/8 x 1 1/2
29.	07-3708	2	Bolt, Carriage, Gr5, 1/2 x 1 1/2
30.	09-0020	4ft	Hose, Suction, 1 1/4
31.	11-2147	1	Weld, Tank
32.	11-6115	2	Plate, Mounting, Tank
33.	11-7461	1	Weld, Mounting, Tank
34.	11-7466	4	Arm, Mounting, Tank, Hydraulic
35.	50-0184	1	Label, Sweepster, White, Small
36.	50-0272	1	Label, Oil, ISO, VG-46
37.	50-0635	1	Label, Plate, Part Number
38.	50-0725	1	Label, Warning, High Pressure Fluid

ELECTRIC WIRING HARNESS


Serial Number 1118199 & Down

LAF9444

Item Part Qty Description



- 1. 07-3152 1 Circuit Breaker
- 2. 07-0868 1 Switch
- 3. 07-1824 1 Rubber Boot

LAF9444 WIRE HARNESS		WIRE NO.	GUAGE	IDENTIFICATION	FROM	TO
1A	16	BLACK	PACKARD CONN. PIN F	BATTERY +12V	SPADE TERMINAL (MALE)	
1B	16	BLACK	PACKARD CONN. PIN F	BATTERY +	SPADE TERMINAL (FEMALE)	
2A	16	RED	CIRCUIT BREAKER 10A-AUX	CIRCUIT BREAKER 10A-BAIT		
2B	16	RED	PACKARD CONN. PIN B/DEPTH	SWITCH 1-A	SWITCH 1-B	
3	16	YELLOW	PACKARD CONN. PIN C-TILT	SWITCH 1-C	SWITCH 1-C	




LAF9441

LAF9441 WIRE HARNESS		WIRE NO.	GUAGE	IDENTIFICATION	FROM	TO
1A	16	BLACK	PACKARD PIN F	ULTRA SONIC SPLICE		
1B	16	BLACK	ULTRA SONIC SPLICE	PACKARD 1 PIN B		
1C	16	BLACK	ULTRA SONIC SPLICE	PACKARD 2 PIN B		
2	16	RED	PACKARD PIN B	PACKARD 1 PIN A		
3	16	YELLOW	PACKARD PIN C	PACKARD 2 PIN A		




07-7733

WIRE NO.	IDENTIFICATION	APPLICATION		□ END (LEFT) (BEYOND HARNESS)				△ END (RIGHT) (BEYOND HARNESS)				
		FROM	TO	SIZE	TYPE	EXTRA WIDE PROTECTION	TERMINAL	SIZE	TYPE	EXTRA WIDE PROTECTION	TERMINAL	
						YES	NO			YES	NO	
1A	RED	BATTERY (+)	ULTRA SONIC SPLICE	0.38	RING TERMINAL (WAYTEK # 32205)	-	X	-	ULTRA SONIC SPLICE	-	X	1A
1B	RED	ULTRA SONIC SPLICE	PACKCARD PIN A	-	ULTRA SONIC SPLICE	-	X	-	PACKCARD 12129493 & SEAL	-	X	1B
2	BLACK	BATTERY (-)	PACKCARD PIN B	0.38	RING TERMINAL (WAYTEK # 32205)	-	X	-	PACKCARD 12129493 & SEAL	-	X	2



07-7737

WIRE NO.	IDENTIFICATION	APPLICATION		□ END (LEFT) (BEYOND HARNESS)				△ END (RIGHT) (BEYOND HARNESS)				
		FROM	TO	SIZE	TYPE	EXTRA WIDE PROTECTION	TERMINAL	SIZE	TYPE	EXTRA WIDE PROTECTION	TERMINAL	
						YES	NO			YES	NO	
1A	BLACK	PACKCARD PIN F	ULTRA SONIC SPLICE	-	PACKCARD 12045773 & SEAL	-	X	-	ULTRA SONIC SPLICE	-	X	1A
1B	BLACK	ULTRA SONIC SPLICE	DEUTSCH 1 PIN B	-	ULTRA SONIC SPLICE	-	X	-	DEUTSCH 0462-201-16141 & SEAL	-	X	1B
1C	BLACK	ULTRA SONIC SPLICE	DEUTSCH 2 PIN B	-	ULTRA SONIC SPLICE	-	X	-	DEUTSCH 0462-201-16141 & SEAL	-	X	1C
2	RED	PACKCARD PIN B	DEUTSCH 1 PIN A	-	PACKCARD 12045773 & SEAL	-	X	-	DEUTSCH 0462-201-16141 & SEAL	-	X	2
3	YELLOW	PACKCARD PIN C	DEUTSCH 2 PIN A	-	PACKCARD 12045773 & SEAL	-	X	-	DEUTSCH 0462-201-16141 & SEAL	-	X	3





ELECTRIC WIRING HARNESS

Serial Number 1119001 & Up

07-7734

WIRE NO.	GUAGE	IDENTIFICATION	WIRE APPLICATION		TERMINAL (BEYOND HARNESS)		EXTRA WIDE PROTECTION		TERMINAL (A END (RIGHT) BEYOND HARNESS)		NO. WIRE PINS	
			FROM	ATO	TYPE	SIZE	YES	NO	TYPE	SIZE		YES
1	16 BLACK	PACKKARD PIN F (8-PIN)	PACKKARD PIN A (2-PIN)	-	PACKKARD 12048159 & SEAL	-	X	-	PACKKARD 12048074 & SEAL	-	X	1
2	16 RED	PACKKARD PIN B (2-PIN)	SWITCH 1-A	-	PACKKARD 12048159 & SEAL	-	X	-	SPADE TERMINAL (FEMALE)	-	X	2
3	16 RED	PACKKARD PIN B (8-PIN)	SWITCH 1-B	-	PACKKARD 12048074 & SEAL	-	X	-	SPADE TERMINAL (FEMALE)	-	X	3
4	16 YELLOW	PACKKARD PIN C (8-PIN)	SWITCH 1-C	-	PACKKARD 12048074 & SEAL	-	X	-	SPADE TERMINAL (FEMALE)	-	X	4




Item	Part	Qty	Description
1.	N/A	1	Boot, Full
2.	50-0942	1	Decal, Swing Arrow

DIRT DEFLECTOR KITS S26 & S30


S26 & S30

- 28-10162-4 4 Ft.
- 28-10162-5 5 Ft.
- 28-10162-6 6 Ft.
- 28-10162-7 7 Ft.



Item	Part	Qty	Description
1.	07-1714	2	Screw, HHC, Gr8, 5/16-18 x 1
2.	07-3273	8	Washer, Lock, Split, Medium
3.	07-3275	16	Washer, Flat, Gr8, 5/16
4.	07-3278	8	Nut, Hex, Gr8, 5/16-18
5.	07-3436	6	Screw, HHC, Gr8, 5/16-18 x 3/4
6.	13-13634	1	Plate, Mounting, Left
7.	13-13635	1	Plate Mounting, Right
8.	13-16201-4	1	Sheet, Dirt Deflector (4 Ft.)
	13-16201-5	1	Sheet, Dirt Deflector (5 Ft.)
	13-13633	1	Sheet, Dirt Deflector (6 Ft.)
	13-16201-7	1	Sheet, Dirt Deflector (7 Ft.)

HYDRAULIC ANGLE / NO VALVE 11-4191




Item	Part	Qty	Description
1.	03-2092	2	Fitting, Elbow, HP, 90°, 9/16MOR, 3/8MFS
2.	03-2159	2	Fitting, Adapter, HP, 3/8MFS, 1/4MP
3.	03-2270	2	Hose, 3/8 x 72, 3/8FFS, 3/8FFS
4.	03-3573	1	O-Ring, Face Seal, 3/8, SAE #6
5.	03-4668	1	Plate, Hydraulic, Orifice, .028, #6 O-Ring Face Seal
6.	03-5719	1	Cylinder, 1.75 x .75 x 4, 3.5K (09/24/09 & After)
	03-3381	1	Cylinder, 1.75 x .75 x 4 (09/23/09 & Before)
7.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
8.	07-1782	2	Washer, Flat, Gr2, 3/4SAE, 1 1/2

Service Part for 03-3381 Cylinder
03-3382 Seal Kit

Service Part for 03-5719 Cylinder
46072 Seal Kit
114406 Cylinder Rod

HYDRAULIC ANGLE WITH ELECTRIC VALVE MRHL 11-5310

Serial Number 1014199 & Down




Item	Part	Qty	Description
1.	03-1920	1	Fitting, 12MF-12MF
2.	03-1945	2	Fitting, Adapter, HP, 1 1/16MOR, 3/4MFS
3.	03-2092	2	Fitting, Elbow, HP, 90°, 3/16MOR, 3/8MFS
4.	03-2291	2	Fitting, Adapter, HP, 3/8MFS, 9/16MOR
5.	03-2352	2	Hose, 3/8 x 32, 2W, 3/8FFS90, 3/8FFS
6.	03-3968	1	Hose, .75 x 60, 12FF-12FF90, 3.125K
7.	03-4506	1	Hose, .75 x 60, 12FF-12FF, 3.125K
8.	03-5215	1	Manifold, 12 Volt
9.	03-3381	1	Cylinder, 1.75 x .75 x 4 (09/23/09 & Before)
	03-5719	1	Cylinder, 1.75 x .75 x 4, 3.5K (09/24/09 & After)
10.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
11.	07-3745	4	Washer, Flat, CL8.8, M10
12.	07-3749	2	Screw, HHC, CL10.9, M10-1.5 x 30mm
13.	07-4622	4	Nut, Hex, Lock, M10-1.5, CL10.9
14.	07-7028	2	Screw, HHC, CL10.9, M10-1.5 x 130mm
15.	13-16972	1	Bracket, Mounting
16.	LAF9441	1	Wire Harness
17.	LAF9444	1	Wire Harness, with Box

HYDRAULIC ANGLE WITH ELECTRIC VALVE

MRHL 11-5433

Serial Number 1015001 & Up



Item Part Qty Description

Item	Part	Qty	Description
1.	03-1920	1	Fitting, 12MF-12MF
2.	03-1945	2	Fitting, Adapter, HP, 1 1/16MOR, 3/4MFS
3.	03-2092	2	Fitting, Elbow, HP, 90°, 3/16MOR, 3/8MFS
4.	03-2291	2	Fitting, Adapter, HP, 3/8MFS, 9/16MOR
5.	03-2352	2	Hose, 3/8 x 32, 2W, 3/8FFS90, 3/8FFS
6.	03-3968	1	Hose, .75 x 60, 12FF-12FF90, 3.125K
7.	03-4506	1	Hose, .75 x 60, 12FF-12FF, 3.125K
8.	03-3381	1	Cylinder, 1.75 x .75 x 4 (09/23/09 & Before)
	03-5719	1	Cylinder, 1.75 x .75 x 4, 3.5K (09/24/09 & After)
9.	03-5835	1	Manifold, 12 Volt, with Deutsch Coil
10.	07-0206	2	Pin, Cotter, Gr2, 3/16 x 2
11.	07-3745	4	Washer, Flat, CL8.8, M10
12.	07-3749	2	Screw, HHC, CL10.9, M10-1.5 x 30mm
13.	07-4622	4	Nut, Hex, Lock, M10-1.5, CL10.9
14.	07-7028	2	Screw, HHC, CL10.9, M10-1.5 x 130mm
15.	07-7733	1	Wire Harness, Power Lead, 126 Inches
16.	07-7734	1	Wire Harness, with Box
17.	07-7737	1	Wire Harness, 108 Inches, for Solenoid
18.	13-16972	1	Bracket, Hydraulic

Service Part for 03-3381 Cylinder
03-3382 Seal Kit

Service Part for 03-5719 Cylinder
46072 Seal Kit
114406 Cylinder Rod

NOTES