



Click Here To View
Item at

www.GapPower.com

Sales • Rentals
Parts & Service



A TEREX BRAND

Service Manual

Serial Number Range

GS-2669DC

from GS6912-1300

GS-3369DC

GS-4069DC

Part No. 214415

Rev D

December 2013

Introduction

Important

Read, understand and obey the safety rules and operating instructions in the appropriate Operator's Manual on your machine before attempting any maintenance or repair procedure.

This manual provides detailed scheduled maintenance information for the machine owner and user. It also provides troubleshooting fault codes and repair procedures for qualified service professionals.

Basic mechanical, hydraulic and electrical skills are required to perform most procedures. However, several procedures require specialized skills, tools, lifting equipment and a suitable workshop. In these instances, we strongly recommend that maintenance and repair be performed at an authorized Genie dealer service center.

Compliance

Machine Classification

Group B/Type 3 as defined by ISO 16368

Machine Design Life

Unrestricted with proper operation, inspection and scheduled maintenance.

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:

www.genielift.com
e-mail: awp.techpub@terex.com

Copyright © 2011 Terex Corporation

214415 Rev D December 2013
First Edition, Fourth Printing

Genie and "GS" are registered trademarks of Terex South Dakota, Inc. in the USA and many other countries.

 Printed on recycled paper

Printed in U.S.A.



Revision History

Revision	Date	Section	Procedure / Schematic Page / Description
A	7/2012		New release
B	8/2012	2 - Spec.	Hyd. Comp. Spec.
		4 - Repair	5-1, 6-1
		6 - Schem.	6-22, 6-23
C	N/A	N/A	Not Released
D	12/2013	3 - Maint.	Section 3
		4 - Repair	Section 4
		5 - Diag.	Section 5
		6 - Schem.	Section 6
REFERENCE EXAMPLES:			
Kubota Engine_Section 2_Specifications. A-6,B-3,C-7_Section 3_Maintenance Procedure. 3-2, 6-4, 9-1_Section 4_Repair Procedure. Fault Codes_Section 5. 6-35, 6-56, 6-104_Section 6_Schematic Page #.			<p style="text-align: center;">Electronic Version</p> <p>Click on any procedure or page number highlighted in blue to view the update.</p>

REVISION HISTORY, CONTINUED

Revision	Date	Section	Procedure / Schematic Page / Description
REFERENCE EXAMPLES:			
<p>Kubota Engine_Section 2_Specifications. A-6,B-3,C-7_Section 3_Maintenance Procedure. 3-2, 6-4, 9-1_Section 4_Repair Procedure. Fault Codes_Section 5. 6-35, 6-56, 6-104_Section 6_Schematic Page #.</p>			<p style="text-align: center;"><u>Electronic Version</u></p> <p>Click on any procedure or page number highlighted in blue to view the update.</p>





Model: GS-3369
Serial number: GS6912A-12345
Model year: 2012 **Manufacture date:** 02/19/12
Electrical schematic number: ES0XXX
Machine unladen weight: 2,714 lb / 1,231 kg

Rated work load (including occupants): 500 lb / 227 kg

Maximum allowable inclination of the chassis:

N/A

Gradeability: N/A

Maximum allowable side force : 100 lb / 445 N

Maximum number of platform occupants: 2

Country of manufacture: USA
This machine complies with:



ANSI A92.6
CAN B354.2

Terex South Dakota, Inc.
18340 NE 76th Street
PO Box 97030
Redmond, WA 98052
USA



PN - 96472

Serial Number Legend



Serial number (stamped on chassis)

Serial label (inside compartment)



Safety Rules



Danger

Failure to obey the instructions and safety rules in this manual and the appropriate Operator's Manual on your machine will result in death or serious injury.

Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:

- You are trained and qualified to perform maintenance on this machine.
- You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- You have the appropriate tools, lifting equipment and a suitable workshop.

SAFETY RULES

Personal Safety

Any person working on or around a machine must be aware of all known safety hazards. Personal safety and the continued safe operation of the machine should be your top priority.



Read each procedure thoroughly. This manual and the decals on the machine, use signal words to identify the following:



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.



Indicates a potentially hazardous situation which, if not avoided, may result in property damage.



Be sure to wear protective eye wear and other protective clothing if the situation warrants it.



Be aware of potential crushing hazards such as moving parts, free swinging or unsecured components when lifting or placing loads. Always wear approved steel-toed shoes.

Workplace Safety



Be sure to keep sparks, flames and lighted tobacco away from flammable and combustible materials like battery gases and engine fuels. Always have an approved fire extinguisher within easy reach.



Be sure that all tools and working areas are properly maintained and ready for use. Keep work surfaces clean and free of debris that could get into machine components and cause damage.



Be sure any forklift, overhead crane or other lifting or supporting device is fully capable of supporting and stabilizing the weight to be lifted. Use only chains or straps that are in good condition and of ample capacity.



Be sure that fasteners intended for one time use (i.e., cotter pins and self-locking nuts) are not reused. These components may fail if they are used a second time.



Be sure to properly dispose of old oil or other fluids. Use an approved container. Please be environmentally safe.



Be sure that your workshop or work area is properly ventilated and well lit.

Table of Contents

Introduction

Important Information	<i>ii</i>
Revision History	<i>iii</i>
Serial Number Legend	<i>v</i>

Section 1

Safety Rules

General Safety Rules	<i>vi</i>
----------------------------	-----------

Section 2

Specifications

Machine Specifications	2 - 1
Performance Specifications	2 - 2
Hydraulic Specifications	2 - 3
Hydraulic Components Specifications	2 - 4
Manifold Component Specifications	2 - 4
Battery Specifications	2 - 5
Hydraulic Hose and Fitting Torque Specifications	2 - 6
SAE and Metric Fasteners Torque Charts	2 - 8

Section 3

Scheduled Maintenance Procedures

Introduction	3 - 1
Pre-delivery Preparation Report	3 - 3
Maintenance Inspection Report	3 - 5

Section 3	Scheduled Maintenance Procedures, continued
	Checklist A Procedures
A-1	Inspect the Manuals and Decals 3 - 7
A-2	Perform Pre-operation Inspection 3 - 8
A-3	Perform Function Tests 3 - 8
A-4	Test the Oscillate Axle 3 - 9
A-5	Perform 30 Day Service 3 - 10
A-6	Replace the Drive Hub Oil 3 - 10
	Checklist B Procedures
B-1	Inspect the Battery 3 - 11
B-2	Inspect the Battery Balancer 3 - 13
B-3	Inspect the Electrical Wiring 3 - 14
B-4	Inspect the Tires, Wheels and Castle Nut Torque 3 - 15
B-5	Test the Emergency Stop 3 - 15
B-6	Test the Key Switch 3 - 16
B-7	Test the Automotive-style Horn (if equipped) 3 - 16
B-8	Test the Drive Brakes 3 - 17
B-9	Test the Drive Speed - Stowed Position 3 - 18
B-10	Test the Drive Speed - Raised Position 3 - 18
B-11	Check the Module Tray Latch Components 3 - 19
B-12	Check the Electrical Contactor 3 - 19
B-13	Perform Hydraulic Oil Analysis 3 - 20
B-14	Check the Oil Level in the Drive Hubs 3 - 20

 TABLE OF CONTENTS

Section 3	Scheduled Maintenance Procedures, continued	
	Checklist C Procedures	
	C-1 Test the Platform Overload System (if equipped)	3 - 21
	C-2 Down Limit Switch Descent Delay (if equipped)	3 - 22
	C-3 Replace the Hydraulic Tank Breather Cap - Models with Optional Hydraulic Oil	3 - 23
	Checklist D Procedures	
	D-1 Check the Scissor Arm Wear Pads and Slider Blocks	3 - 24
	D-2 Replace the Hydraulic Filter	3 - 24
	D-3 Replace the Drive Hub Oil	3 - 25
	D-4 Test the Function Pump	3 - 26
	Checklist E Procedures	
	E-1 Test or Replace the Hydraulic Oil	3 - 27
	E-2 Grease the Steer Axle Wheel Bearings	3 - 28
Section 4	Repair Procedures	
	Introduction	4 - 1
	Platform Controls	
	1-1 Circuit Boards	4 - 3
	1-2 Joystick	4 - 4
	1-3 Platform Controls Alarm	4 - 4
	1-4 Platform Emergency Stop Button	4 - 5


Section 4	Repair Procedures, continued	
	Platform Components	
	2-1 Platform	4 - 6
	2-2 Platform Extension Deck	4 - 7
	Scissor Components	
	3-1 Scissor Assembly, GS-2669 DC	4 - 10
	3-2 Scissor Assembly, GS-3369 DC	4 - 14
	3-3 Scissor Assembly, GS-4069 DC	4 - 18
	3-4 Wear Pads	4 - 22
	3-5 Lift Cylinder(s)	4 - 24
	Ground Controls	
	4-1 Software Revision Level	4 - 27
	4-2 Machine Setup	4 - 28
	4-3 Auxiliary Platform Lowering	4 - 29
	4-4 Level Sensor - Models without Outriggers	4 - 29
	4-5 Level Sensor - Models with Outriggers	4 - 32
	4-6 Service Override Mode	4 - 34
	Hydraulic Pump	
	5-1 Hydraulic Pump	4 - 36
	Manifolds	
	6-1 Function Manifold Components	4 - 40
	6-2 Valve Adjustments - Function Manifold	4 - 42
	6-3 Outrigger Manifold Components	4 - 51
	6-4 Valve Coils	4 - 52

 TABLE OF CONTENTS

Section 4	Repair Procedures, continued	
	Fuel and Hydraulic Tanks	
	7-1 Hydraulic Tank	4 - 54
	Steer Axle Components	
	8-1 Yoke Assembly	4 - 55
	8-2 Steer Cylinder	4 - 57
	8-3 Tie Rod	4 - 57
	8-4 Oscillate Cylinder	4 - 58
	8-5 Oscillate Hoses	4 - 58
	8-6 Steer Angle Sensor	4 - 60
	Non-steer Axle Components	
	9-1 Drive Motors	4 - 64
	9-2 Drive Hub	4 - 65
	Outrigger Components	
	10-1 Outrigger Cylinder	4 - 66
	10-2 Outrigger Calibration	4 - 67
	Platform Overload Components	
	11-1 Platform Overload System	4 - 69

TABLE OF CONTENTS

Section 5	Diagnostics	
	Introduction	5 - 1
	GCON I/O Map	5 - 4
	Operation Indicator Codes (OIC)	5 - 5
	Diagnostic trouble codes (DTC)	5 - 5
	Troubleshooting "HXXX" and "PXXX" Faults	5 - 6
	Fault Inspection Procedure	5 - 7
	Type "HXXX" Faults	5 - 9
	Type "PXXX" Faults	5 - 13
	Type "UXXX" Faults	5 - 15
	Type "FXXX" Faults	5 - 17
	Type "CXXX" Faults	5 - 22
Section 6	Schematics	
	Introduction	6 - 1
	Electrical Schematics Abbreviation, Wire Color and Hydraulic Component Legends	6 - 2
	Electrical Symbols Legend	6 - 4
	Hydraulic Symbols Legend	6 - 5
	Limit Switch Legend	6 - 6
	Fuse Box Layout, All Models	6 - 7
	Ground Control Box Layout, All Models	6 - 10
	Platform Control Box Layout, All Models	6 - 11
	Electrical Schematic - GS-2669 DC and GS-3369 DC, (ANSI / CSA)	6 - 14
	Electrical Schematic - GS-4069 DC, (ANSI / CSA)	6 - 15
	Electrical Schematic - GS-2669 DC and GS-3369 DC, (AS / CE)	6 - 18
	Electrical Schematic - GS-4069 DC, (AS / CE)	6 - 19
	Hydraulic Schematic, GS-2669 DC and GS-3369 DC	6 - 22
	Hydraulic Schematic, GS-4069 DC	6 - 23



This page intentionally left blank.

Specifications

Machine Specifications

Fluid capacities

Hydraulic tank (maximum fill capacity)	16.5 gallons 62.5 liters
Hydraulic system without outriggers (including tank), GS-2669 DC	16.5 gallons 62.5 liters
Hydraulic system with outriggers (including tank), GS-2669 DC	18 gallons 68 liters
Hydraulic system without outriggers (including tank), GS-3369 DC	16.5 gallons 62.5 liters
Hydraulic system with outriggers (including tank), GS-3369 DC	18 gallons 68 liters
Hydraulic system without outriggers (including tank), GS-4069 DC	17.5 gallons 66 liters
Hydraulic system with outriggers (including tank), GS-4069 DC	19 gallons 72 liters

Tire and wheels

Wheel lugs (steer end)	9 @ 5/8-18
Lug nut torque, dry Front	90 ft-lbs 122 Nm
Lug nut torque, lubricated Front	68 ft-lbs 92 Nm
Wheel lugs (non-steer end)	9 @ 5/8-18
Lug bolt torque, dry Rear	170 ft-lbs 230 Nm
Lug bolt torque, lubricated Rear	130 ft-lbs 176 Nm

Castle nut (steer end)

Castle nut torque	35 ft-lbs 47.5 Nm
-------------------	----------------------

Non-marking, foam filled, RT

Tire size	26 x 12D380
Tire ply rating	8
Tire diameter	26 in 66 cm
Tire width	12 in 30 cm
Weight	177.5 lbs (+/- 7.5 lbs) 80.5 kg (+/- 3.4 kg)

For operational specifications, refer to the Operator's Manual.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Performance Specifications**Drive speed, maximum**

Platform stowed	4.5 mph
Forward direction	7.2 km/h
	40 ft / 6.1 sec
	12.2 m / 6.1 sec

Platform stowed	3.0 mph
Reverse direction	4.8 km/h
	40 ft / 9.1 sec
	12.2 m / 9.1 sec

Platform raised	0.3 mph
	0.5 km/h
	40 ft / 91 sec
	12.2 m / 91 sec

Braking distance, maximum

High range on flat level	less than 3 ft
paved surface	less than 0.9 m

Gradeability	See Operator's Manual
---------------------	-----------------------

**Function speed, maximum from platform controls
(with maximum rated load in platform)****GS-2669 DC**

Platform up	29 to 39 seconds
Platform down	26 to 36 seconds

GS-3369 DC

Platform up	34 to 44 seconds
Platform down	24 to 34 seconds

GS-4069 DC

Platform up	56 to 66 seconds
Platform down	23 to 33 seconds

Outrigger leveling, maximum

Front	5.3°
Back	4.2°
Side to side	11.7°

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Hydraulic Specifications

Hydraulic Oil Specifications

Hydraulic oil type	Chevron Rando HD MV equivalent
Viscosity grade	Multi-viscosity
Viscosity index	200
Cleanliness level, minimum	15/13
Water content, maximum	200 ppm

Chevron Rando HD MV oil is fully compatible and mixable with Shell Donax TG (Dexron III) oils.

Genie specifications require hydraulic oils which are designed to give maximum protection to hydraulic systems, have the ability to perform over a wide temperature range, and the viscosity index should exceed 140. They should provide excellent antiwear, oxidation, corrosion inhibition, seal conditioning, and foam and aeration suppression properties.

Optional fluids

Biodegradable	Petro Canada Environ MV 46 Statoil Hydra Way Bio Pa 32 BP Biohyd SE-S
Fire resistant	UCON Hydrolube HP-5046 Quintolubric 822
Mineral based	Shell Tellus S2 V 32 Shell Tellus S2 V 46 Chevron Aviation A Arnica 32

NOTICE

Continued use of Chevron Aviation A hydraulic fluid when ambient temperatures are consistently above 32°F / 0°C may result in component damage.

Note: Use of Chevron Aviation A hydraulic fluid is required when ambient temperatures are consistently below 0°F / -17°C unless an oil heating system is used.

Note: Use Shell Tellus S2 V 46 hydraulic oil when oil temperatures consistently exceed 205°F / 96°C.

Note: Genie specifications require additional equipment and special installation instructions for the approved optional fluids. Consult the Genie Service Department before use.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Hydraulic Components Specifications

Function pump

Type:	gear pump
Displacement per revolution	0.4 cu in 6 cc
Flow rate @ 3100 rpm	6 gpm 22.7 L/min

Function manifold

System relief valve pressure	3500 psi 241 bar
Lift relief valve pressure GS-2669 DC	3100 psi 214 bar
Lift relief valve pressure GS-3369 DC	2900 psi 200 bar
Lift relief valve pressure GS-4069 DC	2850 psi 197 bar
Steer relief valve pressure	1500 psi 103 bar
Oscillate relief valve pressure	3300 psi 228 bar
Steer flow regulator	2 gpm 7.6 L/min
Oscillate flow regulator	1 gpm 4 L/min

Manifold Component Specifications

Plug torque

SAE No. 4	13 ft-lbs / 18 Nm
SAE No. 6	18 ft-lbs / 24 Nm
SAE No. 8	50 ft-lbs / 68 Nm
SAE No. 10	55 ft-lbs / 75 Nm

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Battery Specifications**J305GH**

Type	6V DC
Quantity	8
Capacity	315 AH
Reserve capacity @ 25A rate	678 minutes
Reserve capacity @ 75A rate	175 minutes
Weight (single)	88 lbs / 40 kg
Weight (tray with batteries)	779 lbs / 353.5 kg

T105

Type	6V DC
Quantity	8
Capacity	225 AH
Reserve capacity @ 25A rate	447 minutes
Reserve capacity @ 75A rate	115 minutes
Weight	62 lbs / 28 kg
Weight (tray with batteries)	554 lbs / 251 kg

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Hydraulic Hose and Fitting Torque Specifications

Your machine is equipped with Parker Seal-Lok™ ORFS or 37° JIC fittings and hose ends. Genie specifications require that fittings and hose ends be torqued to specification when they are removed and installed or when new hoses or fittings are installed.

Seal-Lok™ Fittings (hose end - ORFS)


SAE Dash size	Torque
-4	10 ft-lbs / 13.6 Nm
-6	30 ft-lbs / 40.7 Nm
-8	40 ft-lbs / 54.2 Nm
-10	60 ft-lbs / 81.3 Nm
-12	85 ft-lbs / 115 Nm
-16	110 ft-lbs / 150 Nm
-20	140 ft-lbs / 190 Nm
-24	180 ft-lbs / 245 Nm

JIC 37° Fittings (swivel nut or hose connection)

SAE Dash size	Thread Size	Flats
-4	7/16-20	2
-6	9/16-18	1 1/4
-8	3/4-16	1
-10	7/8-14	1
-12	1 1/16-12	1
-16	1 5/16-12	1
-20	1 5/8-12	1
-24	1 7/8-12	1

SAE O-ring Boss Port (tube fitting - installed into Aluminum) (all types)

SAE Dash size	Torque
-4	14 ft-lbs / 19 Nm
-6	23 ft-lbs / 31.2 Nm
-8	36 ft-lbs / 54.2 Nm
-10	62 ft-lbs / 84 Nm
-12	84 ft-lbs / 114 Nm
-16	125 ft-lbs / 169.5 Nm
-20	151 ft-lbs / 204.7 Nm
-24	184 ft-lbs / 249.5 Nm



SAE O-ring Boss Port (tube fitting - installed into Steel)

SAE Dash size	Torque
-4 ORFS / 37° (Adj) ORFS (Non-adj) 37° (Non-adj)	15 ft-lbs / 20.3 Nm 26 ft-lbs / 35.3 Nm 22 ft-lbs / 30 Nm
-6 ORFS (Adj / Non-adj) 37° (Adj / Non-adj)	35 ft-lbs / 47.5 Nm 29 ft-lbs / 39.3 Nm
-8 ORFS (Adj / Non-adj) 37° (Adj / Non-adj)	60 ft-lbs / 81.3 Nm 52 ft-lbs / 70.5 Nm
-10 ORFS (Adj / Non-adj) 37° (Adj / Non-adj)	100 ft-lbs / 135.6 Nm 85 ft-lbs / 115.3 Nm
-12 (All types)	135 ft-lbs / 183 Nm
-16 (All types)	200 ft-lbs / 271.2 Nm
-20 (All types)	250 ft-lbs / 339 Nm
-24 (All types)	305 ft-lbs / 413.5 Nm

SPECIFICATIONS

Torque Procedure

Seal-Lok™ fittings

- 1 Replace the O-ring. The O-ring must be replaced anytime the seal has been broken. The O-ring cannot be re-used if the fitting or hose end has been tightened beyond finger tight.

Note: The O-rings used in the Parker Seal Lok™ fittings and hose ends are custom-size O-rings. They are not standard SAE size O-rings. They are available in the O-ring field service kit (Genie part number 49612).

- 2 Lubricate the O-ring before installation.
- 3 Be sure that the face seal O-ring is seated and retained properly.
- 4 Position the tube and nut squarely on the face seal end of the fitting and tighten the nut finger tight.
- 5 Tighten the nut or fitting to the appropriate torque per given size as shown in the table.
- 6 Operate all machine functions and inspect the hoses and fittings and related components to confirm that there are no leaks.

JIC 37° fittings

- 1 Align the tube flare (hex nut) against the nose of the fitting body (body hex fitting) and tighten the hex nut to the body hex fitting to hand-tight, approximately 30 in-lbs / 3.4 Nm.
- 2 Make a reference mark on one of the flats of the hex nut, and continue it on to the body hex fitting with a permanent ink marker. Refer to Figure 1.




Figure 1

- a hex nut
- b reference mark
- c body hex fitting

- 3 Working clockwise on the body hex fitting, make a second mark with a permanent ink marker to indicate the proper tightening position. Refer to Figure 2.

Note: Use the *JIC 37° Fittings* table on the previous page to determine the correct number of flats for the proper tightening position.

Note: The marks indicate that the correct tightening positions have been determined. Use the second mark on the body hex fitting to properly tighten the joint after it has been loosened.




Figure 2

- a body hex fitting
- b reference mark
- c second mark

- 4 Tighten the hex nut until the mark on the hex nut is aligned with the second mark on the body hex fitting.
- 5 Operate all machine functions and inspect the hoses and fittings and related components to confirm that there are no leaks.

SPECIFICATIONS

SAE FASTENER TORQUE CHART											
• This chart is to be used as a guide only unless noted elsewhere in this manual •											
SIZE	THREAD	Grade 5 				Grade 8 				A574 High Strength Black Oxide Bolts	
		LUBED		DRY		LUBED		DRY		LUBED	
		in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
1/4	20	80	9	100	11.3	110	12.4	140	15.8	130	14.7
	28	90	10.1	120	13.5	120	13.5	160	18	140	15.8
		LUBED		DRY		LUBED		DRY		LUBED	
		ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
5/16	18	13	17.6	17	23	18	24	25	33.9	21	28.4
	24	14	19	19	25.7	20	27.1	27	36.6	24	32.5
3/8	16	23	31.2	31	42	33	44.7	44	59.6	38	51.5
	24	26	35.2	35	47.4	37	50.1	49	66.4	43	58.3
7/16	14	37	50.1	49	66.4	50	67.8	70	94.7	61	82.7
	20	41	55.5	55	74.5	60	81.3	80	108.4	68	92.1
1/2	13	57	77.3	75	101.6	80	108.4	110	149	93	126
	20	64	86.7	85	115	90	122	120	162	105	142
9/16	12	80	108.4	110	149	120	162	150	203	130	176
	18	90	122	120	162	130	176	170	230	140	189
5/8	11	110	149	150	203	160	217	210	284	180	244
	18	130	176	170	230	180	244	240	325	200	271
3/4	10	200	271	270	366	280	379	380	515	320	433
	16	220	298	300	406	310	420	420	569	350	474
7/8	9	320	433	430	583	450	610	610	827	510	691
	14	350	474	470	637	500	678	670	908	560	759
1	8	480	650	640	867	680	922	910	1233	770	1044
	12	530	718	710	962	750	1016	990	1342	840	1139
1 1/8	7	590	800	790	1071	970	1315	1290	1749	1090	1477
	12	670	908	890	1206	1080	1464	1440	1952	1220	1654
1 1/4	7	840	1138	1120	1518	1360	1844	1820	2467	1530	2074
	12	930	1260	1240	1681	1510	2047	2010	2725	1700	2304
1 1/2	6	1460	1979	1950	2643	2370	3213	3160	4284	2670	3620
	12	1640	2223	2190	2969	2670	3620	3560	4826	3000	4067

METRIC FASTENER TORQUE CHART																
• This chart is to be used as a guide only unless noted elsewhere in this manual •																
Size (mm)	Class 4.6 				Class 8.8 				Class 10.9 				Class 12.9 			
	LUBED		DRY		LUBED		DRY		LUBED		DRY		LUBED		DRY	
	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
5	16	1.8	21	2.4	41	4.63	54	6.18	58	6.63	78	8.84	68	7.75	91	10.3
6	19	3.05	36	4.07	69	7.87	93	10.5	100	11.3	132	15	116	13.2	155	17.6
7	45	5.12	60	6.83	116	13.2	155	17.6	167	18.9	223	25.2	195	22.1	260	29.4
	LUBED		DRY		LUBED		DRY		LUBED		DRY		LUBED		DRY	
	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
8	5.4	7.41	7.2	9.88	14	19.1	18.8	25.5	20.1	27.3	26.9	36.5	23.6	32	31.4	42.6
10	10.8	14.7	14.4	19.6	27.9	37.8	37.2	50.5	39.9	54.1	53.2	72.2	46.7	63.3	62.3	84.4
12	18.9	25.6	25.1	34.1	48.6	66	64.9	88	69.7	94.5	92.2	125	81	110	108	147
14	30.1	40.8	40	54.3	77.4	105	103	140	110	150	147	200	129	175	172	234
16	46.9	63.6	62.5	84.8	125	170	166	226	173	235	230	313	202	274	269	365
18	64.5	87.5	86.2	117	171	233	229	311	238	323	317	430	278	377	371	503
20	91	124	121	165	243	330	325	441	337	458	450	610	394	535	525	713
22	124	169	166	225	331	450	442	600	458	622	612	830	536	727	715	970
24	157	214	210	285	420	570	562	762	583	791	778	1055	682	925	909	1233



Scheduled Maintenance Procedures



Observe and Obey:

- ☑ Maintenance inspections shall be completed by a person trained and qualified on the maintenance of this machine.
- ☑ Scheduled maintenance inspections shall be completed daily, quarterly, semiannually, annually and every 2 years as specified on the *Maintenance Inspection Report*.

▲WARNING Failure to perform each procedure as presented and scheduled could result in death, serious injury or substantial damage.

- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.
- ☑ Use only Genie approved replacement parts.
- ☑ Machines that have been out of service for a period longer than 3 months must complete the quarterly inspection.
- ☑ Unless otherwise specified, perform each maintenance procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Platform in the stowed position
 - Key switch in the off position with the key removed
 - The red Emergency Stop button in the off position at both ground and platform controls
 - Wheels chocked
 - All external AC power supply disconnected from the machine

About This Section

This section contains detailed procedures for each scheduled maintenance inspection.

Each procedure includes a description, safety warnings and step-by-step instructions.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

▲DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

▲WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

▲CAUTION

Indicates a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.

NOTICE

Indicates a potentially hazardous situation which, if not avoided, may result in property damage.

- ⦿ Indicates that a specific result is expected after performing a series of steps.
- ⊗ Indicates that an incorrect result has occurred after performing a series of steps.

SCHEDULED MAINTENANCE PROCEDURES

Maintenance Symbols Legend

Note: The following symbols have been used in this manual to help communicate the intent of the instructions. When one or more of the symbols appear at the beginning of a maintenance procedure, it conveys the meaning below.



Indicates that tools will be required to perform this procedure.



Indicates that new parts will be required to perform this procedure.



Indicates that a cold engine will be required to perform this procedure.



Indicates that a warm engine will be required to perform this procedure.



Indicates that dealer service will be required to perform this procedure.

Pre-delivery Preparation Report

The pre-delivery preparation report contains checklists for each type of scheduled inspection.

Make copies of the *Pre-delivery Preparation* report to use for each inspection. Store completed forms as required.

Maintenance Schedule

There are five types of maintenance inspections that must be performed according to a schedule—daily, quarterly, semiannually, annually, and two year. The *Scheduled Maintenance Procedures Section and the Maintenance Inspection Report* have been divided into five subsections—A, B, C, D, and E. Use the following chart to determine which group(s) of procedures are required to perform a scheduled inspection.

Inspection	Checklist
Daily or every 8 hours	A
Quarterly or every 250 hours	A + B
Semiannually or every 500 hours	A + B + C
Annually or every 1000 hours	A + B + C + D
Two year or every 2000 hours	A + B + C + D + E

Maintenance Inspection Report

The maintenance inspection report contains checklists for each type of scheduled inspection.

Make copies of the *Maintenance Inspection Report* to use for each inspection. Maintain completed forms for a minimum of 4 years or in compliance with your employer, jobsite and governmental regulations and requirements.

Pre-Delivery Preparation

Fundamentals

It is the responsibility of the dealer to perform the Pre-delivery Preparation.

The Pre-delivery Preparation is performed prior to each delivery. The inspection is designed to discover if anything is apparently wrong with a machine before it is put into service.

A damaged or modified machine must never be used. If damage or any variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

Instructions

Use the operator's manual on your machine.

The Pre-delivery Preparation consists of completing the Pre-operation Inspection, the Maintenance items and the Function Tests.

Use this form to record the results. Place a check in the appropriate box after each part is completed. Follow the instructions in the operator's manual.

If any inspection receives an N, remove the machine from service, repair and reinspect it. After repair, place a check in the R box.

Legend

Y = yes, completed

N = no, unable to complete

R = repaired

Comments

Pre-Delivery Preparation	Y	N	R
Pre-operation inspection completed			
Maintenance items completed			
Function tests completed			

Model

Serial number

Date

Machine owner

Inspected by (print)

Inspector signature


Inspector title

Inspector company



Terex South Dakota, Inc. USA
500 Oak Wood Road
PO Box 1150
Watertown, SD 57201-6150
(605) 882-4000

Genie UK
The Maltings, Wharf Road
Grantham, Lincolnshire
NG31- 6BH England
(44) 1476-584333



This page intentionally left blank.

Maintenance Inspection Report

Model
Serial number
Date
Hour meter
Machine owner
Inspected by (print)
Inspector signature
Inspector title
Inspector company

- Instructions**
- Make copies of this report to use for each inspection.
 - Select the appropriate checklist(s) for the type of inspection to be performed.

<input type="checkbox"/>	Daily or 8 hours Inspection:	A
<input type="checkbox"/>	Quarterly or 250 hours Inspection:	A+B
<input type="checkbox"/>	Semiannually or 500 hours Inspection:	A+B+C
<input type="checkbox"/>	Annually or 1000 hours Inspection:	A+B+C+D
<input type="checkbox"/>	Two year or 2000 hours Inspection:	A+B+C+D+E

- Place a check in the appropriate box after each inspection procedure is completed.
- Use the step-by-step procedures in this section to learn how to perform these inspections.
- If any inspection receives an "N", tag and remove the machine from service, repair and reinspect it. After repair, place a check in the "R" box.

Legend
 Y = yes, acceptable
 N = no, remove from service
 R = repaired

Checklist A	Y	N	R
A-1 Manuals and decals			
A-2 Pre-operation inspect			
A-3 Function tests			
A-4 Test the oscillate			

Perform after 40 hours:
 A-5 30 day service

Perform after 150 hours:	Y	N	R
A-6 Drive hub oil			


Checklist B	Y	N	R
B-1 Batteries			
B-2 Battery balancer			
B-3 Electrical wiring			
B-4 Tires and wheels			
B-5 Emergency Stop			
B-6 Key switch			
B-7 Horn (if equipped)			
B-8 Drive brakes			
B-9 Drive speed - stowed			
B-10 Drive speed - raised			
B-11 Module tray latch			
B-12 Electrical contactor			
B-13 Hydraulic oil analysis			
B-14 Drive hub oil			

Checklist C	Y	N	R
C-1 Platform overload (if equipped)			
C-2 Down limit switch delay (if equipped)			
C-3 Breather cap - models with optional oil			

Checklist D	Y	N	R
D-1 Scissor arm wear pads			
D-2 Hydraulic filter			
D-3 Drive hub oil			
D-4 Function pump			

Checklist E	Y	N	R
E-1 Hydraulic oil			
E-2 Wheel bearings			





This page intentionally left blank.

Checklist A Procedures

A-1 Inspect the Manuals and Decals

Genie specifications require that this procedure be performed every 8 hours or daily, whichever comes first.

Maintaining the operator's and safety manuals in good condition is essential to safe machine operation. Manuals are included with each machine and should be stored in the container provided in the platform. An illegible or missing manual will not provide safety and operational information necessary for a safe operating condition.

In addition, maintaining all of the safety and instructional decals in good condition is mandatory for safe machine operation. Decals alert operators and personnel to the many possible hazards associated with using this machine. They also provide users with operation and maintenance information. An illegible decal will fail to alert personnel of a procedure or hazard and could result in unsafe operating conditions.

- 1 Check to make sure that the operator's and safety manuals are present and complete in the storage container on the platform.
- 2 Examine the pages of each manual to be sure that they are legible and in good condition.
 - ⊙ Result: The operator's manual is appropriate for the machine and all manuals are legible and in good condition.
 - ⊗ Result: The operator's manual is not appropriate for the machine or all manuals are not in good condition or is illegible. Remove the machine from service until the manual is replaced.
- 3 Open the operator's manual to the decals inspection section. Carefully and thoroughly inspect all decals on the machine for legibility and damage.
 - ⊙ Result: The machine is equipped with all required decals, and all decals are legible and in good condition.
 - ⊗ Result: The machine is not equipped with all required decals, or one or more decals are illegible or in poor condition. Remove the machine from service until the decals are replaced.
- 4 Always return the manuals to the storage container after use.

Note: Contact your authorized Genie distributor or Genie if replacement manuals or decals are needed.

CHECKLIST A PROCEDURES

**A-2
Perform Pre-operation
Inspection**

Genie specifications require that this procedure be performed every 8 hours or daily, whichever comes first.

Completing a Pre-operation Inspection is essential to safe machine operation. The Pre-operation Inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests. The Pre-operation Inspection also serves to determine if routine maintenance procedures are required.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

**A-3
Perform Function Tests**

Genie specifications require that this procedure be performed every 8 hours or daily, whichever comes first.

Completing the function tests is essential to safe machine operation. Function tests are designed to discover any malfunctions before the machine is put into service. A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

CHECKLIST A PROCEDURES

A-4**Test the Oscillate Axle**

Note: Genie specifications require that this procedure be performed daily or every 8 hours, whichever comes first.

The oscillate system is designed so that all four tires maintain firm contact to the ground on unlevel terrain improving traction and machine stability.

Proper axle oscillation is essential to safe machine operation. If the axle oscillation system is not operating correctly, the stability of the machine is compromised and it may tip over.

Test the Oscillate System (stowed position):

- 1 Drive the left steer tire up onto a 4 in / 10 cm high ramp.
 - ⦿ Result: All four tires should maintain firm contact with the ground.
- 2 Drive the right steer tire up onto a 4 in / 10 cm high ramp.
 - ⦿ Result: All four tires should maintain firm contact with the ground.

Test the Oscillate System (elevated position):

- 4 Push and hold the lift function enable button and raise the platform between 7 ft / 213 cm to 9 ft / 274 cm.
- 5 Drive the left steer tire into a 4 in / 10 cm deep hole.
 - ⦿ Result: All four tires should maintain firm contact with the ground.
- 6 Drive the right steer tire into a 4 in / 10 cm deep hole.
 - ⦿ Result: All four tires should maintain firm contact with the ground.

Note: Verify there are no fault codes shown on the ground control display.

CHECKLIST A PROCEDURES

A-5 Perform 30 Day Service

The 30 day maintenance procedure is a one-time sequence of procedures to be performed after the first 30 days or 40 hours of use. After the interval, refer to the maintenance checklists for continued scheduled maintenance.

- 1 Perform the following maintenance procedures:
 - B-3 Inspect the Tires, Wheels and Castle Nut Torque
 - B-13 Check the Oil Level in the Drive Hubs
 - D-2 Replace the Hydraulic Filter


A-6 Replace the Drive Hub Oil



Note: Manufacturer drive hub specifications require that this one-time procedure be performed after the first 150 hours.

Replacing the drive hub oil is essential for good machine performance and service life. Failure to replace the drive hub oil after the first 150 hours of use may cause the machine to perform poorly and continued use may cause component damage.

- 1 Select the drive hub to be serviced. Drive the machine until one of the two plugs is at the lowest point.
- 2 Remove both plugs and drain the oil into a suitable container.
- 3 Drive the machine until one of the two plugs is at the highest point.



a drive hub plugs

- 4 Fill the hub until the oil level is even with the bottom of the lowest plug hole. Refer to Section 2, *Specifications*.
- 5 Install the plugs into the drive hub.
- 6 Repeat this procedure for the other drive hub.

Checklist B Procedures

B-1 Inspect the Batteries



Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper battery condition is essential to good machine performance and operational safety. Improper fluid levels or damaged cables and connections can result in component damage and hazardous conditions.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ WARNING Bodily injury hazard. Batteries contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

- 1 Put on protective clothing and eye wear.
- 2 Be sure that the battery cable connections are free of corrosion.

Note: Adding terminal protectors and a corrosion preventative sealant will help eliminate corrosion on the battery terminals and cables.

- 3 **Models without maintenance-free or sealed batteries:** Be sure that the battery hold downs and cable connections are tight. Proceed to step 4.
Models with maintenance-free or sealed batteries: Be sure that the battery hold downs and cable connections are tight. Proceed to step 12.
- 4 Fully charge the batteries and allow the batteries to rest at least 6 hours.
- 5 Remove the battery vent caps and check the specific gravity of each battery cell with a hydrometer. Note the results.
- 6 Check the ambient air temperature and adjust the specific gravity reading for each cell as follows:
 - Add 0.004 to the reading of each cell for every 10° / 5.5° C above 80° F / 26.7° C.
 - Subtract 0.004 from the reading of each cell for every 10° / 5.5° C below 80° F / 26.7° C.
- Ⓞ Result: All battery cells display an adjusted specific gravity of 1.277 or higher. The battery is fully charged. Proceed to step 11.
- ✗ Result: One or more battery cells display a specific gravity of 1.217 or below. Proceed to step 8.
- 7 Perform an equalizing charge OR fully charge the batteries and allow the batteries to rest at least 6 hours.

CHECKLIST B PROCEDURES

- 8 Remove the battery vent caps and check the specific gravity of each battery cell with a hydrometer. Note the results.
- 9 Check the ambient air temperature and adjust the specific gravity reading for each cell as follows:
- Add 0.004 to the reading of each cell for every 10° / 5.5° C above 80° F / 26.7° C.
 - Subtract 0.004 from the reading of each cell for every 10° / 5.5° C below 80° F / 26.7° C.
- ⊙ Result: All battery cells display a specific gravity of 1.277 or greater. The battery is fully charged. Proceed to step 13.
- ⊗ Result: The difference in specific gravity readings between cells is greater than 0.1 OR the specific gravity of one or more cells is less than 1.177. Replace the battery.
- 10 Check the battery acid level. If needed, replenish with distilled water to 1/8 inch / 3 mm below the bottom of the battery fill tube. Do not overfill.
- 11 Install the vent caps and neutralize any electrolyte that may have spilled.
- 13 Inspect the battery charger plug and pigtail for damage or excessive insulation wear. Replace as required.
- 14 Thoroughly clean the exterior of the battery charger. Inspect and tighten, if necessary, all wire connections at the charger.
- 15 Connect the battery charger to a properly grounded 115V or 230V single phase AC power supply.
- ⊙ Result: The charger, after a short delay, should start as indicated by the transformer hum, and begin charging the batteries.

Note: For best results, always use a three-conductor, number 14 AWG / 1.5 mm heavy duty with ground extension cord, in as short a length as possible. Refer to the operating instructions for the battery charger.

Note: If you have any further questions regarding the battery charger operation, please contact the Genie Service Department.

All models:


- 12 Check each battery pack and confirm that the batteries are wired correctly. Refer to the *Battery Connection Diagram* decal on the machine.

CHECKLIST B PROCEDURES

B-2 Inspect the Battery Balancer

Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

- 1 Open the battery compartment and locate the fuse box.



- 2 Locate the LED indicator under the fuse box and watch the LED for 5 seconds to verify the battery balancer condition.

MODE	LED INDICATOR	CONDITION
Balanced	Green - Steady	Voltage differential (< 0.3V)
Equalizing	Green - Blinking (1 per sec)	Voltage differential (> 0.3V)
Low or Over voltage Auto shutdown	Green w/ Orange blinking (1 every 4 seconds)	B- to 24V battery pack beyond normal range (< 18V or > 33V)
Low or Over voltage Auto shutdown	Green w/ Orange blinking (2 every 4 seconds)	24V to 48V battery pack beyond normal range (< 18V or > 33V)
24V circuit Disconnected	No LED	24V lead not connected
Auto shutdown	Red - Steady	1) Voltage differential, > 8V between battery packs. -OR- 2) 48V disconnected.

CHECKLIST B PROCEDURES

B-3 Inspect the Electrical Wiring



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining electrical wiring in good condition is essential to safe operation and good machine performance. Failure to find and replace burnt, chafed, corroded or pinched wires could result in unsafe operating conditions and may cause component damage.

WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Inspect the underside of the chassis for damaged or missing ground strap(s).
- 2 Inspect the following areas for burnt, chafed, corroded and loose wires:
 - In the rear axle:
 - drive motors
 - limit switches
 - Hydraulic box:
 - inside ground controls
 - harness connections
 - motor controllers
 - battery charger
 - Battery box:
 - batteries
 - fuse box
 - Machine:
 - center of drive chassis
 - linkage assembly
 - platform
 - platform controls
 - harness connections
- 3 Inspect for a liberal coating of dielectric grease in all wire harness connectors:
 - Ground controls
 - Platform controls
 - Function manifold
 - Motor controllers
 - Limit switches
 - Level sensor
 - Steer sensor

CHECKLIST B PROCEDURES

B-4 Inspect the Tires, Wheels and Castle Nut Torque



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the tires and wheels in good condition, including proper wheel fastener torque, is essential to safe operation and good performance. Tire and/or wheel failure could result in a machine tip-over. Component damage may also result if problems are not discovered and repaired in a timely fashion.

- 1 Check the tire surface and sidewalls for cuts, cracks, punctures and unusual wear.
- 2 Check each wheel for damage, bends and cracks.
- 3 Remove the castle nut cotter pin and check each castle nut for proper torque. Refer to Maintenance Procedure E-2, *Grease the Steer Axle and Wheel Bearings*.

Note: Always replace the cotter pin with a new one when removing the castle nut or when checking the torque of the castle nut.

- 4 Check each lug bolt for proper torque. Refer to Section 2, *Specifications*.
- 5 Install a new cotter pin and secure.

B-5 Test the Emergency Stop

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

A properly functioning Emergency Stop is essential for safe machine operation. An improperly operating red Emergency Stop button will fail to shut off power and stop all machine functions, resulting in a hazardous situation.

Note: As a safety feature, selecting and operating the ground controls will override the platform controls, except the platform red Emergency Stop button.

- 1 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 2 Push in the red Emergency Stop button at the ground controls to the off position.
- ⊙ Result: No machine functions should operate.
- 3 Turn the key switch to platform control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 4 Push down the red Emergency Stop button at the platform controls to the off position.
- ⊙ Result: No machine functions should operate.

Note: The red Emergency Stop button at the ground controls will stop all machine operation, even if the key switch is turned to platform control.

CHECKLIST B PROCEDURES

B-6 Test the Key Switch

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper key switch action and response is essential to safe machine operation. The machine can be operated from the ground or platform controls and the activation of one or the other is accomplished with the key switch. Failure of the key switch to activate the appropriate control panel could cause a hazardous operating situation.

Note: Perform this procedure from the ground using the platform controls. Do not stand in the platform.

- 1 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 2 Turn the key switch to **platform control**.
- 3 Check the platform up/down function from the **ground controls**.
- ⊙ Result: The machine functions should **not** operate.
- 4 Turn the key switch to **ground control**.
- 5 Check the machine functions from the **platform controls**.
- ⊙ Result: The machine functions should **not** operate.
- 6 Turn the key switch to the off position.
- ⊙ Result: No function should operate.

B-7 Test the Automotive-style Horn (if equipped)

Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

A functioning horn is essential to safe machine operation. The horn is activated at the platform controls and sounds at the ground as a warning to ground personnel. An improperly functioning horn will prevent the operator from alerting ground personnel of hazards or unsafe conditions.

- 1 Turn the key switch to platform control and pull out the red Emergency Stop button to the ON position at both the ground and platform controls.
- 2 Push down the horn button at the platform controls.
- ⊙ Result: The horn should sound.

Note: If necessary, the horn can be adjusted to obtain the loudest volume by turning the adjustment screw near the wire terminals on the horn.

CHECKLIST B PROCEDURES

B-8 Test the Drive Brakes



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper brake action is essential to safe machine operation. The drive brake function should operate smoothly, free of hesitation and unusual noise. Electrically-released individual wheel brakes can appear to operate normally when not fully operational.

Note: Perform this procedure with the machine on incline button at the platform controls in the off position (LED light should be off) and the platform extension deck fully retracted.

- 1 Mark a test line on the ground for reference.
- 2 Turn the key switch to platform control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Press the drive function select button.
- 4 Press and hold the function enable switch on the joystick.
- 5 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the test line.
- 6 Bring the machine to top drive speed before reaching the test line. Release the function enable switch or the joystick when your reference point on the machine crosses the test line.
- 7 Measure the distance between the test line and your machine reference point. Refer to Section 2, *Specifications*.

Note: The brakes must be able to hold the machine on any slope it is able to climb.

CHECKLIST B PROCEDURES

**B-9
Test the Drive Speed -
Stowed Position**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper drive functions are essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation and unusual noise over the entire proportionally controlled speed range.

- 1 Create start and finish lines by marking two lines on the ground 40 feet / 12.2 m apart.
- 2 Turn the key switch to platform control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Press the drive function select button.
- 4 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
- 5 Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
- 6 Continue at full speed and note the time when your reference point on the machine passes over the finish line. Refer to Section 2, *Specifications*.

**B-10
Test the Drive Speed -
Raised Position**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper drive functions are essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation and unusual noise over the entire proportionally controlled speed range.

- 1 Create start and finish lines by marking two lines on the ground 40 feet / 12.2 m apart.
- 2 Turn the key switch to platform control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Press the drive function select button.
- 4 Raise the platform approximately 6 ft / 2 m.
- 5 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
- 6 Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
- 7 Continue at full speed and note the time when your reference point on the machine passes over the finish line. Refer to Section 2, *Specifications*.

CHECKLIST B PROCEDURES

B-11 Check the Module Tray Latch Components



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the module tray latch components in good condition is essential to good performance and service life. Failure to detect worn out latch components may result in module trays opening unexpectedly, creating an unsafe operating condition.

- 1 Open both module trays and lubricate each module tray latch. Using light oil, apply a few drops to the side of the latch mechanism.
- 2 Inspect for and tighten any loose fasteners.

B-12 Check the Electrical Contactor



Note: Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the electrical contactors in good condition is essential to safe machine operation. Failure to locate a worn or damaged contactor could result in an unsafe working condition and component damage.

- 1 Open the battery compartment.
- 2 Remove the contactor enclosure mounted to the top of the battery compartment.
- 3 Visually inspect the contact points of each contactor for the following items:
 - Excessive burns
 - Excessive arcs
 - Excessive pitting

⚠ WARNING Electrocutation/burn hazard. Contact with hot or live circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Note: Replace the contactors if any damage is found.

CHECKLIST B PROCEDURES

B-13 Perform Hydraulic Oil Analysis



Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and a clogged suction strainer may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often.


Note: Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary. **If the hydraulic oil is not replaced at the two year inspection, test the oil quarterly. Replace the oil when it fails the test.** Refer to E-1, *Test or Replace the Hydraulic Oil*.

B-14 Check the Oil Level in the Drive Hubs



Failure to maintain proper drive hub oil levels may cause the machine to perform poorly and continued use may cause component damage.

- 1 Select the drive hub to be serviced. Drive the machine until one of the two plugs is at the highest point.



a drive hub plugs

- 2 Remove the plug located at 90 degrees and check the oil level.
- ③ Result: The oil level should be even with the bottom of the hole.
- 3 If necessary, remove the top plug and add oil until the oil level is even with the bottom of the hole.
- 4 Apply pipe thread sealant to the plugs and install the plugs.
- 5 Repeat steps 1 through 4 for the other drive hub.
- 6 Check the torque of the drive hub mounting bolts. Refer to Section 2, *Specifications*.

Checklist C Procedures

C-1

Test the Platform Overload System (if equipped)




Genie specifications require that this procedure be performed every 500 hours or six months, whichever comes first OR when the machine fails to lift the maximum rated load.

Testing the platform overload system regularly is essential to safe machine operation. Continued use of an improperly operating platform overload system could result in the system not sensing an overloaded platform condition. Machine stability could be compromised resulting in the machine tipping over.

- 1 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 2 Raise the platform approximately 10 feet / 3 m.
- 3 Lift the safety arm and move it to the center of the linkage and rotate to a vertical position.
- 4 Lower the platform onto the safety arm.
- 5 Turn the key switch to the off position.
- 6 Locate and remove the maximum height limit switch from the lower slider channel and set aside.

Note: Do not disconnect the limit switch harness.



a maximum height limit switch

- 7 Turn the key switch to ground control and fully raise the platform.
 - ⊙ Result: The platform should stop raising and an alarm should sound. A fault of PLATFORM OVERLOADED should be present on the ECM diagnostic display window at the ground controls.
 - ✗ Result: The platform continues to raise OR an alarm does not sound OR a fault is not present on the ECM diagnostic display window at the ground controls. Refer to Repair Procedure 11-1, *Calibrate the Platform Overload System (if equipped)*.

CHECKLIST C PROCEDURES

- 8 Lower the platform onto the safety arm.
- 9 Turn the key switch to the off position.
- 10 Securely install the limit switch to the lower slider channel.
- 11 Turn the key switch to ground control and fully raise the platform.
 - ⦿ Result: The platform should stop raising at maximum height. An alarm should not sound.
 - ⊗ Result: The platform does not raise to maximum height OR an alarm sounds. Refer to Repair Procedure 11-1, *Calibrate the Platform Overload System (if equipped)*.
- 12 Lower the platform enough to return the safety arm to the stowed position.
- 13 Lower the platform to the stowed position.

C-2**Down Limit Switch Descent Delay (if equipped)****Check the Descent Delay Function**

Genie requires that this procedure be performed every 500 hours or six months, whichever comes first.

- 1 Turn the key switch to platform controls.
- 2 Raise the platform approximately 10 ft / 3 m.
- 3 Lower the platform until the down limit switch activates and the platform stops lowering. Quickly release the controls and then **immediately** attempt to lower the platform to the stowed position.
 - ⦿ Result: The platform stops for 4 to 6 seconds. Release the joystick and proceed to step 4.
 - ⊗ Result: The platform does not stop. Confirm that the descent delay option has been selected to ON. Refer to Repair Procedure 4-2, *How to Setup the Machine from Ground Controls*. Repeat this procedure.
- 4 Lower the platform to the stowed position.
- 5 Push in the red Emergency Stop button to the off position.

CHECKLIST C PROCEDURES

Check the Down Limit Switch Height

- 1 Turn the key switch to platform controls.
- 2 Raise the platform approximately 10 ft / 3 m.
- 3 Lower the platform until the down limit switch activates and the platform stops lowering.
- 4 Push in the red Emergency Stop button to the off position.
- 5 Measure the distance between the working surface and the platform deck.

GS-2669	63 to 69 inches 1.6 to 1.75 m
GS-3369	66 to 72 inches 1.7 to 1.83 m
GS-4069	76 to 82 inches 1.9 to 2.1 m

C-3 Replace the Hydraulic Tank Breather Cap - Models with Optional Hydraulic Oil



Genie requires that this procedure be performed every 500 hours or six months, whichever comes first.

The hydraulic tank is a vented-type tank. The breather cap has an internal air filter that can become clogged or deteriorate. If the breather cap is faulty or improperly installed, impurities can enter the hydraulic system which may cause component damage. Extremely dirty conditions may require that the cap be inspected more often.

- 1 Remove and discard the hydraulic tank breather cap.
- 2 Install and new cap onto the tank.

Checklist D Procedures

D-1

Check the Scissor Arm Wear Pads and Slider Blocks



Genie requires that this procedure be performed every 1000 hours or annually, whichever comes first.

Maintaining the scissor arm wear pads in good condition is essential to safe machine operation. Continued use of worn out wear pads may result in component damage and unsafe operating conditions.

- 1 Measure the thickness of each platform scissor arm slider blocks at the non-steer end of the machine.
 - ⦿ Result: The measurement is 3.875 inch / 9.843 cm or more. Proceed to step 2.
 - ⊗ Result: The measurement is less than 3.875 inch / 9.843 cm. Replace both slider blocks.
- 2 Measure the thickness of each chassis scissor arm upper and lower slider wear pads at the non-steer end of the machine.
 - ⦿ Result: The measurement is 1/4 inch / 6.35 mm or more. Proceed to step 3.
 - ⊗ Result: The measurement is less than 11/32 inch / 8.71 mm. Replace both upper and lower slider wear pads.

D-2

Replace the Hydraulic Filter



Genie requires that this procedure be performed every 1000 hours or annually, whichever comes first.

Replacement of the hydraulic tank return filter is essential for good machine performance and service life. A dirty or clogged filter may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

⚠ CAUTION Bodily injury hazard. Beware of hot oil. Contact with hot oil may cause severe burns.

- 1 Remove the filter with an oil filter wrench. Clean the area where the hydraulic oil filter meets the filter head.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

Note: The hydraulic filter is mounted on the hydraulic tank.

CHECKLIST D PROCEDURES


- 2 Apply a thin layer of fresh oil to the new oil filter gasket.
- 3 Install the new filter and tighten it securely by hand.
- 4 Use a permanent ink marker to write the date and number of hours from the hour meter on the filter.
- 5 Clean up any oil that may have spilled during the replacement procedure.
- 6 Turn the key switch to ground controls and pull out the red Emergency Stop button to the on position at both the ground and platform controls. Start the engine.
- 7 Raise the platform approximately 3 feet / 1 m.
- 8 Inspect the filter and related components to be sure that there are no leaks.

D-3**Replace the Drive Hub Oil**

Note: Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.

Replacing the drive hub oil is essential for good machine performance and service life. Failure to replace the drive hub oil at yearly intervals may cause the machine to perform poorly and continued use may cause component damage.

- 1 Select the drive hub to be serviced. Drive the machine until one of the two plugs is at the lowest point.
- 2 Remove both plugs and drain the oil into a suitable container.
- 3 Drive the machine until one of the two plugs is at the highest point.



a drive hub plugs

- 4 Fill the hub until the oil level is even with the bottom of the lowest plug hole. Refer to Section 2, *Specifications*.
- 5 Install the plugs into the drive hub.
- 6 Repeat this procedure for the other drive hub.

CHECKLIST D PROCEDURES

D-4 Test the Function Pump



Note: Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.

Proper pump function is essential to safe oscillate operation and machine function.

Note: Perform this procedure on a firm, level surface with the platform in the stowed position and the platform extension deck fully retracted.

- 1 Lower the platform to the stowed position.
- 2 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.

- 3 At the ground controls, record the time it takes to fully raise the platform.

- ⊙ Result: The time to fully elevate the platform is at or less than the table shown below. The efficiency of the function pump is good.

GS-2669	55 seconds
GS-3369	60 seconds
GS-4069	94 seconds

- ⊗ Result: The time to fully elevate the platform is greater than the table shown above, refer to Repair Procedure 4-2, *How to Setup the Machine from Ground Controls*. Repeat the above procedure.

Note: If the above times can not be achieved, the machine must be tagged and removed from service until the function pump is repaired or replaced.



Tip-over hazard. Failure to repair or replace the function pump as instructed could compromise the stability of the machine resulting in death or serious injury.

Checklist E Procedures

E-1

Test or Replace the Hydraulic Oil



Genie requires that this procedure be performed every 2000 hours or two years, whichever comes first.

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and suction strainers may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often.

Note: Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary. **If the hydraulic oil is not replaced at the two year inspection, test the oil quarterly. Replace the oil when it fails the test.**

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting torque Specifications*.

- 1 Push in the red Emergency Stop button to the off position.
- 2 Tag and disconnect the harnesses from the ground control box.
- 3 Remove the ground control box retaining fasteners and set aside. Remove the ground control box.
- 4 Locate the tank cover plate. Remove the tank cover plate mounting fasteners and remove the cover.
- 5 Place a drain pan or other suitable container under the hydraulic tank. Refer to Section 2, *Specifications*.
- 6 Remove the drain plug from the hydraulic tank and completely drain the tank.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 7 Tag, disconnect and plug the suction hose from the hydraulic tank. Cap the fitting.
- 8 Tag, disconnect and plug the return hose at the return filter. Cap the fitting on the filter.
- 9 Remove the return filter and head assembly from the tank. Cap and plug the fittings.
- 10 Loosen the tank strap retaining fastener in front of the tank. Move the strap to the side.
- 11 Remove the hydraulic tank from the machine.
- 12 Remove the suction strainer and clean using a mild solvent or replace.

CHECKLIST E PROCEDURES

- 13 Clean the inside of the hydraulic tank using a mild solvent.
- 14 Install the drain plug using thread sealer on the threads.
- 15 Install the suction strainer using thread sealer on the threads.
- 16 Install the hydraulic tank onto the machine.
- 17 Secure the tank with the tank strap. Do not over tighten.
- 18 Install the suction hose onto the tank.
- 19 Install the return filter and head assembly.
Note: Replace the return filter if needed.
- 20 Install the return hose to the return filter.
- 21 Fill the tank with hydraulic oil until the fluid is within the top 2 inches / 5 cm of the sight gauge. Do not overfill.
- 22 Clean up any oil that may have spilled. Properly discard the oil.
- 23 Operate all machine functions through a full cycle and check for leaks.
- 24 Check the oil level in the tank and add if needed.
- 25 Install the tank cover plate and install the tank cover plate mounting fasteners.

E-2**Grease the Steer Axle Wheel Bearings**

Genie requires that this procedure be performed every 2000 hours or two years, whichever comes first.

Maintaining the steer axle wheel bearings is essential for safe machine operation and service life. Operating the machine with loose or worn wheel bearings may cause an unsafe operating condition and continued use may result in component damage. Extremely wet or dirty conditions or regular steam cleaning and pressure washing of the machine may require that this procedure be performed more often.

- 1 Loosen the wheel lug nuts. Do not remove them.
- 2 Block the non-steer wheels, then center a lifting jack under the steer axle.
- 3 Raise the machine 6 inches / 15 cm and place blocks under the drive chassis for support.
- 4 Remove the lug nuts. Remove the tire and wheel assembly.
- 5 Check for wheel bearing wear by attempting to move the wheel hub side to side, then up and down.
 - ⊙ Result: There is no side to side or up and down movement. Proceed to step 10.
 - ⊗ Result: There is side to side or up and down movement Proceed to step 6.

CHECKLIST E PROCEDURES

6 Remove the dust cap from the hub. Remove the cotter pin from the castle nut.

7 Tighten the castle nut to 150 ft-lbs / 203 Nm to seat the bearings.

8 Fully loosen the castle nut and re-tighten to 35 ft-lbs / 48 Nm.

9 Check for wheel bearing wear by attempting to move the wheel hub side to side, then up and down.

⊙ Result: There is no side to side or up and down movement. Proceed to step 11.

⊗ Result: There is side to side or up and down movement. Proceed to step 11 and replace the wheel bearings with new ones.

Note: When replacing a wheel bearing, both the inner and outer bearings, including the pressed-in races, must be replaced.

10 Remove the dust cap from the hub. Remove the cotter pin from the castle nut.

11 Remove the castle nut.

12 Pull the hub off of the spindle. The spindle washer, thrust washer and outer bearing should fall loose from the hub.

13 Place the hub on a flat surface and gently pry the bearing seal out of the hub. Remove the rear bearing.

14 Pack both bearings with clean, fresh grease.

15 Place the large inner bearing into the rear of the hub.

16 Install a new bearing grease seal into the hub by pressing it evenly into the hub until it is flush.

17 Slide the hub onto the yoke spindle.

NOTICE Component damage hazard. Do not apply excessive force or damage to the lip of the seal may occur.

18 Place the outer bearing into the hub.

19 Install the spindle washer, thrust washer and castle nut.


20 Tighten the slotted nut to 150 ft-lbs / 203 Nm to seat the bearings.

21 Fully loosen the castle nut and re-tighten to 35 ft-lbs / 48 Nm.

22 Install a new cotter pin. Bend the cotter pin to lock it in place.

Note: Always use a new cotter pin when installing a castle nut.

23 Install the dust cap.



This page intentionally left blank.

Repair Procedures



Observe and Obey:

- ☑ Repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Repairs Start:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and parts are available and ready for use.
- ☑ Use only Genie approved replacement parts.
- ☑ Read each procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Platform in the stowed position
 - Key switch in the off position with the key removed
 - The red Emergency Stop button in the off position at both ground and platform controls
 - Wheels chocked
 - All external AC power supply disconnected from the machine

About This Section

Most of the procedures in this section should only be performed by a trained service professional in a suitably equipped workshop. Select the appropriate repair procedure after troubleshooting the problem.

Perform disassembly procedures to the point where repairs can be completed. Then to reassemble, perform the disassembly steps in reverse order.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

▲ DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

▲ WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

▲ CAUTION

Indicates a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.

NOTICE

Indicates a potentially hazardous situation which, if not avoided, may result in property damage.

⦿ Indicates that a specific result is expected after performing a series of steps.

⊗ Indicates that an incorrect result has occurred after performing a series of steps.


Platform Controls

The platform controls are used to operate the machine from the platform.

Activating a function button sends a signal to the Electronic Control Module (ECM). When the ECM is in the function mode, the platform controls are used to operate the various machine functions.

The platform controls consist of an Emergency Stop button, electronic circuit board, proportional control handle, drive/steer enable switch, alarm, function buttons and LED display.

For further information or assistance, consult the Genie Service Department.




- a red Emergency Stop button P2
- b platform controls circuit board U3
- c proportional control handle and drive/steer enable switch JC9
- d alarm H1

Operational Indicator Codes

These codes are generated by the electrical system to indicate machine operating status. During normal operation a code will appear in the platform controls LED readout if a condition such as off-level, overload cutout, chassis mode operation or pothole guards stuck occurs.

If the platform controls LED readout displays an operational indicator code such as LL, the fault condition must be repaired or removed before resuming machine operation. Push in and pull out the red Emergency Stop button to reset the system.



Platform Controls LED Readout

Code	Condition
LL	Off-Level
OL	Platform Overloaded (CE and Australia)
CH	Chassis Mode Operation
nd	No Drive (option)
F053	DCON RR Thermal Protection
F054	DCON LR Thermal protection
F055	Traction Motor RR
F056	Traction Motor LR
Ld	Lifting Disabled (option)

Note: A code and a description of a code can also be viewed at the ground controls LCD display.

PLATFORM CONTROLS

1-1 Circuit Board

How to Remove the Platform Controls Circuit Board

- 1 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 2 Disconnect the platform controls from the control cable at the platform.
- 3 Remove the fasteners securing the platform control box to the platform control bracket.
- 4 Remove the fasteners securing the bottom cover to the platform control box. Open the control box.
- 5 Remove the ties securing the wire harness.
- 6 Disconnect the red and black wires from the alarm.
- 7 Carefully remove the alarm from the platform control box.
- 8 Carefully disconnect all wire harness connectors from the platform controls circuit board.
- 9 Carefully remove the platform controls circuit board fasteners.
- 10 Carefully remove the platform controls circuit board from the platform control box.
- 11 Remove the transparent caps from the platform controls circuit board and save.

Circuit board fastener torque specifications

Hand tighten until screw seats	< 5 in-lbs < 0.6 Nm
--------------------------------	------------------------

Note: Before installing a circuit board, place the transparent caps removed in step 11, over the circuit board buttons.

Note: After installing the circuit board, check for proper button operation. Excessive torque of the circuit board fasteners will cause the buttons to bind. Moderate torque of the circuit board fasteners will not allow the buttons to engage.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

NOTICE Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

 PLATFORM CONTROLS

1-2 Joystick

How to Remove the Joystick

- 1 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 2 Disconnect the platform controls from the control cable at the platform.
- 3 Remove the fasteners securing the platform control box to the platform control bracket.
- 4 Remove the fasteners securing the bottom cover to the platform control box. Open the control box.
- 5 Remove the ties securing the joystick wire harness.
- 6 Carefully disconnect the joystick wire harness from the platform controls circuit board.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

NOTICE Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

- 7 Carefully remove the joystick fasteners.
- 8 Carefully remove the joystick from the platform control box.

Torque specifications

Joystick fasteners	9 in-lbs 1 Nm
--------------------	------------------

1-3 Platform Controls Alarm

How to Remove the Platform Controls Alarm

- 1 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 2 Disconnect the platform controls from the control cable at the platform.
- 3 Remove the fasteners securing the platform control box to the platform control bracket.
- 4 Remove the fasteners securing the bottom cover to the platform control box. Open the control box.
- 5 Disconnect the red and black wires from the alarm.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

NOTICE Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

- 6 Carefully remove the alarm from the platform control box.

PLATFORM CONTROLS

1-4 Platform Emergency Stop Button

How to Remove the Platform Controls Emergency Stop Button

- 1 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 2 Disconnect the platform controls from the control cable at the platform.
- 3 Remove the fasteners securing the platform control box to the platform control bracket.
- 4 Remove the fasteners securing the bottom cover to the platform control box. Open the control box.
- 5 Disconnect the white wires from the Emergency Stop base.

WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

NOTICE Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

- 6 Carefully remove the Emergency Stop base from the Emergency Stop button.
- 7 Carefully remove the retaining ring from the Emergency Stop button.
- 8 Carefully remove the Emergency Stop button from the platform control box.

Platform Components

2-1 Platform

How to Remove the Platform

WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is required.

Note: This procedure will require an overhead lifting device capable of supporting 1000 lbs / 454 kg.

- 1 Remove the zip tie that secures the power to platform wiring to the bottom of the platform.

NOTICE Component damage hazard. Be sure not to cut the power to platform wiring.

- 2 Remove the clamp that secures the platform controls cable to the platform.
- 3 Disconnect the platform controls cable from the connector located under the platform.
- 4 Remove the platform control box from the platform and lay it off to the side.


NOTICE Component damage hazard. The platform controls wiring can be damaged if it is kinked or pinched.

- 5 Remove the cover to the AC power to platform outlet. Tag and disconnect the wiring from the outlet.


WARNING Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Note: If your machine is equipped with an air line to platform option, the air line must be disconnected from the platform before removal.

- 6 Attach a sling chain from the overhead lifting device to the four lifting points on the platform.




- 7 Remove the two carriage bolts that secure the platform to the platform pivot at the steer end of the machine.



PLATFORM COMPONENTS

- 8 Carefully lift the platform enough to clear the platform pivot.
- 9 Slide the platform towards the non-steer end of the machine until the slider blocks are visible underneath the slider block channel.



- 10 Carefully lift the platform off of the machine and place it on a structure capable of supporting it.

WARNING Crushing hazard. The platform will become unbalanced and fall when removed from the machine if not properly supported.


Note: Note the position of the slider blocks before the platform is removed so that when the platform is installed they will be in the correct position.

2-2

Platform Extension Deck

How to Remove the Platform Extension Deck


- 1 Remove the retaining fasteners from the deck catch and remove the deck catch.
- 2 Remove the retaining fasteners from the deck stop and remove the deck stop.
- 3 Repeat steps 1 and 2 for the other side of the platform.



- a deck catch
b deck stop

PLATFORM COMPONENTS

- 4 Remove the platform controls from the platform and lay it off to the side.
- 5 Release the four rail spacers by pulling the retaining pin and turn them in a downward position.
- 8 Secure the platform extension deck railings to the carriage of the forklift to support the platform extension deck.
- 9 Carefully slide the platform extension out and away from the platform and place it on a structure capable of supporting it.




a rail spacer

- 6 Position a forklift at the steer end of the machine with the forks even with the bottom of the platform extension.
- 7 Carefully slide the platform extension out until the platform extension makes contact with the carriage on the forklift.

WARNING Crushing hazard. The platform extension will become unbalanced and fall when removed from the machine if not properly supported and secured to the forklift.

Scissor Components



Steer End

Non-steer End

- | | |
|---|---------------------------------------|
| 1 Platform pivot | 10 Slider block (Qty. 2) |
| 2 Number 3 outer arm | 11 Number 3 inner arm |
| 3 Lift cylinder rod-end pivot pin | 12 Number 3 center pivot pin (Qty. 2) |
| 4 Number 3 pivot pin (steer end) | 13 Number 3 pivot pin (non-steer end) |
| 5 Number 2 center pivot pin (Qty. 2) | 14 Number 2 inner arm |
| 6 Number 2 pivot pin (steer end) | 15 Number 2 outer arm |
| 7 Number 1 center pivot pin (Qty. 2) (ANSI/CSA) | 16 Number 2 pivot pin (non-steer end) |
| 7 Number 1 center pivot pin (Qty. 1) (AS/CE) | 17 Lift cylinder barrel-end pivot pin |
| 8 Number 1 inner arm | 18 Number 1 outer arm |
| 9 Chassis pivot | |



SCISSOR COMPONENTS

3-1 Scissor Assembly, GS-2669 DC

How to Disassemble the Scissor Assembly

WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is required.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.


Note: This procedure will require an overhead lifting device and sling chains capable of supporting 1000 lbs / 454 kgs.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Remove the retaining fasteners that attach the ladder to the drive chassis. Remove the ladder and set aside.
- 3 Remove the cables from the linkage assembly.

NOTICE Component damage hazard. Cables can be damaged if they are kinked or pinched.

- 4 Using a suitable supporting device, attach a strap to the rod end of the lift cylinder. Do not apply pressure.
- 5 Remove the lift cylinder rod end pivot pin (index #3) retaining fasteners.
- 6 Using a soft metal drift, remove the pivot pin.
- 7 Lower the lift cylinder and remove the strap.
- 8 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 3 inner arm (index #10). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.




- 9 Remove the retaining fasteners from the number 3 pivot pins (index #4 and #13).

Note: Do not remove the external snap ring.

SCISSOR COMPONENTS

- 10 Using a soft metal drift, remove the pivot pins and set aside.
- 11 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.
- 12 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 2 inner arm (index #14). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



- 13 Remove the retaining fasteners from the number 2 pivot pins (index #6 and #16).

Note: Do not remove the external snap ring.


- 14 Using a soft metal drift, remove the pivot pins and set aside.

- 15 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.
- 16 Tag and disconnect the harness from the lift cylinder valve block.
- 17 Tag and disconnect the hydraulic hoses from the lift cylinder. Plug the hoses and cap the fittings.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 18 Remove the hose clamps and hoses from the number 1 inner arm.
- 19 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 1 inner arm (index #8). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



SCISSOR COMPONENTS

- 20 Remove the two carriage bolts that secure the inner arm and chassis pivot to the steer end of the drive chassis.
- 21 Move the linkage towards the non-steer end of the machine until the slider feet are clear of the slider channel.
- 22 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

Separate the link sets:

- 1 Using an overhead lifting device attach a 4 hook sling chain to the ends of the inner arm (index #8, #11 or #14). Make the chains tight but do not apply lifting pressure.


▲WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.

- 2 Remove the retaining fasteners from the center pivot pins (index #5, #7 or #12).

Note: Do not remove the external snap ring.

- 3 Using a soft metal drift, remove the center pivot pins and set aside.
- 4 Carefully lift and separate the linkage assembly apart and place it on a structure capable of supporting it.

SCISSOR COMPONENTS



Steer End

Non-steer End

- | | |
|--|---------------------------------------|
| 1 Platform pivot | 13 Slider block (Qty. 2) |
| 2 Number 4 center pivot pin (Qty. 2) | 14 Number 4 inner arm |
| 3 Number 4 pivot pin (steer end) | 15 Number 4 outer arm |
| 4 Number 3 center pin (Qty. 2) | 16 Number 4 pivot pin (non-steer end) |
| 5 Lift cylinder rod-end pivot pin | 17 Number 3 inner arm |
| 6 Number 3 pivot pin (steer end) | 18 Number 3 outer arm |
| 7 Number 2 center pivot pin (2 Qty.) | 19 Number 3 pivot pin (non-steer end) |
| 8 Number 2 pivot pin (steer end) | 20 Number 2 inner arm |
| 9 Number 1 outer arm | 21 Number 2 outer arm |
| 10 Number 1 center pivot pin (Qty. 2) (ANSI/CSA) | 22 Number 2 pivot pin (non-steer end) |
| 10 Number 1 center pivot pin (Qty. 1) (AS/CE) | 23 Lift cylinder barrel-end pivot pin |
| 11 Number 1 inner arm | 24 Number 1 outer arm |
| 12 Chassis pivot | |



SCISSOR COMPONENTS

3-2 Scissor Assembly, GS-3369 DC

How to Disassemble the Scissor Assembly

WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is required.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.


Note: This procedure will require an overhead lifting device and sling chains capable of supporting 1000 lbs / 454 kgs.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Remove the retaining fasteners that attach the ladder to the drive chassis. Remove the ladder and set aside.
- 3 Remove the cables from the linkage assembly.

NOTICE Component damage hazard. Cables can be damaged if they are kinked or pinched.

- 4 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 4 inner arm (index #14). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



- 5 Remove the retaining fasteners from the number 4 pivot pins (index #3 and #16).


Note: Do not remove the external snap ring.

- 6 Using a soft metal drift, remove the pivot pins and set aside.
- 7 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

SCISSOR COMPONENTS

- 8 Using a suitable supporting device, attach a strap to the rod end of the lift cylinder. Do not apply pressure.
- 9 Remove the lift cylinder rod end pivot pin (index #5) retaining fasteners.
- 10 Using a soft metal drift, remove the pivot pin.
- 11 Lower the lift cylinder and remove the strap.
- 12 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 3 inner arm (index #19). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.




- 13 Remove the retaining fasteners from the number 3 pivot pins (index #6 and #19).

Note: Do not remove the external snap ring.

- 14 Using a soft metal drift, remove the pivot pins and set aside.
- 15 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.
- 16 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 2 inner arm (index #20). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



- 17 Remove the retaining fasteners from the number 2 pivot pins (index #8 and #22).

Note: Do not remove the external snap ring.

- 18 Using a soft metal drift, remove the pivot pins and set aside.

SCISSOR COMPONENTS

19 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

20 Tag and disconnect the harness from the lift cylinder valve block.


21 Tag and disconnect the hydraulic hoses from the lift cylinder. Plug the hoses and cap the fittings.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

22 Remove the hose clamps and hoses from the number 1 inner arm.

23 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 1 inner arm (index #11). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



24 Remove the two carriage bolts that secure the inner arm and chassis pivot to the steer end of the drive chassis.

25 Move the linkage towards the non-steer end of the machine until the slider feet are clear of the slider channel.

26 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

Separate the link sets:

1 Using an overhead lifting device attach a 4 hook sling chain to the ends of the inner arm (index #11, #14, #17 or #20). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.


2 Remove the retaining fasteners from the center pivot pins (index #2, #4, #7 or #10).

Note: Do not remove the external snap ring.

3 Using a soft metal drift, remove the center pivot pins and set aside.

4 Carefully lift and separate the linkage assembly apart and place it on a structure capable of supporting it.

SCISSOR COMPONENTS



- | | |
|--|---|
| 1 Platform pivot | 16 Slider block (Qty. 2) |
| 2 Number 5 center pivot pin (Qty. 2) | 17 Number 5 inner arm |
| 3 Number 5 pivot pin (steer end) | 18 Number 5 outer arm |
| 4 Number 4 center pivot pin (Qty. 2) | 19 Number 5 pivot pin (non-steer end) |
| 5 Number 4 inner arm | 20 Upper lift cylinder rod-end pivot pin |
| 6 Number 4 pivot pin (steer end) | 21 Number 4 outer arm |
| 7 Number 3 center pivot pin (Qty. 2) | 22 Number 4 pivot pin (non-steer end) |
| 8 Lower lift cylinder rod-end pivot pin | 23 Upper lift cylinder barrel-end pivot pin |
| 9 Number 3 inner arm | 24 Number 3 outer arm |
| 10 Number 3 pivot pin (steer end) | 25 Number 3 pivot pin (non-steer end) |
| 11 Number 2 center pivot pin (Qty. 2) | 26 Number 2 inner arm |
| 12 Number 2 pivot pin (steer end) | 27 Number 2 outer arm |
| 13 Number 1 center pivot pin (Qty. 2) (ANSI/CSA) | 28 Number 2 pivot pin (non-steer end) |
| 13 Number 1 center pivot pin (Qty. 1) (AS/CE) | 29 Lower lift cylinder barrel-end pivot pin |
| 14 Number 1 inner arm | 30 Number 1 outer arm |
| 15 Chassis pivot | |



SCISSOR COMPONENTS

3-3 Scissor Assembly, GS-4069 DC

How to Disassemble the Scissor Assembly

WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is required.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.


Note: This procedure will require an overhead lifting device and sling chains capable of supporting 1000 lbs / 454 kgs.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Remove the retaining fasteners that attach the ladder to the drive chassis. Remove the ladder and set aside.
- 3 Remove the cables from the platform through the linkage assembly.

NOTICE Component damage hazard. Cables can be damaged if they are kinked or pinched.

- 4 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 5 inner arm (index #17). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



- 5 Remove the retaining fasteners from the number 5 pivot pins (index #3 and #19).


Note: Do not remove the external snap ring.

- 6 Using a soft metal drift, remove the pivot pins and set aside.
- 7 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

SCISSOR COMPONENTS

- 8 Using a suitable supporting device, attach a strap to the rod end of the upper lift cylinder. Do not apply pressure.
- 9 Remove the upper cylinder rod end pivot pin (index #20) retaining fasteners.
- 10 Using a soft metal drift, remove the pivot pin.
- 11 Lower the lift cylinder and remove the strap.
- 12 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 4 inner arm (index #5). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



- 13 Remove the retaining fasteners from the number 4 pivot pins (index #6 and #22).

Note: Do not remove the external snap ring.

- 14 Using a soft metal drift, remove the pivot pins and set aside.
- 15 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.
- 16 Tag and disconnect the harness from the upper lift cylinder valve block.
- 17 Tag and disconnect the hydraulic hoses from the upper lift cylinder. Plug the hoses and cap the fittings.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 18 Remove the cables and hoses from the linkage assembly.


NOTICE Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.

- 19 Using a suitable lifting device remove the retaining fasteners from the upper lift cylinder. Remove the cylinder.
- 20 Using a suitable supporting device, attach a strap to the rod end of the lower lift cylinder. Do not apply pressure.
- 21 Remove the lower cylinder rod end pivot pin (index #8) retaining fasteners.
- 22 Using a soft metal drift, remove the pivot pin.
- 23 Lower the lift cylinder and remove the strap.

SCISSOR COMPONENTS

24 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 3 inner arm (index #9). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



25 Remove the retaining fasteners from the number 3 pivot pins (index #10 and #25).


Note: Do not remove the external snap ring.

26 Using a soft metal drift, remove the pivot pins and set aside.

27 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

28 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 2 inner arm (index #26). Make the chains tight but do not apply lifting pressure.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



29 Remove the retaining fasteners from the number 2 pivot pins (index #12 and #28).

Note: Do not remove the external snap ring.

30 Using a soft metal drift, remove the pivot pins and set aside.

31 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.


SCISSOR COMPONENTS

- 32 Tag and disconnect the harness from the lower lift cylinder valve block.
- 33 Tag and disconnect the hydraulic hoses from the lower lift cylinder. Plug the hoses and cap the fittings.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 34 Remove the hose clamps and hoses from the number 1 inner arm.
- 35 Using an overhead lifting device attach a 4 hook sling chain to the ends of the number 1 inner arm (index #14). Make the chains tight but do not apply lifting pressure.

▲WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.



- 36 Remove the two carriage bolts that secure the inner arm and chassis pivot to the steer end of the drive chassis.
- 37 Move the linkage towards the non-steer end of the machine until the slider feet are clear of the slider channel.
- 38 Carefully lift the linkage assembly off of the machine and place it on a structure capable of supporting it.

Separate the link sets:

- 1 Using an overhead lifting device attach a 4 hook sling chain to the ends of the inner arm (index #5, #9, #14, #17 or #26). Make the chains tight but do not apply lifting pressure.

▲WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported when removed from the machine.

- 2 Remove the retaining fasteners from the center pivot pins (index #2, #4, #7, #11 or #13).

Note: Do not remove the external snap ring.

- 3 Using a soft metal drift, remove the center pivot pins and set aside.
- 4 Carefully lift and separate the linkage assembly apart and place it on a structure capable of supporting it. It will need to be carefully adjusted for proper balancing.

SCISSOR COMPONENTS


3-4 Wear Pads

How to Replace the Scissor Arm Wear Pads

Platform Scissor Arm Slider Blocks:

- 1 Remove the platform. See 2-1, How to Remove the Platform.
- 2 Remove the slider blocks and discard.
- 3 Install the slider blocks.

Note: When installing the platform the drill holes in the slider blocks must be on the top and bottom.



- 4 Install the platform.

Chassis Scissor Arm Wear Pads:


- 1 Attach a lifting strap from a suitable lifting device to the ladder at the non-steer end of the machine. Support the ladder. Do not apply lifting pressure.
- 2 Remove the fasteners securing the ladder to the chassis. Remove the ladder from the machine and set aside.

WARNING Crushing hazard. The ladder could fall if not properly supported when the fasteners are removed from the machine.

- 3 Using an overhead lifting device attach a strap to the #1 inner arm at the non-steer end of the machine.


Note: The overhead lifting device and strap must be capable of supporting 5000 lbs / 2268 kg.

WARNING Crushing hazard. The linkage assembly could become unbalanced and fall if not properly supported.



SCISSOR COMPONENTS


- 4 Raise the linkage assembly slightly with the overhead lifting device just enough to take pressure off of the slider feet.
- 5 Remove the retaining fasteners from the slider feet pivot pins and set aside.



- a Slider foot assembly
- b pivot pin
- c retaining fasteners

- 6 Using a soft metal drift, remove the pivot pins and set aside.
- 7 Remove the slider feet by sliding them out of the slider channel.
- 8 Remove the upper and lower wear pads and discard.

- 9 Using a hard rubber mallet, secure the upper and lower wear pads to the slider feet.



- a upper wear pads
- b slider foot
- c lower wear pad

- 10 Install the slider feet into the slider channel and secure them to the linkage assembly with the pivot pins.
- 11 Securely tighten the pivot pin retaining fasteners.
- 12 Securely install the ladder onto the machine. Do not over tighten the fasteners.

SCISSOR COMPONENTS

3-5 Lift Cylinder(s)

The lift cylinders are single acting hydraulic cylinders. The GS-2669 DC and GS-3369 DC uses one lift cylinder; the GS-4069 DC uses two. Each lift cylinder is equipped with a check valve to prevent movement in the event of a hydraulic line failure.


How to Remove the Lift Cylinder

GS-2669 DC and GS-3369 DC:

⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Disassemble the scissor assembly. See 3-1 or 3-2, *How to Disassemble the Scissor Assembly*.



GS-2669 DC and GS-3369 DC

- a platform down solenoid valve
- b lift cylinder
- c pressure switch (AS/CE models)


SCISSOR COMPONENTS

GS-4069 DC:

⚠WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Disassemble the scissor assembly. See 3-3, *How to Disassemble the Scissor Assembly*.



GS-4069 DC

- a platform down solenoid valve
- b upper lift cylinder
- c lower lift cylinder
- d pressure switch (AS/CE models)

Ground Controls

The ground controls, used to operate the machine from the ground, can also be used to tune the performance of the machine.


The ground controls consist of an Electronic Control Module (ECM), emergency stop button, key switch and circuit breaker.

Activating the function enable button and the up or down at the same time, sends a signal to the (ECM). This allows the platform to be raised or lowered at the ground controls.

Note: Steer and drive functions are not available at the ground controls.

When the ECM is in the set up mode, the ground controls are used to adjust the function speed parameters, machine models, or machine options.

For further information or assistance, consult the Genie Service Department.



- a machine setup, escape button
- b machine setup, scroll up button
- c LCD readout
- d machine setup, scroll down button
- e machine setup, enter button
- f key switch KS1
- g red Emergency Stop P1
- h ECM U1
- i platform down button
- j lift function enable button
- k platform up button


GROUND CONTROLS

4-1 Software Revision Level


How to Determine the Software Revision Level

The machine software revision level is displayed at the ground controls LCD display.

- 1 Turn the key switch to the ground controls or platform controls position. Pull out the red Emergency Stop button to the on position at both ground and platform controls.
- Result: The display at the platform controls will show "CH". See example below.




- Result: The display at the ground controls will show the machine model and hour meter information. After 3 seconds, the machine model will not show on the display. See example below.



- 2 Press the ground control scroll down button.
- Result: The ground control LCD display will indicate the software revision and hour meter information. After 5 seconds, the ground controls LCD display will display machine model and hour meter information again. See example below.



- 3 Push in the red Emergency Stop button to the off position at both the ground and platform controls and turn the key switch to the off position.



- a ground control LCD display
- b ground control scroll down button

GROUND CONTROLS

4-2 Machine Setup

How to Setup the Machine from Ground Controls


The ground controls can be used to setup the machine parameters from the ground. Features that can be adjusted from the ground controls include machine Model, Options and Speed setup. This menu can only be entered from ground controls with the key switch in the ground controls position.

⚠ DANGER Tip-over hazard. Do not adjust function speeds higher than specified in this procedure. Setting the function speeds greater than specifications could cause the machine to tip over resulting in death or serious injury.

⚠ DANGER Tip-over hazard. This procedure must only be performed by a trained service professional. Attempting this procedure without the necessary skills could result in death or serious injury.

Note: Select a test area that is firm, level and free of obstructions.

- 1 Turn the key switch to the ground controls position and pull out the red Emergency Stop button to the on position at the platform controls.
- 2 Press and hold the ground control scroll up and scroll down buttons.



Ground Control Menu Buttons

- a scroll down button
- b enter button
- c scroll up button
- d escape button
- e LCD display

- 3 Pull out the red Emergency Stop button to the on position at the ground controls.
- Result: The ground controls LCD display will show the following:




- 4 Use the ground control menu buttons to select machine Model, Options and Speed Setup parameters. Follow the menu structure indicated on the ground control LCD display.

GROUND CONTROLS

4-3 Auxiliary Platform Lowering

Auxiliary Platform Lowering

In the event of a main power failure, activating the auxiliary enable and auxiliary platform lowering toggle switches at the ground controls will lower the platform. There is no adjustment required.



- a auxiliary enable toggle switch
b auxiliary lowering toggle switch

4-4 Level Sensor - Models without Outriggers

The Electronic Control Module (ECM) is programmed to deactivate the lift and drive functions and activate an alarm when a signal is received from the level sensor.

The tilt alarm sounds when the incline of the chassis exceeds 2° to the side and 3° to the front or rear.

How to Install and Calibrate the Level Sensor

⚠ DANGER Tip-over hazard. Failure to install or calibrate the level sensor as instructed could result in the machine tipping over causing death or serious injury. Do not install or calibrate the level sensor other than specified in this procedure.


Note: Perform this procedure with the machine on a firm, level surface and the platform in the stowed position. Use a digital level to confirm.

- 1 Remove the platform controls from the platform.

If you are not installing a new level sensor, proceed to step 7.

- 2 Locate the level sensor in the ground controls compartment.

GROUND CONTROLS




a ground control box
b level sensor

- 3 Tag and disconnect the wire harness from the level sensor.
- 4 Remove the retaining fasteners securing the level sensor to the compartment. Remove the level sensor from the machine.

- 5 Install the new level sensor onto the machine with the "X" on the level sensor base towards the steer end of the machine. Install and tighten the level sensor retaining fasteners.

⚠ DANGER Tip-over hazard. The tilt level sensor must be installed with the "X" on the level sensor base towards the steer end of the machine. Failure to install the tilt level sensor as instructed could result in the machine tipping over causing death or serious injury.



a "Y" indicator
b level sensor
c "X" indicator
d chassis

GROUND CONTROLS

- 6 Connect the wire harness to the level sensor.
 - 7 Turn the key switch to platform control and pull out the red Emergency Stop buttons to the on position at both the ground and platform controls.
 - 8 Tighten the level sensor adjusting fasteners until the bubble in the top of the level sensor is centered in the circles.
- Note: Be sure there are threads showing through the top of the adjusting fasteners.
- ⦿ Result: The tilt sensor alarm should not sound.
- 9 Center a lifting jack under the drive chassis at the ground controls side of the machine.
 - 10 Raise the machine approximately 4 inches / 10 cm.
 - 11 Place a 1.94 x 10 x 10 inch / 4.93 x 25 x 25 cm thick steel block under both wheels at the ground controls side of the machine.
 - 12 Lower the machine onto the blocks.
 - 13 Raise the platform at least 12 feet / 3.6 m.
- ⦿ Result: The tilt alarm does not sound and all functions will operate. Proceed to step 15.
 - ⊗ Result - The drive function and the lift function will not operate and the tilt alarm will sound at 180 beeps per minute. Proceed to step 14.
- 14 Turn the level sensor adjusting nuts just until the level sensor alarm does not sound.
 - 15 Lower the platform to the stowed position.
 - 16 Raise the machine approximately 4 inches / 10 cm.
 - 17 Remove the blocks from under both wheels.
 - 18 Lower the machine and remove the jack.
 - 19 Center a lifting jack under the drive chassis at the engine side of the machine.
 - 20 Raise the machine approximately 4 inches / 10 cm.
 - 21 Place a 2.25 x 10 x 10 inch / 5.72 x 25 x 25 cm thick steel block under both wheels at the ground controls side of the machine.
 - 22 Lower the machine onto the blocks.
 - 23 Raise the platform at least 12 feet / 3.6 m.
- ⦿ Result - The drive function and the lift function will not operate and the tilt alarm will sound at 180 beeps per minute.
 - ⊗ Result: If the tilt sensor alarm does not sound, adjust the tilt level sensor until the alarm just begins to sound OR the down limit switch may need to be adjusted.
- 24 Lower the platform to the stowed position.
 - 25 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
 - 26 Turn the key switch to the off position.
 - 27 Raise the machine approximately 4 inches / 10 cm.
 - 28 Remove the blocks from under both wheels.
 - 29 Lower the machine and remove the jack.

GROUND CONTROLS

4-5 Level Sensor - Models with Outriggers

The Electronic Control Module (ECM) is programmed to deactivate the lift and drive functions and activate an alarm when a signal is received from the level sensor.

When the outriggers are stowed, the tilt alarm sounds when the incline of the chassis exceeds 2° to the side.

When the outriggers are deployed, the tilt alarm sounds when the incline of the chassis exceeds 0.8° to the side.


At all times, the tilt alarm sounds when the incline of the chassis exceeds 3° to the front or rear.

How to Install the Outrigger Level Sensor

⚠ DANGER Tip-over hazard. Failure to install the level sensor as instructed will compromise machine stability and cause the machine to tip over, resulting in death or serious injury. Do not install the level sensor other than specified in this procedure.

- 1 Move the machine to an area that has a firm, level surface and is free of obstructions.
- 2 Turn the key switch to the off position and push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 3 Open the access door at the ground controls side of the machine.
- 4 Tag and disconnect the wire harness from the level sensor.

GROUNDCONTROLS



a ground controls (GCON)
b level sensor




illustration 1

- 5 Remove the level sensor retaining fasteners and remove the level sensor from the machine.
- 6 Install the new level sensor onto the machine with the "X" on the level sensor base towards the steer end of the machine. Refer to Illustration 1.
- 7 Secure the level sensor with the retaining fasteners removed in step 5.
- 8 Adjust the level sensor retaining fasteners until the bubble in the top of the level sensor is centered in the circles.
- 9 Connect the level sensor wire harness to the new level sensor.
- 10 Close the access door at the battery side of the machine.
- 11 Calibrate the new level sensor. Refer to Repair Procedure 10-2, *Outrigger Calibration*.

GROUND CONTROLS

4-6 Service Override Mode

The Electronic Control Module (ECM) is programmed with a service override mode. Service Override mode is only intended for certain circumstances and is not part of normal machine operation. If Service Override mode is required, this indicates there may be faults and/or a malfunctioning machine. Contact trained personnel immediately.

Note: This procedure can only be performed from the ground controls and is intended to allow the platform to be raised or lowered. Once the platform has reached the maximum allowable height the system will exit service override mode. Repeat this procedure to lower the platform.


Note: When in Service Override mode an audible alarm will sound.

Note: Before using the Service Override mode, make sure you understand the fault code or malfunction affecting the operation of the machine to be sure the use of Service Override is required.

Note: Perform this procedure on a firm, level surface with the outriggers auto leveled or fully retracted.

⚠ DANGER Tip-over hazard. Operating the machine on an unlevel surface while in Service Override mode will result in death or serious injury if proper operating procedures and safety precautions are not followed. Do not use this mode if you are not trained and familiar with the operation of the machine.

- 1 Turn the key switch to the ground controls position and pull out the red Emergency Stop button to the on position at the platform controls.
- 2 Press and hold the ground control scroll up and scroll down buttons.



Ground Control Menu Buttons

- a scroll down button
- b enter button
- c scroll up button
- d escape button
- e LCD display

GROUND CONTROLS

3 Pull out the red Emergency Stop button to the on position at the ground controls.

- ⦿ Result: The ground controls LCD display will show the following:



4 Release the Scroll Up and Scroll Down buttons after the ground controller powers up.


5 At the ground controls, use the Scroll Down button to scroll to **SVC Override**.

- ⦿ Result: The ground controls LCD display will show the following.




6 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following.



6 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following.



Hydraulic Pump

5-1 Hydraulic Pump

The hydraulic pump is a single section, gear-type pump.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

How to Test the Hydraulic Pump

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to test port #1 (TP1) on the function manifold.
- 2 Remove the platform controls from the platform and place the controls near the function manifold on the tank side of the machine.
- 4 Steer the machine fully to the right or left and hold. Note the pressure readings on the pressure gauge. Refer to Section 2, *Specifications*.

How to Remove the Hydraulic Pump

- 1 Tag, disconnect and plug the hydraulic hoses on the pump. Cap the fittings on the pump.

⚠WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


- 2 Remove the pump mounting bolts. Carefully remove the pump.

⚠WARNING After replacing the hydraulic pump, it is critical to return the lift and drive speed settings to original factory specifications. Refer to Section 2, *Performance Specifications*.

HYDRAULIC PUMP

How to Calibrate the Hydraulic Pump

- 1 Turn the key switch to the ground controls position and pull out the red Emergency Stop button to the on position at the platform controls.
- 2 Press and hold the ground control scroll up and scroll down buttons.



Ground Control Menu Buttons

- a scroll down button
- b enter button
- c scroll up button
- d escape button
- e LCD display

- 3 Pull out the red Emergency Stop button to the on position at the ground controls.
- ⦿ Result: The ground controls LCD display will show the following:



- 4 Release the Scroll Up and Scroll Down buttons after the ground controller powers up.
- 5 At the ground controls, use the Scroll Up or Scroll Down buttons to scroll to **Select Option**.



- 6 Press the Enter button.
- 7 Use the Scroll Up or Scroll Down buttons to scroll to **Select Option Pump Efficiency**.



- 8 Press the Enter button.
- ⦿ Result: The ground controls LCD display will show the following.



- 9 Press the Scroll Down button.
- ⦿ Result: The ground controls LCD display will show the following.



HYDRAULIC PUMP

10 Press the Enter button.

- Result: The ground controls LCD display will show the following.



11 Press and **Hold** the Enter button.

- Result: The ground controls LCD display will scroll through the following screens.

Note: Continue to hold the Enter button until calibration is complete. If the Enter button is released, return to step 10 and repeat this procedure.



- Result: The ground controls LCD displays the following screen. Calibration data is within range.




Note: The screen will return to the options screen after 2 seconds.

- Result: The ground controls LCD displays the following screen. Calibration data is not within range. The pump needs to be repaired or replaced.



12 For a bad result, press the Enter button to return to the option screen

13 Push in the red Emergency Stop button to the off position.



This page intentionally left blank.

Manifolds


6-1

Function Manifold Components

The function manifold is located inside the hydraulic tray.

Index No.	Description	Schematic Item	Function	Torque
1	Check valve	FA	Oscillate circuit	20 ft-lbs / 27 Nm
2	Solenoid valve, 2 position 3 way Orifice	FB	Oscillate / Accumulator	20 ft-lbs / 27 Nm
3	Relief valve, (GS 2669 - 3100 psi / 214 bar) (GS 3369 - 2900 psi / 200 bar) (GS 4069 - 2850 psi / 197 bar)	FD	Lift circuit	20 ft-lbs / 27 Nm
4	Accumulator.	FE	Oscillate circuit	11 ft-lbs / 15 Nm
5	Solenoid valve, 2 position 3 way	FF	Oscillate circuit	20 ft-lbs / 27 Nm
6	Flow control valve, 1 gpm / 3.8 L/min	FG	Controls flow to the oscillate circuit	20 ft-lbs / 27 Nm
7	Relief valve, 3500 psi / 241 bar	FH	System relief	20 ft-lbs / 27 Nm
8	Relief valve, 1500 psi / 103 bar	FI	Steer circuit	20 ft-lbs / 27 Nm
9	Check valve	FJ	Load sense	12-14 ft-lbs / 16-19 Nm
10	Flow control valve, 2 gpm / 7.6 L/min	FK	Controls flow to the steer circuit	20 ft-lbs / 27 Nm
11	Solenoid valve, 3 position 5 way Check valve	FL	Steer circuit	20 ft-lbs / 27 Nm
12	Pressure switch	FN	Oscillate / Accumulator	11 ft-lbs / 15 Nm
13	Solenoid valve, 2 position 3 way	FO	Lift circuit	25 ft-lbs / 34 Nm
14	Solenoid valve, 2 position 3 way	FP	Oscillate right	20 ft-lbs / 27 Nm
15	Relief valve, 3300 psi / 228 bar	FQ	Oscillate relief	20 ft-lbs / 27 Nm
16	Solenoid valve, 2 position 3 way	FR	Oscillate left	20 ft-lbs / 27 Nm

MANIFOLDS




MANIFOLDS

6-2 Valve Adjustments - Function Manifold

How to Adjust the System Relief Valve

Note: Perform this procedure with the machine in the stowed position.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to test port #1 on the function manifold.
- 2 Remove the platform controls from the platform and place the controls near the function manifold on the tank side of the machine.
- 3 Remove the coil from the platform up valve. Do not disconnect the harness from the coil.
- 4 Press and hold the enable and platform up buttons. Note the pressure reading on the pressure gauge. Refer to Section 2, *Specifications*.
- 5 Use a wrench to hold the system relief valve (item b) and remove the cap.
- 6 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.
- 7 Repeat this procedure beginning with step 4 to confirm the relief valve pressures.
- 8 Remove the pressure gauge.



- a test port #1
- b system relief valve
- c platform up valve

WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.

MANIFOLDS


How to Adjust the Oscillate Relief Valve

Note: Perform this procedure with the machine in the stowed position and in high torque mode.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to test port #2 (TP2) on the function manifold.
- 2 Disconnect the harness from the oscillate supply coil and the steer right coil.
- 3 Connect the oscillate supply harness to the steer right coil and the steer right harness to the oscillate supply coil.
- 3 Turn the key switch to platform control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 4 Steer the machine to the right and hold. Note the pressure readings on the pressure gauge. Refer to Section 2, *Specifications*.
- 5 Use a wrench to hold the oscillate relief valve (item d) and remove the cap.
- 6 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.

WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.

- 7 Repeat this procedure beginning with step 4 to confirm the relief valve pressure.
- 8 Connect the harness back to the original position.
- 9 Remove the pressure gauge.



- a test port #2
- b oscillate supply coil (green/white and brown wires)
- c steer right coil (blue and brown wires)
- d oscillate relief valve

MANIFOLDS


How to Adjust the Steer Relief Valve

Note: Perform this procedure with the machine in the stowed position.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to test port #1 on the function manifold.
- 2 Remove the platform controls from the platform and place the controls near the function manifold on the tank side of the machine.
- 3 Steer the machine fully to the right or left and hold. Note the pressure reading on the pressure gauge. Refer to Section 2, *Specifications*.
- 4 Use a wrench to hold the steer relief valve (item b) and remove the cap.
- 5 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.

WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.

- 6 Repeat this procedure beginning with step 3 to confirm the relief valve pressures.
- 7 Remove the pressure gauge.




- a test port #1
b steer relief valve

MANIFOLDS

How to Adjust the Platform Up Relief Valve (Models with Platform Overload)

Note: Be sure that the hydraulic oil level is within the top 2 inches / 5 cm of the sight gauge.


- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to test port #1 on the function manifold.



- a platform up relief valve
- b test port #1

- 2 Turn the key switch to the ground controls position and pull out the red Emergency Stop button to the on position at the platform controls.

- 3 Press and hold the ground control scroll up and scroll down buttons.



Ground Control Menu Buttons

- a scroll down button
- b enter button
- c scroll up button
- d escape button
- e LCD display

- 4 Pull out the red Emergency Stop button to the on position at the ground controls.
- Result: The ground controls LCD display will show the following:



- 5 Release the Scroll Up and Scroll Down buttons after the ground controller powers up.

MANIFOLDS


- 6 At the ground controls, use the Scroll Down button to scroll to **SELECT OPTION**.

- ⦿ Result: The ground controls LCD display will show the following.



- 7 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following:



- 8 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following:




- 9 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following:



- Note: After 1 second the display will return to **SELECT OPTION, PLAT. OVERLOAD**.



- 10 Press the Scroll Down button to scroll to **Down Delay**.

- ⦿ Result: The ground controls LCD display will show the following:



- 11 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following:



- 12 Press the Enter button.

- ⦿ Result: The ground controls LCD display will show the following:




MANIFOLDS

Note: After 1 second the display will return to **SELECT OPTION, DOWN DELAY**.




- 13 Push in the red Emergency Stop button to the off position.
- 14 Pull out the red Emergency Stop button to the on position and raise the platform approximately 10 feet / 3 m.
- 15 Lift the safety arm and move it to the center of the linkage and rotate to a vertical position.
- 16 Lower the platform onto the safety arm. Push in the red Emergency stop button to the off position.
- 17 Locate and disconnect the lift cylinder pressure switch harness.



- a platform down solenoid valve
 b lift cylinder
 c pressure switch (AS/CE models)

- 18 Locate and disconnect the maximum height limit switch harness.



a maximum height limit switch

Models to serial number GS6913-1755:

- 19 Remove the maximum height limit switch from the lower slider channel and set aside.

Models from serial number GS6913-1756:

- 19 Secure the maximum height limit switch roller head in the up position.

NOTICE

Component damage hazard. The limit will be damaged if it is not properly removed or the roller is secured.

MANIFOLDS

20 Pull out the red Emergency Stop button to the on position and raise the platform approximately 10 feet / 3 m.

21 Return the safety arm to the stowed position.

22 Lower the platform to the stowed position.

23 Using a suitable lifting device, place a test weight in the center of the platform floor. Secure the weight to the platform. Refer to the chart below.

GS-2669	680 kg
GS-3369	454 kg
GS-4069	363 kg

24 Press and hold the lift function enable button and press and hold the platform up button. Allow the platform to raise completely, then continue activating the lift function while observing the pressure reading on the pressure gauge. Note the pressure. Refer to Section 2, *Specifications*.

25 Hold the lift relief valve (item a) with a wrench and remove the cap.

26 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.

▲ DANGER Tip-over hazard. Failure to adjust the relief valve as instructed will cause the machine to tip over resulting in death or serious injury. Do not adjust the relief valve higher than specified.

27 Repeat this procedure beginning with step 24 to confirm the relief valve pressure.

28 Lower the platform and remove the test weights.

29 Raise the platform approximately 10 feet / 3 m.

30 Lift the safety arm and move it to the center of the linkage and rotate to a vertical position.

31 Lower the platform onto the safety arm. Push in the red Emergency stop button to the off position.

32 Connect the harness to the lift cylinder pressure switch.

Models to serial number GS6913-1755:

33 Install the maximum height limit switch to the lower slider channel and connect the harness.

Models from serial number GS6913-1756:

33 Release the maximum height limit switch roller head and connect the harness.

34 Pull out the red Emergency Stop button to the on position and raise the platform approximately 10 feet / 3 m.

35 Return the safety arm to the stowed position.

36 Lower the platform to the stowed position.

37 Push in the red Emergency Stop button to the off position.

MANIFOLDS

38 Press and hold the ground control scroll up and scroll down buttons.

39 Pull out the red Emergency Stop button to the on position at the ground controls.

- Result: The ground controls LCD display will show the following:



40 Release the Scroll Up and Scroll Down buttons after the ground controller powers up.


41 At the ground controls, use the Scroll Down button to scroll to **SELECT OPTION**.

- Result: The ground controls LCD display will show the following.




42 Press the Enter button.

- Result: The ground controls LCD display will show the following:



43 Press the Enter button.

- Result: The ground controls LCD display will show the following:




44 Press the Enter button.

- Result: The ground controls LCD display will show the following:



Note: After 1 second the display will return to **SELECT OPTION, PLAT. OVERLOAD.**



45 Press the Scroll Down button to scroll to **Down Delay**.

- Result: The ground controls LCD display will show the following:



MANIFOLDS

46 Press the Enter button.

- Result: The ground controls LCD display will show the following:



47 Press the Enter button.

- Result: The ground controls LCD display will show the following:



Note: After 1 second the display will return to **SELECT OPTION, DOWN DELAY.**




48 Push in the red Emergency Stop button to the off position.

49 Perform maintenance procedures *C-1, Test the Platform overload System* and *C-2, Down Limit Switch Desent delay.*

How to Adjust the Platform Up Relief Valve (Models with Platform Overload)

Note: Be sure that the hydraulic oil level is within the top 2 inches / 5 cm of the sight gauge.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to test port #1 on the function manifold.



- a platform up relief valve
- b test port #1

MANIFOLDS

- 2 Pull out the red Emergency Stop button to the on position and raise the platform approximately 10 feet / 3 m.
- 3 Return the safety arm to the stowed position.
- 4 Lower the platform to the stowed position.
- 5 Using a suitable lifting device, place a test weight in the center of the platform floor. Secure the weight to the platform. Refer to the chart below.
- 9 Repeat this procedure beginning with step 4 to confirm the relief valve pressure.
- 10 Lower the platform and remove the test weights.

GS-2669	680 kg
GS-3369	454 kg
GS-4069	363 kg

- 6 Press and hold the lift function enable button and press and hold the platform up button. Allow the platform to raise completely, then continue activating the lift function while observing the pressure reading on the pressure gauge. Note the pressure. Refer to Section 2, *Specifications*.
- 7 Hold the lift relief valve (item a) with a wrench and remove the cap.
- 8 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.


▲ DANGER Tip-over hazard. Failure to adjust the relief valve as instructed will cause the machine to tip over resulting in death or serious injury. Do not adjust the relief valve higher than specified.

MANIFOLDS

6-3 Outrigger Manifold Components

The outrigger manifold is located beneath the hose cover panel on top of the drive chassis

Index No.	Description	Schematic Item	Function	Torque
1	Solenoid valve, 3 position 4 way NC	BA	Outriggers in / out	20-25 ft-lbs / 27-34 Nm



6-4 Valve Coils

How to Test a Coil

A properly functioning coil provides an electromagnetic force which operates the solenoid valve. Critical to normal operation is continuity within the coil. Zero resistance or infinite resistance indicates the coil has failed.

Since coil resistance is sensitive to temperature, resistance values outside specification can produce erratic operation. When coil resistance decreases below specification, amperage increases. As resistance rises above specification, voltage increases.

While valves may operate when coil resistance is outside specification, maintaining coils within specification will help ensure proper valve function over a wide range of operating temperatures.

⚠ WARNING Electrocuting/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Note: If the machine has been in operation, allow the coil to cool at least 3 hours before performing this test.

- 1 Tag and disconnect the wiring from the coil to be tested.
- 2 Test the coil resistance using a multimeter set to resistance (Ω). Refer to the Valve Coil Resistance Specification table.

✘ Result: If the resistance is not within the adjusted specification, plus or minus 10%, replace the coil.

Valve Coil Resistance Specification

Note: The following coil resistance specifications are at an ambient temperature of 68°F / 20°C. As valve coil resistance is sensitive to changes in air temperature, the coil resistance will typically increase or decrease by 4% for each 18°F / 20°C that your air temperature increases or decreases from 68°F / 20°C.

Description	Specification
Solenoid valve, 2 position 2 way 24V DC with diode (schematic items CA, CB, CC, CD, CE, CF)	25 Ω
Solenoid valve, 2 position 3 way 24V DC with diode (schematic items BA, FB, FF, FO, FP, FR,)	35 Ω
Solenoid valve, 3 position 5 way 24V DC with diode (schematic item FL)	35 Ω

MANIFOLDS

How to Test a Coil Diode

Genie incorporates spike suppressing diodes in many valve coils. Properly functioning coil diodes protect the electrical circuit by suppressing voltage spikes. Voltage spikes naturally occur within a function circuit following the interruption of electrical current to a coil. Faulty diodes can fail to protect the electrical system, resulting in a tripped circuit breaker or component damage.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Test the coil for resistance. See 6-4, *How to Test a Coil*.
- 2 Connect a 10Ω resistor to the negative terminal of a known good 9V DC battery. Connect the other end of the resistor to a terminal on the coil.


Note: The battery should read 9V DC or more when measured across the terminals.

Resistor, 10Ω

Genie part number 27287

- 3 Set a multimeter to read DC current.

Note: The multimeter, when set to read DC current, should be capable of reading up to 800 mA.



Note: Dotted lines in illustration indicate a reversed connection as specified in step 6

- 4 Connect the negative lead to the other terminal on the coil.

Note: If testing a single-terminal coil, connect the negative lead to the internal metallic ring at either end of the coil.

- 5 Momentarily connect the positive lead from the multimeter to the positive terminal on the 9V DC battery. Note the current reading.
 - 6 At the battery or coil terminals, reverse the connections. Note the current reading.
- ⊕ Result: Both current readings are greater than 0 mA and are different by a minimum of 20%. The coil is good.
- ⊗ Result: If one or both of the current readings are 0 mA, or if the two current readings do not differ by a minimum of 20%, the coil and/or its internal diode are faulty and the coil should be replaced.

Hydraulic Tank

7-1

Hydraulic Tank

The primary functions of the hydraulic tank is to cool, clean and deaerate the hydraulic fluid during operation. It utilizes internal suction strainer for the pump supply line and has an external return line filter.

How to Remove the Hydraulic Tank

NOTICE Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system and cause severe component damage. Dealer service is recommended.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Open the hydraulic tank side cover.
- 2 Remove the drain plug from the hydraulic tank and completely drain the tank into a container of suitable capacity. Refer to Section 2, *Machine Specifications*.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Tag and disconnect the harnesses from the ground control box.
- 4 Remove the ground control box from the machine and set aside.
- 5 Tag disconnect and plug the hydraulic hoses from the hydraulic tank. Cap the fittings on the tank and return filter.
- 6 Loosen the hydraulic tank mounting strap fastener. Pull the tank strap to the side.

Note: Do not remove the tank strap.

- 7 Remove the hydraulic tank from the machine.

NOTICE Component damage hazard. During installation, do not overtighten the hydraulic tank strap mounting fastener.

Note: Clean the hydraulic tank and inspect for cracks or other damage before installing.

Steer Axle Components

8-1 Yoke Assembly

How to Remove the Yoke


- 1 Block the non-steer wheels and center a lifting jack under the drive chassis at the steer end of the machine.
- 2 Loosen the wheel lug bolts. Do not remove them.
- 3 Raise the machine approximately 2 inches / 5 cm. Place blocks under the chassis for support.

WARNING Crushing hazard. The chassis will fall if not properly supported.

- 4 Remove the wheel lug bolts. Remove the tire and wheel assembly.
- 5 Support and secure the yoke and assembly with a lifting device.

Left side yoke:

- 6 Remove the retaining fasteners from the tie rod pivot pin.



- a upper king pin
- b tie rod pivot pin
- c lower king pin
- d steer sensor assembly
- e yoke assembly

- 7 Use a small pry bar to move the pivot pin down enough to clear the steer sensor assembly.
- 8 Remove the steer sensor actuator and spring from the tie rod pivot pin and set aside.
- 9 Remove the steer sensor assembly and set it aside.
- 10 Using a soft metal drift pin and a mallet, drive the pivot pin up to remove it.

STEER AXLE COMPONENTS

- 11 Remove the retaining fastener from the lower yoke king pin.
- 12 Use a small pry bar to remove the king pin.
- 13 Remove the retaining fastener from the upper yoke king pin.
- 14 Use a small pry bar to remove the king pin.
- 15 Remove the yoke assembly from the machine.

CAUTION Crushing hazard. The assembly may become unbalanced and fall if not properly supported and secured with a suitable lifting device when it is removed from the machine.

Right side yoke:

- 6 Remove the steer cylinder rue ring and clevis pin from the yoke and set aside.
- 7 Remove the tie rod rue ring and clevis pin from the yoke and set aside.
- 8 Remove the retaining fastener from the lower yoke king pin.
- 9 Use a small pry bar to remove the king pin.
- 10 Remove the retaining fastener from the upper yoke king pin.
- 11 Use a small pry bar to remove the king pin.
- 12 Remove the yoke assembly from the machine.

CAUTION Crushing hazard. The assembly may become unbalanced and fall if not properly supported and secured with a suitable lifting device when it is removed from the machine.

How to Remove a Drive Motor (4 WD Models)

NOTICE Component damage hazard. Repairs to the motor should only be performed by an authorized dealer.

NOTICE Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system and cause severe component damage. Dealer service is recommended.

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Refer to Repair Procedure 8-1, *How to Remove the Yoke*.
- 2 Remove the drive motor mounting fasteners. Remove the drive motor from the yoke.

STEER AXLE COMPONENTS

8-2 Steer Cylinder

How to Remove the Steer Cylinder

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Tag, disconnect and plug the hydraulic hoses from the steer cylinder. Cap the fittings on the cylinder.


AWARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Remove the rue ring from each cylinder clevis pin. Remove the clevis pins.
- 3 Remove the steer cylinder from the machine.

8-3 Tie Rod

How to Remove the Tie Rod

- 1 Remove the rue ring from the clevis pin connecting the tie rod to the right side yoke assembly. Remove the clevis pin.



- a clevis pin
- b pivot pin
- c steer sensor assembly
- d tie rod
- e rue ring

- 2 Remove the retaining fasteners from the pivot pin connecting the tie rod to the left side yoke assembly.
- 3 Use a small pry bar to move the pivot pin down enough to clear the steer sensor assembly.
- 4 Remove the steer sensor assembly and set it aside.
- 5 Using a soft metal drift pin and a mallet, drive the pivot pin up to remove it.
- 6 Remove the tie rod.

STEER AXLE COMPONENTS

8-4 Oscillate Cylinder

How to Remove the Oscillate Cylinder

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Tag, disconnect and plug the hydraulic hoses from the oscillate cylinder. Cap the fittings on the cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Block the non-steer wheels and center a lifting jack under the drive chassis just behind the front axle at the side of the machine.
- 3 Remove the pivot pin retaining fasteners.
- 4 Using a soft metal drift, remove the pivot pins.

Note: Adjust the lifting jack to reduce the load on the pivot pins. Do not lift the machine off of the ground.

- 5 Remove the oscillate cylinder from the machine.

8-5 Oscillate Hoses

Test the Oscillate Axle Hose Routing

Note: Perform this procedure if the oscillate hoses have been removed or replaced.

- 1 Open the ground controls compartment and locate the function manifold. Refer to illustration 1, item A.




illustration 1

STEER AXLE COMPONENTS

- 2 Disconnect the connector with the green/black wire from the oscillate right coil (item b) and swap it with the connector with the blue wire from the steer right coil (item c) Refer to illustration 2.




illustration 2

- 3 Disconnect the connector with the green wire from the oscillate left coil (item a) and swap it with the connector with the blue/black wire from the steer left coil (item d) Refer to illustration 2.
- 4 Turn the key switch to platform controls and pull out the red Emergency stop buttons to the on position at both the ground and platform controls.
- 5 Slowly drive the machine in a safe direction and activate steer right.
 - ⦿ Result: The right oscillate cylinder will extend and the left oscillate cylinder will retract.
- 6 Slowly drive the machine in a safe direction and activate steer left.
 - ⦿ Result: The left oscillate cylinder will extend and the right oscillate cylinder will retract.
- 7 Turn the machine off.
- 8 Swap the connectors back to the correct coils using steps 2 and 3 as a reference. Continue to **Check the Steering**.

Check the Steering

- 1 Turn the key switch to platform controls and pull out the red Emergency stop buttons to the on position at both the ground and platform controls.
- 2 Activate steer right and verify the machine steers to the right.
- 3 Activate steer left and verify the machine steers to the left.
- 4 Test the axle oscillate. Refer to Maintenance Procedures A-4, *Test the Oscillate Axle*.


STEER AXLE COMPONENTS

8-6 Steer Angle Sensor

How to Replace the Steer Angle Sensor

The steer angle sensor, installed on the steer yoke, is monitored by the control system to determine steer angle. The control system uses the steer angle input, along with pre-programmed parameters, to vary the speed of each drive motor while steering to minimize tire scrub and to help minimize turning radius. Drive speed is also reduced proportionately depending on the steer angle to minimize lateral platform acceleration.

- 1 Adjust the steer tires so they are in a straight driving position.
- 2 Turn the key switch to the off position.
- 3 Push in the red Emergency Stop buttons to the off position at both the ground and platform controls.
- 4 Remove the cable clamp securing the steer sensor cable to the chassis.
- 5 Tag and disconnect the steer sensor harness from the main harness.
- 6 Remove the steer sensor cover.
- 7 Remove the tie rod pivot pin retaining fasteners.



- a left yoke assembly
- b steer sensor cover
- c compression spring
- d steer sensor actuator
- e tie rod pivot pin


- 8 Use a small pry bar to move the pivot pin down enough to remove the steer sensor actuator and compression spring.

Note: Inspect the steer sensor actuator to make sure it is not broken or twisted.

- 9 Remove the steer sensor assembly retaining fasteners. Remove the steer sensor assembly from the yoke.

STEER AXLE COMPONENTS

10 Set the spacer plate aside.



- a steer sensor cover
- b spacer plate
- c steer sensor bracket
- d cable restraint
- e steer sensor
- f steer sensor spacer
- g steer sensor mounting plate


11 Pull the sensor harness through the cable restraint and sensor bracket.

12 Remove the retaining fasteners that secure the steer sensor and the sensor spacer to the mounting plate. Remove the steer sensor.

13 Install the new steer sensor.

14 Install the steer sensor assembly to the yoke.

15 Rotate the tie rod pivot pin until it is approximately 90° from the mounting tab on the tie rod.



16 Install the steer sensor actuator onto the tie rod pivot pin.

17 Insert the compression spring into the steer sensor and push the tie rod pivot pin up until the actuator hex pin is engaged into the steer sensor.

Note: Be sure the sensor actuator hex pin is engaged into the sensor.

18 Rotate the tie rod pivot pin counterclockwise approximately 90° and secure it to the tie rod.

19 Install the steer sensor cover.


20 Connect the steer sensor harness to the main harness and secure with the cable clamp.

21 Calibrate the steer sensor. Refer to, *How to Calibrate the Steer Angle Sensor*.

STEER AXLE COMPONENTS

How to Calibrate the Steer Angle Sensor

- 1 Turn the key switch to the ground controls position and pull out the red Emergency Stop button to the on position at the platform controls.
- 2 Press and hold the ground control scroll up and scroll down buttons.



- a scroll down button
- b enter button
- c scroll up button
- d escape button
- e LCD display

- 3 Pull out the red Emergency Stop button to the on position at the ground controls.
- ⦿ Result: The ground controls LCD display will show the following.



- 4 Release the Scroll Up and Scroll Down buttons after the ground controller powers up.
- 5 At the ground controls, use the Scroll Up or Scroll Down buttons to scroll to **Select Option**.



- 6 Press the Enter button.
- 7 Use the Scroll Up or Scroll Down buttons to scroll to **Select Option Steer Sensor**.



- 8 Press the Enter button.
- ⦿ Result: The ground controls LCD display will show the following.



Note: Do not press the Enter button. Pressing the Enter button will disable the steer sensor

- 9 Use the Scroll Up or Scroll Down buttons to scroll to **Calibrate Steer Sensor**.




STEER AXLE COMPONENTS

10 Press the Enter button.


- Result: The ground controls LCD display will show the following.

Note: The platform controls do not have to be connected at the chassis ground controls.



11 Press the Enter button.

- Result: The ground controls LCD display will show the following screens.



12 Use the platform drive controller steer function to align the steer tires with the drive chassis.

13 Press the Enter button.

- Result: The ground controls LCD display will show the following screens.



14 Use the platform drive controller steer function to turn the steer tires fully to the right.

15 Press the Enter button.

- Result: The ground controls LCD display will show the following screens.



16 Use the platform drive controller steer function to turn the steer tires fully to the left.

17 Press the Enter button.

- Result: The ground controls LCD display will show the following.



Note: If any screens other than the one shown is displayed, repeat this procedure. If the problem persist, contact your local Genie Service Department.

18 Push in the red Emergency Stop button to the off position.

Non-steer Axle Components

9-1 Drive Motors

How to Remove a Drive Motor

The drive motors are AC powered and are a brushless design requiring very little maintenance. They have built-in speed and temperature sensors which is monitored by the ground controls (GCON). The speed sensor is a Hall-effect type and is part of the rear motor shaft bearing. The temperature switch will shut down the drive motor if it becomes excessively hot.

- 1 Disconnect the battery pack from the machine.


AWARNING Electrocuttion/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 2 Block the steer wheels.
- 3 Center a lifting jack of ample capacity under the drive chassis at the non-steer end of the machine.
- 4 Loosen the wheel lug nuts. Do not remove them.
- 5 Raise the machine approximately 2 inches / 5 cm. Place blocks under the chassis for support.

AWARNING Crushing hazard. The chassis will fall if it is not properly supported.

- 6 Remove the wheel lug nuts. Remove the tire and wheel assembly.

- 7 Remove the axle cover.




- a axle cover
- b drive hub
- c axle assembly

- 8 Tag and disconnect the electrical connectors for the brake, speed and temperature sensors at the drive motor.
- 9 Tag and disconnect the electrical connectors for the oscillate limit switches.
- 10 Tag and disconnect the drive motor power cables from the motor controller in the ground controls compartment.

Note: The power cables will have to be pulled through the drive chassis when the axle assembly is removed.

NON-STEER AXLE COMPONENTS


11 Support and secure the rear axle assembly.



- a axle pivot pin
- b retaining fasteners
- c axle assembly

12 Remove the axle pivot pin retaining fasteners.

13 Using a soft metal drift, remove the axle pivot pin. Remove the axle assembly from the machine.



- a axle assembly
- b drive hub
- c retaining fasteners (x4)
- d drive motor

14 Remove the retaining fasteners that secure the drive motor to the drive hub.

15 Support and slide the drive motor shaft out of the drive hub. Remove the drive motor from the machine.

9-2 Drive Hub

How to Remove a Drive Hub


NOTICE Component damage hazard. Repairs to the drive hub should only be performed by an authorized dealer.

- 1 Remove the drive motor. Refer to Repair Procedure 9-1, *How to Remove a Drive Motor*.
- 2 Support and secure the drive hub.
- 3 Remove the drive hub mounting fasteners. Remove the drive hub.

CAUTION Crushing hazard. The drive hub may become unbalanced and fall if not properly supported and secured with a suitable lifting device when removed from the machine.

Note: There is an O-ring between the drive motor and drive hub. Be sure that it is in place when installing the drive motor to the drive hub.

Note: Refer to Section 2, *Specifications* for torque specifications.



- a axle assembly
- b o-ring
- c mounting fasteners
- d drive hub

Outrigger Components

10-1 Outrigger Cylinder

How to Remove an Outrigger Cylinder (if equipped)

Note: When removing a hose assembly or fitting, the O-ring on the fitting and/or hose must be replaced and then torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*

- 1 Remove the mounting fasteners from the inside outrigger cylinder cover. Remove the cover.
- 2 Remove the outrigger hose cover.
- 3 Disconnect the outrigger limit switch and cylinder valve connectors.
- 4 Remove the mounting fasteners from the outside outrigger cover. Remove the cover.
- 5 Tag, disconnect and plug the hydraulic hoses from the outrigger cylinder. Cap the fittings on the cylinder.

⚠WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 6 Attach a lifting strap from an overhead crane to the barrel end of the outrigger cylinder for support. Do not apply any lifting pressure.
- 7 Remove the outrigger mounting fasteners. Slide the outrigger cylinder down and away from the machine.

⚠CAUTION Crushing hazard. The outrigger cylinder may become unbalanced and fall if not properly supported when removed from the machine.

Note: If the outrigger cylinder is being replaced, remove the foot pad assembly and install it on the replacement cylinder.

Note: After an outrigger cylinder has been installed the machine must be re-calibrated. Refer to Repair Procedure 10-2, *Outrigger Calibration*.

OUTRIGGER COMPONENTS

10-2 Outrigger Calibration

The Electronic Control Module (ECM) is programmed to deactivate the drive and steer functions while the outriggers are deployed and activate an alarm when a signal is received from the outrigger level sensor, indicating the outriggers are not deployed or the machine is out of level.


The ECM is also used to calibrate the outrigger level sensor to achieve a levelness of $0^\circ \pm 0.5^\circ$ front to back and side to side, while the outriggers are deployed.

For further information or assistance, consult the Genie Service Department.

How to Calibrate the Outrigger System

- 1 Move the machine to a firm level surface that is free of obstructions. Use a digital level to confirm.
- 2 Turn the key switch to the ground controls position and pull out the red Emergency Stop button to the on position at the platform controls.

- 3 Press and hold the ground controls scroll up and scroll down buttons.



- a scroll down button
- b enter button
- c scroll up button
- d escape button
- e LCD display

- 4 Pull out the red Emergency Stop button to the on position at the ground controls.
- Result: The ground controls LCD display will show the following.



- 5 Release the Scroll Up and Scroll Down buttons at the ground controls.
- 6 Use the Scroll Up or Scroll Down buttons to scroll to Machine Options.

OUTRIGGER COMPONENTS

- 7 Press the Enter button to select Machine Options.
- 8 Use the Scroll Up or Scroll Down buttons to scroll to Outriggers.
- 9 Press the Enter button to select Outriggers.
- 10 Use the Scroll Up or Scroll Down buttons to scroll to Calibrate Outriggers.
- 11 Press the Enter button to select Calibrate Outriggers.
- 12 Press and hold the Enter button while the system gathers data to calibrate the outrigger level sensor.

⚠ WARNING Crushing hazard. Keep body parts away from outriggers during outrigger movement.

- 13 Continue holding the Enter button after the outrigger level sensor is calibrated. The outriggers will retract while the outrigger system gathers and saves data.
 - 14 Continue holding the Enter button after the outriggers retract. The outriggers will now extend and the system will gather and save data to calibrate the outriggers.
 - 15 Continue holding the Enter button after the outriggers extend. The outriggers will now retract while the outrigger system gathers and saves data.
- ⦿ Result: The alarms at the ground and platform controls should sound for 1 second. The outrigger system is calibrated.

Note: This procedure must be performed if the level sensor has been replaced.

Platform Overload Components

11-1 Platform Overload System

How to Calibrate the Platform Overload System (if equipped)



On machines with platform overload systems, proper calibration is essential to safe machine operation. An improperly calibrated platform overload system could result in the system failing to sense an overloaded platform. The stability of the machine is compromised and it could tip over.

Note: For troubleshooting information refer to page 4-72.

- 1 **Models with outriggers:** Deploy the outriggers and level the machine.
- 2 Apply a thin layer of dry film lubricant to the area of the chassis where the scissor arm wear pads make contact.
- 3 Using a suitable lifting device, place a weight, in the center of the platform floor. Secure the weight to the platform. Refer to the chart below.

GS-2669	1500 lb / 680 kg
GS-3369	1000 lb / 454 kg
GS-4069	800 lb / 363 kg

- 4 Turn the key switch to ground controls and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
 - 5 Raise the platform to approximately 10 ft / 3 m.
 - 6 Lower the platform until the down limit switch activates and the platform stops lowering.
 - 7 Locate a supporting device under the platform. Do not apply any lifting pressure.
 - 8 Loosen the retaining ring and remove the switch adjustment cover from the pressure switch.
- Note: The pressure switch is located on the lower lift cylinder.
- 9 Using a small slotted screwdriver, turn the adjustment screw of the platform overload pressure switch one-quarter turn into the hydraulic line.
 - 10 Push in the red Emergency Stop button to the off position at the ground controls.

PLATFORM OVERLOAD COMPONENTS

11 Pull out the red Emergency Stop button to the on position at the ground controls. Wait 3 seconds.

⊙ Result: The alarm doesn't sound. Proceed to step 12.

⊗ Result: An alarm is sounding. Repeat this procedure beginning with step 9.

Note: The red Emergency Stop button must be cycled after each quarter turn of the nut to allow the platform overload system to reset.

Note: Wait a minimum of 3 seconds between each quarter turn of the nut to allow the platform overload system to reset.

12 Remove the supporting device from under the platform.

13 Raise the platform to 13 ft / 4 m.

14 Rotate the safety arm away from the machine and let it hang down.

15 Lower the scissor assembly until the safety arm rest on the cross tube.

16 Install the cover onto the platform overload pressure switch or switch box and securely tighten the cover retaining fasteners. Do not over tighten.

17 Apply Sentry Seal to one of the cover retaining fasteners where it contacts the platform overload pressure switch box.

18 Raise the platform enough to return the safety arm to the stowed position.

19 Lower the platform to the stowed position.

Check the Maximum Height Limit Switch

1 Using a suitable lifting device, place a test weight in the center of the platform floor. Secure the weight to the platform. Refer to the chart below.

GS-2669	680 kg
GS-3369	454 kg
GS-4069	363 kg

2 Raise the platform to approximately 13 ft / 4 m.

3 Rotate the safety arm away from the machine and let it hang down.

4 Raise the platform until it activates the maximum height limit switch.

⊙ Result: The platform should stop raising and the alarm does not sound. Proceed to step 7.


⊗ Result: The platform continues to raise OR the alarm sounds. Proceed to step 5.

5 Lower the scissor assembly until the safety arm rest on the cross tube.

6 Adjust the maximum height limit switch by moving it towards the non-steer end of the machine. Repeat this procedure beginning with step 2.

PLATFORM OVERLOAD COMPONENTS

- 7 Lower the platform enough to return the safety arm to the stowed position.
- 8 Lower the platform to the stowed position.
Remove the test weight.




Limit switch legend

- a down limit switch
- b load sense interrupt limit switch
- c maximum height limit switch

PLATFORM OVERLOAD COMPONENTS

TROUBLESHOOTING THE PLATFORM OVERLOAD SYSTEM		
CONDITION	POSSIBLE CAUSE	SOLUTION
CANNOT LIFT RATED LOAD	RELIEF VALVE SET TOO LOW	INCREASE RELIEF VALVE PRESSURE
AT MAX. HEIGHT WITH RATED LOAD IN PLATFORM, PRESSURE SWITCH ALARM CONTINUES TO SOUND	SYSTEM NEEDS TO BE RESET	TURN OFF RED EMERGENCY STOP BUTTON, WAIT THREE SECONDS AND TURN MACHINE BACK ON
	MAX. HEIGHT LIMIT SWITCH OUT OF ADJUSTMENT OR FAULTY	LOWER THE UP LIMIT SWITCH SLIGHTLY OR REPLACE CONTACTS
	TOO MUCH WEIGHT IN PLATFORM	PUT CORRECT RATED LOAD IN PLATFORM
	PRESSURE SWITCH OUT OF ADJUSTMENT	TURN THE PRESSURE SWITCH NUT 1/4 TURN INTO THE HYDRAULIC LINE
	BATTERIES ARE NOT FULLY CHARGED	CHARGE BATTERIES
	OVERLOAD SYSTEM NOT ADJUSTED PROPERLY	REPEAT CALIBRATION PROCEDURE
	SLIDER CHANNEL NOT LUBRICATED	LUBRICATE THE SLIDER CHANNEL
AT DOWN LIMIT WITH RATED LOAD IN PLATFORM, THE PRESSURE SWITCH ALARM CONTINUES TO SOUND	SYSTEM NEEDS TO BE RESET	TURN OFF RED EMERGENCY STOP BUTTON, WAIT THREE SECONDS AND TURN MACHINE BACK ON
	DOWN LIMIT SWITCH OUT OF ADJUSTMENT	RAISE THE DOWN LIMIT SWITCH
	TOO MUCH WEIGHT IN PLATFORM	PUT CORRECT RATED LOAD IN PLATFORM
	OVERLOAD SYSTEM NOT ADJUSTED PROPERLY	TURN THE PRESSURE SWITCH NUT 1/4 TURN INTO THE HYDRAULIC LINE OR REPEAT CALIBRATION PROCEDURE



This page intentionally left blank.

Diagnostics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Platform in the stowed position
 - Key switch in the off position with the key removed
 - The red Emergency Stop button in the off position at both ground and platform controls
 - Wheels chocked
 - All external AC power supply disconnected from the machine

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.
- ☑ Read each appropriate fault code thoroughly. Attempting short cuts may produce hazardous conditions.
- ☑ Be aware of the following hazards and follow generally accepted safe workshop practices.

⚠ DANGER

Crushing hazard. When testing or replacing any hydraulic component, always support the structure and secure it from movement.

⚠ WARNING

Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


- ⊙ Indicates that a specific result is expected after performing a series of steps.
- ⊗ Indicates that an incorrect result has occurred after performing a series of steps.

DIAGNOSTICS

About This Section

When a malfunction is discovered, the fault code charts in this section will help a service professional pinpoint the cause of the problem. To use this section, basic hand tools and certain pieces of test equipment are required — voltmeter, ohmmeter, pressure gauges.

General Repair Process



Definitions

GSDS - Genie SmartLink™ Diagnostic System

ECM - Electronic Control Module

DCON - Drive Controller

GCON - Ground Controls

PCON - Platform Controls

OIC - Operational Indicator Codes

DTC - Diagnostic Trouble Codes

GCON LCD Diagnostic Readout

**H001: COILFAULT
PLAT UP1:Bat-**

The diagnostic readout displays alpha numeric codes that provide information about the machine operating status and about malfunctions.

The codes listed in the Diagnostic Trouble Code Charts describe malfunctions and can aid in troubleshooting the machine by pinpointing the area or component affected.


DIAGNOSTICS

Genie SmartLink Diagnostic System


This machine is equipped with the Genie SmartLink™ Diagnostic System (GSDS). The GSDS indicates a machine malfunction has happened by displaying Operational Indicator Codes (OIC) and Diagnostic Trouble Codes (DTC). These codes are displayed at the Platform Controls and the Ground Controls. The Ground Controls will display a brief description of the code at the LCD display as well.

Refer to the GCON I/O Maps, Operational Indicator Codes (OIC) and Diagnostic Trouble Codes (DTC) in this section, to assist in troubleshooting faults.


GCON ECM Connector Layout




Rear of Ground Controls ECM



Models without outriggers



Rear of Ground Controls ECM



Models with outriggers



GCON I/O Map

GCON I/O MAP			
Ground Controls Pin Number	Circuit Function	I/O Type	Wire Color
C1 Connector - Gray			
C1-01	ECM / Logic Power	Power Input	RD
C1-02	PCON - E-Stop Power	Power Output	WH
C1-03	PCON - E-Stop Return	Power Input	BK
C1-04	Link to PCON - CAN HI	Data Bus	YL
C1-05	Link to PCON - CAN LOW	Data Bus	GR
C1-06	PCON - Ground	Ground Output	BR
C1-07	GCON - Ground	Ground Output	BR
C1-08	Key Switch - PCON Mode	Digital Input	BK
C1-09	Key Switch - GCON Mode	Digital Input	WH
C1-10	GCON - Emergency Stop	Digital Input	RD
C1-11	Accumulator Pressure Switch	Digital Input	OR/RD
C1-12	ECM Driver Power	Power Input	RD
C2 Connector - Black			
C2-01	Platform Up Coil	Digital Output	OR
C2-02	Platform Down Coil	Digital Output	OR/BK
C2-03	Steer Left Coil	Digital Output	BL/BK
C2-04	Steer Right Coil	Digital Output	BL
C2-05	Oscillate Supply Coil	Digital Output	GR/WH
C2-06	Oscillate Right Coil	Digital Output	GR/BK
C2-07	Not Used	N/A	N/A
C2-08	Brake Relay CR60	Digital Output	WH/RD
C2-09	Oscillate Left	Digital Output	GR
C2-10	Accumulator Coil	Digital Output	OR/RD
C2-11	Not Used	N/A	N/A
C2-12	Not Used	N/A	N/A
C3 Connector - Green			
C3-01	Not used	N/A	N/A
C3-02	GCON - Alarm	Digital Output	WH/RD
C3-03	Sensor Power	Digital output	RD
C3-04	Automotive Horn	Digital Output	WH
C3-05	Left Oscillate Limit Switch	Digital Input	GR/BK
C3-06	Right Oscillate Limit Switch	Digital Input	GR
C3-07	Down Limit Switch - LS6	Digital Input	OR
C3-08	Digital Level Sensor (if equipped)	Digital Input	RD/BK
C3-09	Platform Overload Pressure Switch (platform overload option)	Digital Input	BL
C3-10	Platform Overload Pressure Switch (platform overload option)	Digital Input	WH/BK
C3-11	Pump Speed Hz	Digital Input	OR/BK
C3-12	Sensor Ground	Digital Input	BK
C4 Connector - Brown (Outrigger Option)			
C4-01	Left Front Outrigger Limit Switch	Digital Input	BK
C4-02	Right Front Outrigger Limit Switch	Digital Input	OR
C4-03	Left Rear Outrigger Limit Switch	Digital Input	BL
C4-04	Right Rear Outrigger Limit Switch	Digital Input	GR
C4-05	Level Sensor Y Axis	Analog Input	GR/WH
C4-06	Level Sensor X Axis	Analog input	GR/BK
C4-07	Left Front Outrigger Coil	Digital Output	BK/WH
C4-08	Right Front Outrigger Coil	Digital Output	OR/WH
C4-09	Left Rear Outrigger Coil	Digital Output	BL/WH
C4-10	Right Rear Outrigger Coil	Digital Output	GR/WH
C4-11	Outrigger Extend Coil	Digital Output	WH/RD
C4-12	Outrigger Retract Coil	Digital Output	WH/BK

DIAGNOSTICS

Operational Indicator Codes (OIC)

These codes are generated by the electrical system to indicate machine operating status such as Off-level, Overload Cutout, Chassis Mode Operation during normal operation. These codes are not indicators of a device malfunction in the electrical system.

Code	Condition
LL	Off-Level
OL	Platform Overloaded (CE and Australia)
CH	Chassis Mode Operation
nd	No Drive (option)
Ld	Lifting Disabled (option)

Diagnostic Trouble Codes (DTC)

These codes are generated by the system to indicate that a device or circuit malfunction has been detected in the electrical system. The types of Diagnostic Trouble Codes that may occur are explained below.

Type "HXXX" - Indicate a malfunction associated with devices that control hydraulic functions in the electrical system. The "HXXX" faults are divided into short circuit battery negative, short circuit to battery positive, open circuit and generic shorts. Example of these devices are solenoid controlled hydraulic valves and motor controller.

Type "PXXX" - Indicate a malfunction associated with power type devices in the electrical system. The "PXXX" faults are divided into short circuit to battery negative, short circuit to battery positive, open circuit and generic shorts. Example of these devices are horns, sensor power and alarms.

Type "UXXX" - Indicate a malfunction associated with user interface devices in the electrical system. The "UXXX" faults are divided into short circuit to battery negative, short circuit to battery positive, open circuit and generic shorts. Example of these devices are GCON up and down switches and PCON drive joystick.

Type "FXXX" - Indicate a malfunction associated with machine feedback devices in the electrical system. The "FXXX" faults are divided into short circuit to battery negative, short circuit to battery positive, open circuit and generic shorts. Example of these devices are limit switches and pressure switches.


Type "CXXX" - Indicate a malfunction associated with controls devices in the electrical system. Example of these devices are platform controls and ground controls ECM.

DIAGNOSTICS

Troubleshooting "HXXX" and "PXXX" Faults


The procedure below illustrates typical steps for diagnosing and fixing faults of type "HXXX and PXXX".

Diagnostic Chart



Wiring Diagram


The wiring diagram shown below illustrates how fault type "HXXX" or "PXXX" devices are typically wired. The signal to these types of devices originates at the Ground Controls and terminates at system ground.




In order to successfully troubleshoot "HXXX" or "PXXX" type faults, the entire faulted out circuit needs to be investigated.

DIAGNOSTICS


Fault Inspection Procedure

1	Check the device associated with the faulted circuit																
	<ol style="list-style-type: none"> 1. Disconnect the faulted device connector. 2. Using a multi meter, measure resistance between the two terminals of the faulted device. 3. Resistance should be as follows. <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="text-align: left;">Device</th> <th style="text-align: left;">Typical Resistance</th> </tr> </thead> <tbody> <tr> <td>Solenoid Valve, Drive</td> <td>27.2Ω</td> </tr> <tr> <td>Solenoid Valve, Steer</td> <td>19Ω</td> </tr> <tr> <td>Solenoid Valve, Platform Up</td> <td>25Ω</td> </tr> <tr> <td>Solenoid Valve, Platform Down</td> <td>6.25Ω</td> </tr> <tr> <td>GCON and PCON Alarms</td> <td>>1MΩ</td> </tr> <tr> <td>Automotive Horn</td> <td>1.0Ω</td> </tr> <tr> <td>Contacto Coil</td> <td>47Ω</td> </tr> </tbody> </table>	Device	Typical Resistance	Solenoid Valve, Drive	27.2Ω	Solenoid Valve, Steer	19Ω	Solenoid Valve, Platform Up	25Ω	Solenoid Valve, Platform Down	6.25Ω	GCON and PCON Alarms	>1MΩ	Automotive Horn	1.0Ω	Contacto Coil	47Ω
Device	Typical Resistance																
Solenoid Valve, Drive	27.2Ω																
Solenoid Valve, Steer	19Ω																
Solenoid Valve, Platform Up	25Ω																
Solenoid Valve, Platform Down	6.25Ω																
GCON and PCON Alarms	>1MΩ																
Automotive Horn	1.0Ω																
Contacto Coil	47Ω																
OK >	Go to Step 2																
No Good >	Replace faulted device																

2	Check harness between ground controls and faulted device
	<ol style="list-style-type: none"> 1. Disconnect the GCON ECM connectors C1, C2 and C3. (or C4 if equipped with outriggers) 2. Disconnect the faulted device connector. 3. Check the continuity between the GCON ECM connector and the signal side of the faulted device. <ul style="list-style-type: none"> ⊙ Result: Resistance should be close to 0Ω. 4. Check the continuity between the return side of the faulted device and system ground. <ul style="list-style-type: none"> ⊙ Result: Resistance should be close to 0Ω. 5. Check resistance between the return side and the signal side of the harness connector of the faulted device. <ul style="list-style-type: none"> ⊙ Result: Resistance should be 1 MΩ or higher.
OK >	Go to Step 3
No Good >	Replace or repair harness



DIAGNOSTICS

3 Check the GCON ECM

1. Disconnect the GCON ECM connectors C1, C2 and C3. (or C4 if equipped with outriggers)
2. For short to B- type faults, measure resistance between pins C1-7 (ground) and the GCON pin associated with the fault code. Refer to the GCON I/O Map Tables on page 5-4 or 5-5 to identify the faulted circuit pin.
3. Short to ground resistance should be greater than 5kΩ.
4. For short to B+ type faults, measure resistance between pins C1-12 (driver power) and the GCON pin associated with the fault code. Refer to the GCON I/O Map Tables on page 5-4 or 5-5 to identify the faulted circuit pin.
5. Short to power resistance should be greater than 50kΩ.

No
Good → Replace GCON ECM

Type "HXXX" Faults

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
H001	H001:COILFAULT PLAT UP1:Bat-	Short circuit of the platform up #1 circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in platform up #1 harness. • Platform up #1 coil short circuit. • GCON ECM. 	Platform up function inhibited.
H002	H002:COILFAULT PLAT UP1:Open	Open circuit in the platform up #1 circuit.	<ul style="list-style-type: none"> • Open circuit in platform up #1 harness. • Platform up #1 coil open circuit. • GCON ECM. 	Platform up function inhibited.
H003	H003:COILFAULT PLAT UP1:Bat+	Short circuit of the platform up #1 circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in platform up #1 harness. • Platform up #1 coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H009	H009:COILFAULT PLAT DOWN1:Bat+	Short circuit of the platform down #1 circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in platform down #1 harness. • Platform down #1 coil short circuit. • GCON ECM. 	All functions inhibited.
H027	H027:COILFAULT STEER RT:Bat+	Short circuit of the steer right circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in steer right harness. • Steer right coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H030	H030:COILFAULT STEER LT:Bat+	Short circuit of the steer left circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in steer left harness. • Steer left coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H043	H043:COILFAULT BRAKE REL1:Bat-	Short circuit of the brake circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in brake release enable harness. • Brake release relay short circuit. • GCON ECM. 	All functions inhibited except platform down.
H044	H044:COIL FAULT BRAKE REL1:Bat+	Open circuit in the brake coil circuit.	<ul style="list-style-type: none"> • Open circuit in brake release enable harness. • Brake release relay open circuit. • GCON ECM. 	All functions inhibited except platform down.
H045	H045:COILFAULT BRAKE REL1:Bat+	Short circuit of the brake circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in brake release enable harness. • Brake release relay short circuit. • GCON ECM. 	All functions inhibited except platform down.
H049	H049:COILFAULT O/R EXTEND:Bat-	Short circuit of the outrigger extend coil to battery negative.	<ul style="list-style-type: none"> • Short circuit in outrigger extend coil harness. • Outrigger extend coil short circuit. • GCON ECM. 	Only outrigger extend function disabled.
H050	H050:COIL FAULT O/R EXTEND:Open	Open circuit in the outrigger extend coil circuit.	<ul style="list-style-type: none"> • Open circuit in outrigger extend coil harness. • Outrigger extend coil open circuit. • GCON ECM. 	Only outrigger extend function disabled.
H051	H051:COILFAULT O/R EXTEND:Bat+	Short circuit of the outrigger extend coil to battery positive.	<ul style="list-style-type: none"> • Short circuit in outrigger extend coil harness. • Outrigger extend coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H052	H052:COILFAULT O/R RETRACT:Bat-	Short circuit of the outrigger retract coil to battery negative.	<ul style="list-style-type: none"> • Short circuit in outrigger retract coil harness. • Outrigger retract coil short circuit. • GCON ECM. 	Only outrigger retract function disabled.
H053	H053:COILFAULT O/R RET:Open	Open circuit in the outrigger retract coil circuit.	<ul style="list-style-type: none"> • Open circuit in outrigger retract coil harness. • Outrigger retract coil open circuit. • GCON ECM. 	Only outrigger retract function disabled.
H054	H054:COILFAULT O/R RETRACT:Bat+	Short circuit of the outrigger retract coil to battery positive.	<ul style="list-style-type: none"> • Short circuit in outrigger retract coil harness. • Outrigger retract coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H057	H057:COILFAULT LF RIGGER:Bat+	Short circuit of the left front outrigger coil to battery positive.	<ul style="list-style-type: none"> • Short circuit in left front outrigger coil harness. • Left front outrigger coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H060	H060:COILFAULT LR RIGGER:Bat+	Short circuit of the left rear outrigger coil to battery positive.	<ul style="list-style-type: none"> • Short circuit in left rear outrigger coil harness. • Left rear outrigger coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H063	H063:COILFAULT RF RIGGER:Bat+	Short circuit of the right front outrigger coil to battery positive.	<ul style="list-style-type: none"> • Short circuit in right front outrigger coil harness. • Right front outrigger coil short circuit. • GCON ECM. 	All functions inhibited except platform down.
H066	H066:COILFAULT RR RIGGER:Bat+	Short circuit of the right rear outrigger coil to battery positive.	<ul style="list-style-type: none"> • Short circuit in right rear outrigger coil harness. • Right rear outrigger coil short circuit. • GCON ECM. 	All functions inhibited except platform down.

TYPE "HXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
H074	H074:COILFAULT LF RIGGER	Short circuit of the left front outrigger circuit to battery positive/negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in left front outrigger harness. • Left front outrigger coil short or open circuit. • GCON ECM. 	Left front outrigger function inhibited.
H075	H075:COILFAULT LR RIGGER	Short circuit of the left rear outrigger circuit to battery positive/negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in left rear outrigger harness. • Left rear outrigger coil short or open circuit. • GCON ECM. 	Left rear outrigger function inhibited.
H076	H076:COILFAULT RF RIGGER	Short circuit of the right front outrigger circuit to battery positive/negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in right front outrigger harness. • Right front outrigger coil short or open circuit. • GCON ECM. 	Right front outrigger function inhibited.
H077	H077:COILFAULT RR RIGGER	Short circuit of the right rear outrigger circuit to battery positive/negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in right rear outrigger harness. • Right rear outrigger coil short or open circuit. • GCON ECM. 	Right rear outrigger function inhibited.
H078	H078:COILFAULT PLAT DOWN1	Short circuit of the platform down #1 circuit to battery positive/negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in platform down #1 harness. • Platform down #1 coil short or open circuit. • GCON ECM. 	Platform down function inhibited.
H080	H080:COILFAULT STEER LEFT	Short circuit of the steer left circuit to battery negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in steer left harness. • Steer left coil short or open circuit. • GCON ECM. 	Steer left function inhibited.
H081	H081:COILFAULT STEER RIGHT	Short circuit of the steer right circuit to battery negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in steer right harness. • Steer right coil short or open circuit. • GCON ECM. 	Steer right function inhibited.
H082	H082:COILFAULT OSC SUPPLY:Bat-	Short circuit of the oscillate supply circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in oscillate supply harness. • Oscillate supply coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H083	H083:COILFAULT OSC SUPPLY:Open	Open circuit in the oscillate supply circuit.	<ul style="list-style-type: none"> • Open circuit in oscillate supply harness. • Oscillate supply coil open circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H084	H084:COILFAULT OSC SUPPLY:Bat+	Short circuit of the oscillate supply circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in oscillate supply harness. • Oscillate supply coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H085	H085:COILFAULT OSC RIGHT:Bat-	Short circuit of the oscillate right circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in oscillate right harness. • Oscillate right coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.

TYPE "HXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
H086	H086:COILFAULT OSC RIGHT:Open	Open circuit of the oscillate right circuit.	<ul style="list-style-type: none"> • Open circuit in oscillate right harness. • Oscillate right coil open circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H087	H087:COILFAULT OSC RIGHT:Bat+	Short circuit of the oscillate right circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in oscillate right harness. • Oscillate right coil short circuit. • GCON ECM. 	All functions inhibited except platform down as
H088	H088:COILFAULT OSC LEFT:Bat-	Short circuit of the oscillate left circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in oscillate left harness. • Oscillate left coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H089	H089:COILFAULT OSC LEFT:Open	Open circuit of the oscillate left circuit.	<ul style="list-style-type: none"> • Open circuit in oscillate left harness. • Oscillate right coil open circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H090	H090:COILFAULT OSC LEFT:Bat+	Short circuit of the oscillate left circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in oscillate left harness. • Oscillate left coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H091	H091:COILFAULT ACCUM:Bat-	Short circuit of the accumulator circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in accumulator harness. • Accumulator coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H092	H092:COILFAULT ACCUM:Open	Open circuit of the accumulator circuit.	<ul style="list-style-type: none"> • Open circuit in accumulator harness. • Accumulator coil open circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.

TYPE "HXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
H093	H093:COILFAULT ACCUM:Bat+	Short circuit of the accumulator circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in accumulator harness. • Accumulator coil short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
H105	H105:COILFAULT OSC SUPPLY	Short circuit of the oscillate supply circuit to battery negative/positive or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in oscillate supply harness. • Oscillate supply coil short or open circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine
H116	H116:COILFAULT EXTEND/RETRACT	Short circuit of the outrigger supply circuit to battery negative/positive or open circuit.	<ul style="list-style-type: none"> • Short or open circuit in outrigger harness. • Outrigger supply coil short or open circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.

Type "PXXX" Faults

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
P001	P001:PWRFAULT SW PWR:Bat-	Short circuit of the switched power #1 circuit to battery negative.	<ul style="list-style-type: none"> Short circuit in switched power #1, down limit switch or digital tilt switch harness. GCON ECM. 	All functions inhibited.
P003	P003:PWRFAULT SW PWR1:Bat+	Short circuit of the switched power #1 circuit to battery positive.	<ul style="list-style-type: none"> Short circuit in switched power #1, down limit switch or digital tilt switch harness. GCON ECM. 	All functions inhibited.
P004	P004:DEVICEFAULT HORN:Bat-	Short circuit of the automotive horn circuit to battery negative.	<ul style="list-style-type: none"> Short circuit in automotive horn harness. Automotive horn short circuit. GCON ECM. 	Automotive horn inhibited.
P005	P005:DEVICEFAULT HORN:Open	Open circuit of the automotive horn circuit.	<ul style="list-style-type: none"> Open circuit in automotive horn harness. Automotive horn open circuit. GCON ECM. 	Automotive horn inhibited.
P006	P006:DEVICEFAULT HORN:Bat+	Short circuit of the automotive horn circuit to battery positive.	<ul style="list-style-type: none"> Short circuit in automotive horn harness. Automotive horn short circuit. GCON ECM. 	Automotive horn inhibited.
P007	P007:DEVICEFAULT GCON ALARM:Bat-	Short circuit of the GCON alarm circuit to battery negative.	<ul style="list-style-type: none"> Short circuit in GCON alarm harness. GCON alarm short circuit. GCON ECM. 	GCON alarm inhibited.
P009	P009:DEVICEFAULT GCON ALARM:Bat+	Short circuit of the GCON alarm circuit to battery positive.	<ul style="list-style-type: none"> Short circuit in GCON alarm harness. GCON alarm short circuit. GCON ECM. 	GCON alarm inhibited.
P013	P013:PWRFAULT PCON PWRET:Bat-	Short circuit of the PCON power return circuit to battery negative.	<ul style="list-style-type: none"> Short circuit in PCON power return harness. GCON ECM. 	All functions inhibited.
P015	P015:PWRFAULT PCON PWRET:Bat+	Short circuit of the PCON power return circuit to battery positive.	<ul style="list-style-type: none"> Short circuit in PCON power return harness. GCON ECM. 	All functions inhibited.
P018	P018:PWRFAULT PCON POWER:Bat-	Short circuit of the PCON power circuit to battery negative.	<ul style="list-style-type: none"> Short circuit in PCON power harness. GCON ECM. 	All functions inhibited.
P019	P019:PWRFAULT PCON POWER:Bat+	Short circuit of the PCON power circuit to battery positive.	<ul style="list-style-type: none"> Short circuit in PCON power harness. GCON ECM. 	All functions inhibited.
P023	P023:PUMP MOTOR VOLTAGE NOT OK	Pump motor voltage out of range.	<ul style="list-style-type: none"> Pump voltage to low. Pump voltage to high. Right rear DCON ECM. 	All functions inhibited.
P024	P024:PUMP MOTOR NOT STILL	Pump motor voltage not still at start up.	<ul style="list-style-type: none"> Short circuit in pump motor #1 harness to battery negative. Right rear DCON ECM. 	All functions inhibited.
P025	P025:PUMP MOTOR CURRENT FEEDBK	Open or short circuit of the P-circuit from the right rear drive controller to the pump motor.	<ul style="list-style-type: none"> Open or short circuit in pump motor P- cable. Faulty pump. Right rear DCON ECM. 	All functions inhibited.
P026	P026:MOTOR RR VOLTAGE NOT OK	Open or short circuit of the U or W circuit from the right rear drive controller to the right rear drive motor.	<ul style="list-style-type: none"> Open circuit in right rear drive motor U or W cable. Right rear drive motor. Right rear DCON ECM. 	All functions inhibited.
P027	P027:MOTOR LR VOLTAGE NOT OK	Open or short circuit of the U or W circuit from the left rear drive controller to the left rear drive motor.	<ul style="list-style-type: none"> Open circuit in left rear drive motor U or W cable. Left rear drive motor. Left rear DCON ECM. 	All functions inhibited.
P028	P028:CONTACTOR STUCK CLOSED	Main contactor (PR1) stuck in the closed position.	<ul style="list-style-type: none"> Short circuit in main contactor harness. Faulty contactor. Right rear DCON ECM. 	All functions inhibited.
P029	P029:CONTACTOR DOES NOT CLOSE	Main contactor (PR1) stuck in the open position.	<ul style="list-style-type: none"> Open circuit in main contactor harness. Faulty contactor. Right rear DCON ECM. 	All functions inhibited.
P030	P030:COILFAULT LC RR:Open	Short circuit of the main contactor (PR1) coil to battery negative or open circuit.	<ul style="list-style-type: none"> Short or open circuit in main contactor harness. Faulty contactor. Right rear DCON ECM. 	All functions inhibited.
P031	P031:COILFAULT BRAKE/LC RR:Bat+	Short or open circuit of the right rear brake coil circuit.	<ul style="list-style-type: none"> Short or open circuit in right rear brake harness. Short or open circuit in right rear brake coil. Right rear DCON ECM. 	All functions inhibited.

TYPE "PXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
P032	P032:COILFAULT BRAKE/LC LR:Bat+	Short or open circuit of the left rear brake coil circuit.	<ul style="list-style-type: none"> • Short or open circuit in left rear brake harness. • Short or open circuit in left rear brake coil. • Left rear DCON ECM. 	All functions inhibited.
P033	P033:COILFAULT BRAKE RR:Short	Short circuit of the right rear brake coil circuit (B1) to battery positive/negative. Brake circuit miswired.	<ul style="list-style-type: none"> • Short circuit in right rear brake harness. • Short circuit in right rear brake coil. • Right rear brake harness miswired. • Right rear DCON ECM. 	All functions inhibited.
P034	P034:COILFAULT BRAKE LR:Short	Short circuit of the left rear brake coil circuit (B1) to battery positive/negative. Brake circuit miswired.	<ul style="list-style-type: none"> • Short circuit in left rear brake harness. • Short circuit in left rear brake coil. • Left rear brake harness miswired. • Left rear DCON ECM. 	All functions inhibited.
P035	P035:COILFAULT BRAKE RR:Bat-	Short circuit of the right rear brake coil circuit (B5) to battery negative. Brake circuit miswired.	<ul style="list-style-type: none"> • Short circuit in right rear brake harness. • Short circuit in right rear brake coil. • Right rear brake harness miswired. • Right rear DCON ECM. 	All functions inhibited.
P036	P036:COILFAULT BRAKE LR:Bat-	Short circuit of the left rear brake coil circuit (B5) to battery negative. Brake circuit miswired.	<ul style="list-style-type: none"> • Short circuit in left rear brake harness. • Short circuit in left rear brake coil. • Left rear brake harness miswired. • Left rear DCON ECM. 	All functions inhibited.
P037	P037:BATTERY OUT OF RANGE	Battery voltage is out of range at startup.	<ul style="list-style-type: none"> • Short or open circuit in voltage sensor circuits. • Low batteries. • Faulty battery. • Battery charger connected to AC power source. • Left or right DCON ECM. 	All functions inhibited.
P038	P038:DEVICEFAULT BAT BALANCER	Battery pack out of balance.	<ul style="list-style-type: none"> • Short or open circuit in voltage sensor circuits. • Faulty battery balancer. • Faulty battery. • Battery terminal corrosion. • Loose battery terminal. • GCON ECM. 	All functions operate.
P039	P039:DEVICEFAULT BRAKE PWR RELAY	Short or open circuit of the brake relay contact or coil.	<ul style="list-style-type: none"> • Short or open circuit in brake relay harness. • Brake relay contact stuck closed. • Faulty brake relay. • GCON ECM. 	All functions inhibited.
P040	P040:COILFAULT BRAKE PWR OPEN	Short or open circuit of the brake relay contact or coil to battery negative.	<ul style="list-style-type: none"> • Short or open circuit in brake relay harness. • Faulty brake relay. • Left or right DCON ECM. • GCON ECM. 	All functions inhibited.

Type "UXXX" Faults

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
U001	U001:SWITCHFAULT GCON MAIN FTN EN	Short circuit of the GCON main function enable switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON main function enable switch. • GCON ECM. 	All GCON functions inhibited.
U002	U002:SWITCHFAULT GCON PLAT UP	Short circuit of the GCON up directional switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON up directional switch. • GCON ECM. 	All GCON functions inhibited except platform down.
U003	U003:SWITCHFAULT GCON PLAT DOWN	Short circuit of the GCON down directional switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON down directional switch. • GCON ECM. 	All GCON functions inhibited except platform up.
U004	U004:SWITCHFAULT GCON LCD UP	Short circuit of the GCON LCD scroll up switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON LCD scroll up switch. • GCON ECM. 	All GCON LCD menu functions inhibited.
U005	U005:SWITCHFAULT GCON LCD DOWN	Short circuit of the GCON LCD scroll down switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON LCD scroll down switch. • GCON ECM. 	All GCON LCD menu functions inhibited.
U006	U006:SWITCHFAULT GCON LCD ENTER	Short circuit of the GCON LCD enter switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON LCD enter switch. • GCON ECM. 	All GCON LCD menu functions inhibited.
U007	U007:SWITCHFAULT GCON LCD ESCAPE	Short circuit of the GCON LCD escape switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the GCON LCD escape switch. • GCON ECM. 	All GCON LCD menu functions inhibited.
U014	U014:SWITCHFAULT PCON DRIVE EN	Short circuit of the PCON drive enable switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON drive enable switch. • GCON ECM. 	All PCON drive and steer functions inhibited.
U015	U015:SWITCHFAULT PCON STEER LEFT	Short circuit of the PCON steer left switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON steer left switch. • GCON ECM. 	All PCON drive and steer functions inhibited.
U016	U016:SWITCHFAULT PCON STEER RIGHT	Short circuit of the PCON steer right switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON steer right switch. • GCON ECM. 	All PCON drive and steer functions inhibited.
U017	U017:SWITCHFAULT PCON HORN	Short circuit of the PCON horn switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON horn switch. • GCON ECM. 	PCON horn switch function inhibited.
U018	U018:SWITCH FAULT PCON LO DRIVE SPD	Short circuit of the PCON low drive speed switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON low drive speed switch. • GCON ECM. 	The machine is limited to low drive speed.
U019	U019:SWITCHFAULT PCON LO LIFT SPD	Short circuit of the PCON low lift speed switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON low lift speed switch. • GCON ECM. 	PCON platform up & down functions inhibited.
U020	U020:SWITCHFAULT PCON HI LIFT SPD	Short circuit of the PCON high lift speed switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON high lift speed switch. • GCON ECM. 	PCON platform up & down functions inhibited.
U021	U021:SWITCHFAULT PCON UP	Short circuit of the PCON up directional switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON up directional switch. • GCON ECM. 	PCON platform up function inhibited.
U022	U022:SWITCHFAULT PCON DOWN	Short circuit of the PCON down directional switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON down directional switch. • GCON ECM. 	PCON platform down function inhibited.
U023	U023:SWITCHFAULT PCON O/R ENABLE	Short circuit of the PCON outrigger enable switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON outrigger enable switch. • GCON ECM. 	All outrigger functions inhibited.

TYPE "UXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
U033	U033:JSTICKFAULT OUT OF CAL RANGE	PCON drive joystick signal is outside acceptable calibration range at system startup.	<ul style="list-style-type: none"> • PCON drive joystick is not in neutral position at startup. • PCON joystick. • GCON ECM. 	All PCON drive and steer functions inhibited.
U034	U034:JSTICKFAULT OUT OF RANGE:HI	Short circuit of the PCON drive joystick signal to battery positive at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON drive joystick signal circuit. • PCON joystick. • GCON ECM. 	All PCON drive and steer functions inhibited.
U035	U035:JSTICKFAULT OUT OF RANGE:LO	Short circuit of the PCON drive joystick signal to battery negative at system startup.	<ul style="list-style-type: none"> • Short circuit of the PCON drive joystick signal circuit. • PCON joystick. • GCON ECM. 	All PCON drive and steer functions inhibited.
U036	U036:SWITCHFAULT GCON + PCON:ON	Mis-wiring or short circuit of GCON keyswitch.	<ul style="list-style-type: none"> • Short circuit of the GCON keyswitch harness. • GCON key switch. • GCON ECM. 	All functions inhibited.
U037	U037:SWITCHFAULT FOOTSW PRESSED	Footswitch or Enable switch depressed at startup.	<ul style="list-style-type: none"> • Enable switch activated at startup. • Enable switch contact stuck closed. • PCON ECM 	All PCON drive and steer functions inhibited.
U038	U038:SWITCHFAULT FOOTSWITCH:Bat+	Short circuit of the PCON power circuit to enable switch to battery positive.	<ul style="list-style-type: none"> • Short circuit in PCON power harness. • Enable switch shorted to battery positive. • PCON ECM 	All PCON drive and steer functions inhibited.
U039	U039:SWITCHFAULT FOOTSW:Open/Bat-	Open or short circuit of the PCON power circuit to enable switch to battery negative.	<ul style="list-style-type: none"> • Open or short circuit in PCON power harness. • Enable switch shorted to battery negative. • PCON ECM 	All PCON drive and steer functions inhibited.
U040	U040:SWITCHFAULT FOOTSW:Timeout	Enable switch held closed with no activity.	<ul style="list-style-type: none"> • Enable switch held closed. • Enable switch contact stuck closed. • PCON ECM 	All PCON drive and steer functions inhibited.

Type "FXXX" Faults

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
F001	F001:SWITCHFAULT UP LIMIT1:BAT+	Short circuit of the up limit #1 switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the up limit switch circuit. • Up limit #1 switch short circuit. • GCON ECM. 	All functions inhibited except platform down.
F003	F003:SWITCHFAULT DOWN LIMIT1:BAT+	Short circuit of the down limit #1 switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the down limit switch circuit. • Down limit #1 switch short circuit. • GCON ECM. 	All functions inhibited except platform down.
F007	F007:SWITCHFAULT CHASSISTILT:BAT+	Short circuit of the chassis digital tilt switch at system startup.	<ul style="list-style-type: none"> • Short circuit of the chassis digital tilt switch circuit. • Chassis digital tilt switch short circuit. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F012	F012:SENSORFAULT LEVEL PITCH:BAT+	Short circuit of the Level Pitch Sensor circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in the level pitch sensor circuit. • Faulty level sensor. • GCON ECM. 	All functions inhibited.
F013	F013:SENSORFAULT LEVEL PITCH:BAT-	Short circuit of the Level Pitch Sensor circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in the level pitch sensor circuit. • Faulty level sensor. • GCON ECM. 	All functions inhibited.
F014	F014:SENSORFAULT LEVEL ROLL:BAT+	Short circuit of the Level Roll Sensor circuit to battery positive.	<ul style="list-style-type: none"> • Short circuit in the level roll sensor circuit. • Faulty level sensor. • GCON ECM. 	All functions inhibited.
F015	F015:SWITCHFAULT LEVEL ROLL:Bat+	Short circuit of the Level Roll Sensor circuit to battery negative.	<ul style="list-style-type: none"> • Short circuit in the level roll sensor circuit. • Faulty level sensor. • GCON ECM. 	All functions inhibited.
F032	F032:SWITCHFAULT OVLD SWITCH:Bat+	Short circuit of pressure switch to battery positive.	<ul style="list-style-type: none"> • Short circuit in the limit switch harness. • GCON ECM. 	All functions inhibited.
F033	F033:SWITCHFAULT OVLD:Open/Bat-	Open or short circuit of pressure switch.	<ul style="list-style-type: none"> • Open or short circuit in the limit switch harness. • GCON ECM. 	All functions inhibited.
F037	F037:SWITCHFAULT LF RIGGER:BAT+	Short circuit of the left front outrigger limit switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the left front outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Left front outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F038	F038:SWITCHFAULT LF RIGGER:BAT-	Short circuit of the left front outrigger limit switch to battery negative.	<ul style="list-style-type: none"> • Short circuit of the left front outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Left front outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F039	F039:SWITCHFAULT RF RIGGER:BAT+	Short circuit of the right front outrigger limit switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the right front outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Right front outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F040	F040:SWITCHFAULT RF RIGGER:BAT-	Short circuit of the right front outrigger limit switch to battery negative.	<ul style="list-style-type: none"> • Short circuit of the right front outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Right front outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.

TYPE "FXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
F041	F041:SWITCHFAULT LR RIGGER:BAT+	Short circuit of the left rear outrigger limit switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the left rear outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Left rear outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F042	F042:SWITCHFAULT LR RIGGER:BAT-	Short circuit of the left rear outrigger limit switch to battery negative.	<ul style="list-style-type: none"> • Short circuit of the left rear outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Left rear outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F043	F043:SWITCHFAULT RR RIGGER:BAT+	Short circuit of the right rear outrigger limit switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the right rear outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Right rear outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F044	F044:SWITCHFAULT RR RIGGER:BAT-	Short circuit of the right rear outrigger limit switch to battery negative.	<ul style="list-style-type: none"> • Short circuit of the right rear outrigger limit switch. • Short circuit in outrigger harness. • GCON ECM. 	Right rear outrigger inhibited if outrigger extend is activated. Outrigger can still be retracted.
F045	F045:SWITCHFAULT LEFT AXLE:BAT+	Short circuit of the left axle operational limit switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the left axle operational limit switch. • Short circuit in axle limit switch harness. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F046	F046:SWITCHFAULT LEFT AXLE:BAT-	Short circuit of the left axle operational limit switch to battery negative.	<ul style="list-style-type: none"> • Short circuit of the left axle operational limit switch. • Short circuit in axle limit switch harness. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F047	F047:SWITCHFAULT RIGHT AXLE:BAT+	Short circuit of the right axle operational limit switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the right axle operational limit switch. • Short circuit in axle limit switch harness. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.

TYPE "FXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
F048	F048:SWITCHFAULT RIGHT AXLE:BAT-	Short circuit of the right axle operational limit switch to battery negative.	<ul style="list-style-type: none"> • Short circuit of the right axle operational limit switch. • Short circuit in axle limit switch harness. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F049	F049:SENSORFAULT PUMP SPEED:BAT+	Short circuit of the pump speed sensor to battery positive.	<ul style="list-style-type: none"> • Short circuit of the pump speed sensor. • Short circuit in pump speed sensor harness. • GCON ECM. 	All functions operate.
F050	F050:SENSORFAULT PUMP:OPEN/BAT-	Short circuit of the pump speed sensor to battery negative or open circuit.	<ul style="list-style-type: none"> • Short or open circuit of the pump speed sensor. • Short or open circuit in pump speed sensor harness. • GCON ECM. 	All functions operate.
F051	F051:SWITCHFAULT ACC PRESS:BAT+	Short circuit of the accumulator pressure switch to battery positive.	<ul style="list-style-type: none"> • Short circuit of the accumulator pressure switch. • Short circuit in function manifold harness. • GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F052	F052:SWITCHFAULT ACC PRESS:BAT-	Short circuit of the accumulator pressure switch to battery	<ul style="list-style-type: none"> • Short circuit of the accumulator pressure switch. • Short circuit in function manifold harness. 	All functions inhibited except
F053	F053:DCON RR ECM THERM PROTECTION	Right rear drive controller, thermal protection senses that temperature has exceeded 185° F / 85° C.	<ul style="list-style-type: none"> • Excessive heat. • Faulty thermal sensor in right rear drive controller. • Right rear DCON ECM. 	Drive speed reduces from 185° F / 85° C to 221° F / 105° C. Drive inhibited at 221° F / 105° C.
F054	F054:DCON LR ECM THERM PROTECTION	Left rear drive controller, thermal protection senses that temperature has exceeded 185° F / 85° C.	<ul style="list-style-type: none"> • Excessive heat. • Faulty thermal sensor in left rear drive controller. • Left rear DCON ECM. 	Drive speed reduces from 185° F / 85° C to 221° F / 105° C. Drive inhibited at 221° F / 105° C.
F055	F055:MOTOR RR THERM PROTECTION	Right rear drive motor thermal protection senses that temperature has exceeded 185° F / 85° C.	<ul style="list-style-type: none"> • Excessive heat. • Short or open circuit of the drive motor encoder. • Faulty thermal sensor in right rear drive controller. • Right rear DCON ECM. 	Drive functions inhibited.
F056	F056:MOTOR LR THERM PROTECTION	Left rear drive motor thermal protection senses that temperature has exceeded 185° F / 85° C.	<ul style="list-style-type: none"> • Excessive heat. • Short or open circuit of the drive motor encoder. • Faulty thermal sensor in left rear drive controller. • Left rear DCON ECM. 	Drive functions inhibited.

TYPE "FXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
F057	F057:MOTOR RR ENCODER FAULT	Return signal from the right rear drive motor encoder to the right rear drive controller is 40 Hz or higher.	<ul style="list-style-type: none"> • Short or open circuit of the drive motor encoder. • Faulty encoder in right rear drive motor. • Faulty right rear drive motor. • Right rear DCON ECM. 	All functions inhibited.
F058	F058:MOTOR LR ENCODER FAULT	Return signal from the left rear drive motor encoder to the left rear drive controller is 40 Hz or higher.	<ul style="list-style-type: none"> • Short or open circuit of the drive motor encoder. • Faulty encoder in left rear drive motor. • Faulty left rear drive motor. • Left rear DCON ECM. 	All functions inhibited.
F059	F059:MOTOR RR STALL/ENCODER	Right rear drive motors rotor is stuck or the return signal from the encoder is incorrect.	<ul style="list-style-type: none"> • Right rear drive motor not turning. • Short or open circuit of the drive motor encoder. • Faulty encoder in right rear drive motor. • Faulty right rear drive motor. • Right rear DCON ECM. 	Drive functions inhibited.
F060	F060:MOTOR LR STALL/ENCODER	Left rear drive motors rotor is stuck or the return signal from the encoder is incorrect.	<ul style="list-style-type: none"> • Left rear drive motor not turning. • Short or open circuit of the drive motor encoder. • Faulty encoder in left rear drive motor. • Faulty left rear drive motor. • Left rear DCON ECM. 	Drive functions inhibited.
F061	F061:MOTOR RR THERMAL SENSOR	Open circuit of the right rear drive motor thermal sensor to right rear drive controller (D3) or faulty thermal sensor.	<ul style="list-style-type: none"> • Open circuit in right rear drive motor harness. • Faulty thermal sensor in right rear drive motor. • Right rear DCON ECM. 	Drive performance reduced.
F062	F062:MOTOR LR THERMAL SENSOR	Open circuit of the left rear drive motor thermal sensor to left rear drive controller (D3) or faulty thermal sensor.	<ul style="list-style-type: none"> • Open circuit in left rear drive motor harness. • Faulty thermal sensor in left rear drive motor. • Left rear DCON ECM. 	Drive performance reduced.
F063	F063:SENSORFAULT STEER ANG:RANGE	Steer angle sensor out of range.	<ul style="list-style-type: none"> • Short or open circuit of the steer angle sensor. • Short or open circuit of the steer angle sensor harness. • Steer angle sensor needs to be calibrated. • Faulty steer angle sensor. • Right rear DCON ECM. 	Drive performance reduced.
F064	F064:SWITCHFAULT LEFT AXLE:MISM	Left axle safety limit switch state not matching the left axle operational limit switch state.	<ul style="list-style-type: none"> • Short or open circuit of the left axle safety and/or operational limit switches. • Short or open circuit of the left axle safety and/or operational limit switch harnesses. • Faulty left axle safety and/or operational limit switch. • Right rear DCON or GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F065	F064:SWITCHFAULT RIGHT AXLE:MISM	Right axle safety limit switch state not matching the right axle operational limit switch state.	<ul style="list-style-type: none"> • Short or open circuit of the right axle safety and/or operational limit switches. • Short or open circuit of the right axle safety and/or operational limit switch harnesses. • Faulty right axle safety and/or operational limit switch. • Right rear DCON or GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.

TYPE "FXXX" FAULTS, CONTINUED


DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
F066	F066:MOTOR RR TORQUE TOO LOW	Right rear drive motor torque too low.	<ul style="list-style-type: none"> • Short circuit of the speed sensor harness. • Faulty speed sensor. • Faulty right drive motor. • Right rear DCON ECM. 	Drive performance reduced.
F067	F067:MOTOR RR TORQUE TOO LOW	Left rear drive motor torque too low.	<ul style="list-style-type: none"> • Short circuit of the speed sensor harness. • Faulty speed sensor. • Faulty left drive motor. • Left rear DCON ECM. 	Drive performance reduced.
F068	F068:OSCILLATE TIMEOUT	Oscillate axle safety or operational limit switches failed to close within 4 seconds after opening.	<ul style="list-style-type: none"> • Open circuit of a safety or operational limit switch. • Open circuit in safety or operational limit switch harness. • Faulty safety or operational limit switch. • Right rear DCON or GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F069	F069:SWITCHFAULT OSC LIM SWITCHES	Right and left axle safety or operational limit switches are in an open state.	<ul style="list-style-type: none"> • Open circuit of the right and/or left axle safety or operational limit switches. • Open circuit of the right and/or left axle safety or operational limit switch harnesses. • Right rear DCON or GCON ECM. 	All functions inhibited except platform down as long as machine is in the elevated position. If machine is in stowed position, all functionality is resumed.
F070	F070:SWITCHFAULT DOWN LIMIT:MISM	Platform down safety and operational limit switches are not in the same state.	<ul style="list-style-type: none"> • Open or short circuit of the platform down safety and/or operational limit switches. • Open or short circuit of the platform down safety and/or operational limit switch harness. • Faulty safety and/or operational limit switch. • Right rear DCON or GCON ECM. 	All functions inhibited.
F071	F071:MOTOR THERM PROTECTION	Drive motor(s) thermal sensor has exceeded 185° / 85° C. 185°F / 85° C.	<ul style="list-style-type: none"> • One or both drive motors over heated. • Faulty thermal sensor in rear drive motor. • Faulty rear drive motor. • Left or right rear DCON or GCON ECM. 	All drive and steer functions inhibited.

Type "CXXX" Faults

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
C001	C001:GCON ECM FAULT TYPE 1	GCON ECM CRC check error.	<ul style="list-style-type: none"> • Incorrect software file. • GCON ECM internal failure. 	All functions inhibited.
C004	C004:GCON ECM FAULT TYPE 4	GCON ECM master switch error.	<ul style="list-style-type: none"> • Short circuit in the master switch circuit. • GCON ECM. 	All functions inhibited.
C005	C005:GCON ECM FAULT TYPE 5	GCON ECM safety switch error.	<ul style="list-style-type: none"> • Short circuit in the safety switch circuit. • GCON ECM. 	All functions inhibited.
C006	C006:GCON ECM FAULT TYPE 6	GCON input redundancy error.	<ul style="list-style-type: none"> • Input conditioning circuit failure. • GCON ECM. 	All functions inhibited.
C007	C007:GCON ECM FAULT TYPE 7	GCON ECM inter-processor.	<ul style="list-style-type: none"> • Incorrectly programmed device. • Error in loading software on device. • GCON ECM. 	All functions inhibited.
C021	C021:PCON NOT DETECTED	Communication failure between GCON and PCON.	<ul style="list-style-type: none"> • CAN communication failure. • CAN communication harness. • PCON unplugged. • GCON or PCON ECM. 	All functions inhibited.
C023	C023:MACHINE MODEL FAULT	Discrepancy between model detected and model programmed.	<ul style="list-style-type: none"> • Incorrect machine model programmed. • GCON or PCON ECM. 	All functions inhibited.
C024	C024:PARAMETER PROGRAM FAULT	Invalid machine parameters.	<ul style="list-style-type: none"> • Incorrect machine parameter programmed. • GCON or PCON ECM. 	All functions inhibited.
C025	C025:SYSTEMFAULT PLAT OVLD:NOCAL	Platform overload system not calibrated.	<ul style="list-style-type: none"> • Platform overload system not calibrated. • GCON or PCON ECM. 	All functions inhibited.
C028	C028:SERVICE OVERRIDE MODE ON	Machine is in service override mode.	<ul style="list-style-type: none"> • Machine programmed for use in service override mode. 	All functions inhibited except for down function and up function. Platform can be elevated only once, with the maximum elevate time of X seconds. Elevate time X, depends on machine model.
C030	C030:DCON RR ECM FAULT TYPE 01	Hardware failure of the right rear drive controller.	<ul style="list-style-type: none"> • Right rear DCON. 	Performance reduced or all functions inhibited.
C031	C031:DCON LR ECM FAULT TYPE 01	Hardware failure of the left rear drive controller.	<ul style="list-style-type: none"> • Left rear DCON. 	Performance reduced or all functions inhibited.
C032	C032:DCON RR ECM FAULT TYPE 02	Setup initialization failure of the right rear drive controller at system startup.	<ul style="list-style-type: none"> • Drive input active at system startup. • Faulty drive joystick. • Incorrect software. • Right rear DCON. 	Performance reduced or drive inhibited or all functions inhibited.
C033	C033:DCON LR ECM FAULT TYPE 02	Setup initialization failure of the left rear drive controller at system startup.	<ul style="list-style-type: none"> • Drive input active at system startup. • Faulty drive joystick. • Incorrect software. • Left rear DCON. 	Performance reduced or drive inhibited or all functions inhibited.
C034	C034:DCON RR ECM FAULT TYPE 03	Valve driver failure of the right rear drive controller.	<ul style="list-style-type: none"> • Right rear DCON. 	Drive functions inhibited.
C035	C034:DCON LR ECM FAULT TYPE 03	Valve driver failure of the left rear drive controller.	<ul style="list-style-type: none"> • Left rear DCON. 	Drive functions inhibited.
C036	C036:DCON RR ECM FAULT TYPE 04	Right rear drive controller voltage out of range.	<ul style="list-style-type: none"> • Battery charger connected. • Batteries to low. • Right rear DCON. 	All functions inhibited.
C037	C037:DCON LR ECM FAULT TYPE 04	Left rear drive controller voltage out of range.	<ul style="list-style-type: none"> • Battery charger connected. • Batteries to low. • Left rear DCON. 	All functions inhibited.

TYPE "CXXX" FAULTS, CONTINUED

DTC Number	Message on GCON LCD	ProblemDescription	Possible Causes	Failure Mode
C038	C038:DCON RR ECM FAULT TYPE 05	Capacitor charge failure of the right rear drive controller.	<ul style="list-style-type: none"> • Open on B+ or B- to the right rear drive controller. • Right rear DCON. 	All functions inhibited.
C039	C039:DCON LR ECM FAULT TYPE 05	Capacitor charge failure of the left rear drive controller.	<ul style="list-style-type: none"> • Open on B+ or B- to the left rear drive controller. • Left rear DCON. 	All functions inhibited.
C040	C040:DCON RR ECM FAULT TYPE 06	Open circuit to the PEV (B2) circuit of the right rear drive controller,	<ul style="list-style-type: none"> • Open circuit of the right rear motor controller harness. • Keyswitch relay CR61 not closed. • Right rear DCON or GCON ECM. 	All functions inhibited.
C041	C041:DCON LR ECM FAULT TYPE 06	Open circuit to the PEV (B2) circuit of the left rear drive controller.	<ul style="list-style-type: none"> • Open circuit of the left rear motor controller harness. • Keyswitch relay CR61 not closed. • Left rear DCON or GCON ECM. 	All functions inhibited.
C042	C042:DCON RR ECM FAULT TYPE 07	Open circuit of the keyswitch circuit or battery positive / negative of the right rear drive controller.	<ul style="list-style-type: none"> • Open circuit of the right rear motor controller harness. • Open circuit to B+ and/or B-. • Keyswitch relay CR61 not closed. • Right rear DCON or GCON ECM. 	All functions inhibited.
C043	C043:DCON LR ECM FAULT TYPE 07	Open circuit to the keyswitch circuit or battery positive / negative of the right rear drive controller.	<ul style="list-style-type: none"> • Open circuit of the left rear motor controller harness. • Open circuit to B+ and/or B-. • Keyswitch relay CR61 not closed. • Left rear DCON or GCON ECM. 	All functions inhibited.
C044	C044:DCON RR ECM FAULT TYPE 08	Communication error of the CAN circuit between the GCON and the right rear motor controller.	<ul style="list-style-type: none"> • Open circuit of the right rear motor controller harness. • Right rear DCON or GCON ECM. 	All functions inhibited.
C045	C045:DCON LR ECM FAULT TYPE 08	Communication error of the CAN circuit between the GCON and the left rear motor controller.	<ul style="list-style-type: none"> • Open circuit of the left rear motor controller harness. • Left rear DCON or GCON ECM. 	All functions inhibited.
C046	C046:DCON RR ECM FAULT TYPE 09	Communication error of the CAN circuit between the GCON and the right rear motor controller.	<ul style="list-style-type: none"> • Open or short circuit of the right rear motor controller harness. • Right rear DCON or GCON ECM. 	All functions inhibited.
C047	C045:DCON LR ECM FAULT TYPE 09	Communication error of the CAN circuit between the GCON and the left rear motor controller.	<ul style="list-style-type: none"> • Open or short circuit of the left rear motor controller harness. • Left rear DCON or GCON ECM. 	All functions inhibited.
C048	C048:DCON RR ECM FAULT TYPE 10	Output error of the thermal sensor circuit of the right rear motor controller.	<ul style="list-style-type: none"> • Right rear DCON ECM. 	Performance reduced.
C049	C049:DCON LR ECM FAULT TYPE 10	Output error of the thermal sensor circuit of the left rear motor controller.	<ul style="list-style-type: none"> • Left rear DCON ECM. 	Performance reduced.



This page intentionally left blank.

Schematics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.

About This Section

There are two groups of schematics in this section.


Electrical Schematics

⚠WARNING Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Hydraulic Schematics

⚠WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

General Repair Process



Electrical Schematic Abbreviations, Wire Colors and Hydraulic Component Legends

ELECTRICAL SCHEMATIC LEGEND	
Item	Description
B	Battery B7 = 48V DC Battery pack
BN	Button BN1 = High speed function enable (platform) BN2 = Platform up / Outrigger retract (platform) BN3 = Low speed function enable (platform) BN4 = Platform down / Outrigger extend (platform) BN5 = Horn (platform) BN6 = Outrigger enable (option) (platform)
CB	Circuit breaker CB2 = 7 amp (controls) CB7 = 15 amp (power)
CR	Control relay CR60 = Brake release CR61 = Key switch
CT	Contact type (limit switch) N.O. = Normally open N.C. = Normally closed N.O.H.C. = Normally open, held closed N.C.H.O. = Normally closed, held open
F	Fuse F9 = 50 amp (800W inverter option) F27 = 30 amp (48V DC battery charger) F28 = 5 amp (24V DC battery balancer) F29 = 5 amp (48V DC battery balancer)
FB	Flashing beacon FB1 = Option
H	Horn or alarm H2 = Horn H5 = Multi-function alarm (ground) H8 = Alarm (platform)
JC	Hall effect controller JC3 = Drive / Steer
KS	Key switch KS1 = Key switch
L	LED or Light L12 = Left front outrigger (option) (platform) L13 = Right front outrigger (option) (platform) L14 = Left rear outrigger (option) (platform) L15 = Right rear outrigger (option) (platform)
LS	Limit switch LS6 = Platform down operational LS6B = Platform down safety LS12 = Left front outrigger (option) LS13 = Right front outrigger (option) LS14 = Left rear outrigger (option) LS15 = Right rear outrigger (option) LS20 = Platform full height (CE models) LSA1OS = Left axle oscillate (operational) LSA2OS = Right axle oscillate (operational) LSA1OSS = Left axle oscillate (safety) LSA2OSS = Right axle oscillate (safety)
M	Motor or Pump M5 = Lift pump
P	Red emergency stop button P1 = Ground controls P2 = Platform controls
PS	Pressure switch PS5 = Accumulator
PR	Solenoid relay PR1 = Primary contactor
R	Resistor R1 = 2k ohm


































ELECTRICAL SCHEMATIC LEGEND	
Item	Description
S	Sensor S7 = Digital level sensor (w/o outriggers) S8 = Analog level sensor (w/ outrigger option) S13 = Steer angle sensor S14 = Height angle sensor (Plat. overload option) S25 = Pressure switch (Plat. overload option) S26 = Lift pump speed sensor
TB	Terminal base (Ground controls terminal strip)
TS	Toggle switch TS10 = Auxiliary down (ground) TS51 = Auxiliary down enable (ground)
U	Electronic Component U1 = GCON (ground) U2 = PCON (platform) U3A = Right DCON U3B = Left DCON U4 = Battery charger U6 = 800W inverter (option)
Y	Valve coil Y3 = Steer right / CW Y4 = Steer left / CCW Y5 = Drive reverse Y7 = Platform down Y7A = Platform down (GS-4069 models) Y8 = Platform up Y10 = Auxiliary platform down Y10A = Auxiliary platform down (GS-4069 models) Y33 = Left rear outrigger (option) Y34 = Right rear outrigger (option) Y35 = Left front outrigger (option) Y36 = Right front outrigger (option) Y39 = Outrigger retract (option) Y40 = Outrigger extend (option) Y93 = Oscillate left Y94 = Oscillate right Y99 = Accumulator Y100 = Oscillate supply

Electrical Schematic Abbreviations, Wire Color and Hydraulic Component Legends, continued


WIRE COLOR LEGEND	
Item	Description
BL	Blue
BK	Black
BR	Brown
GR	Green
OR	Orange
PP	Purple
RD	Red
WH	White
YL	Yellow
BL/RD	Blue/Red
BL/WH	Blue/White
BK/RD	Black/Red
OR/WH	Orange/White
RD/BK	Red/Black
RD/WH	Red/White
WH/BL	White Blue
WH/BK	White/Black
WH/RD	White/Red
WH/YL	White/Yellow
YL/BK	Yellow/Black

HYDRAULIC COMPONENT LEGEND	
Item	Function
BA	3 position, 4 way directional valve - outrigger cylinders extend/retract (option)
CA	2 position, 2 way valve - platform down (all models)
CB	2 position, 2 way valve - platform down (GS-4069)
CC	2 position, 2 way valve - LR outrigger (option)
CD	2 position, 2 way valve - RR outrigger (option)
CE	2 position, 2 way valve - LF outrigger (option)
CF	2 position, 2 way valve - RF outrigger (option)
FA	Check valve - blocks flow to tank - oscillate circuit
FB	Relief valve - Platform up circuit accumulator supply
FC	Orifice - accumulator circuit
FD	Relief valve - Platform up circuit
FE	Accumulator
FF	2 position, 2 way valve - oscillate supply
FG	Flow regulator valve - controls flow to the oscillate
FH	Relief valve - main system
FI	Relief valve - steer circuit
FJ	Check valve - load sense circuit
FK	Flow regulator valve - controls flow to the steer circuit
FL	3 position, 5 way valve - steer right / left
FM	Check valve - load sense circuit
FN	Pressure switch
FO	2 position, 3 way valve - platform up
FP	2 position, 3 way valve - oscillate left
FQ	Relief valve - oscillate circuit
FR	2 position, 3 way valve - oscillate right


Electrical Symbols Legend



Hydraulic Symbols Legend




Limit Switch Legend





- a left rear outrigger limit switch, LS14
- b right rear outrigger limit switch, LS15
- c right front outrigger limit switch, LS13
- left front outrigger limit switch, LS12 (not shown)
- d left axle oscillate limit switches, LSA10S and LSA10SS
- e right axle oscillate limit switches, LSA20S and LSA20SS
- f platform overload pressure switch, S25
- g platform down limit switches, LS6 and LS6B
- h platform up limit switch, LS16

Fuse B

M L K J I H G F E D C






LABEL	DESCRIPTION
B7	BATTERY PACK
F8	FUSE, 325A
F27	FUSE, 40A
F28	FUSE, 10A
F29	FUSE, 10A
PR1	PRIMARY CONTACTOR
U5	BATTERY BALANCER
U6	INVERTER, 800W (OPTION)






C D E F G H I J K L M




LABEL	DESCRIPTION
BN33	FUNCTION ENABLE BUTTON
BN34	PLATFORM UP BUTTON
BN35	PLATFORM DOWN BUTTON
BN108	MACHINE SETUP, ESCAPE BUTTON
BN109	SCROLL UP BUTTON
BN110	SCROLL DOWN BUTTON
BN111	MACHINE SETUP, ENTER BUTTON
CB2	POWER CIRCUIT BREAKER
CB7	CONTROLS CIRCUIT BREAKER
CR60	BRAKE RELAY
CR61	KEY SWITCH RELAY
H5	ALARM
KS1	KEY SWITCH
P1	RE EMERGENCY STOP BUTTON
TS10	AUXILIARY PLATFORM/DOWN TOGGLE SWITCH
TS51	AUXILIARY ENABLE TOGGLE SWITCH
U1	GCON CONTROL BOARD

Platform Control B

M L K J I H G F E D C




LABEL	DESCRIPTION
BN1	HIGH SPEED FUNCTION BUTTON
BN2	PLATFORM UP/OUTRIGGERS RETRACT BUTTON
BN3	SLOW SPEED FUNCTION BUTTON
BN4	PLATFORM DOWN/OUTRIGGERS EXTEND BUTTON
BN5	HORN BUTTON
BN6	OUTRIGGERENABLE BUTTON (OPTION)
H8	ALARM
JC3	DRIVE/STEER JOYSTICK
L12	RIGHT FRONT OUTRIGGER LED (OPTION)
L13	LEFT FRONT OUTRIGGER LED (OPTION)
L14	RIGHT REAR OUTRIGGER LED (OPTION)
L15	LEFT REAR OUTRIGGER LED (OPTION)
P2	RED EMERGENCY STOP BUTTON
U2	PCON CONTROL BOARD






GS-2669 DC and GS-3369 DC




Electrical Schematic, GS-4069 DC,
(ANSI / CSA)



GS-2669 DC and GS-3369 DC



Electrical Schematic



NOTES: DOTTED LINES REPRESENT OPTIONS

M N O P Q R S T U V W X Y Z

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

Electrical Schematic, GS-4069 DC,
(AS / CE)



GS-2669 DC and GS-3369 DC

C D E F G H I J K L M



NOTE: FLOWS ARE CALCULATED AT 3100 PRM.

MODEL	PRESSURE
GS-2669	3100 psi / 214 bar

HS0256E

Genie Scandinavia
Phone 0046 3157 5154
Fax 0046 3157 5104

Genie France
Phone 0033 237 260 986
Fax 0033 237 260 998

Genie Iberica
Phone 0034 935 725 090
Fax 0034 935 725 080

Genie Germany
Phone 0800 180 9017
Phone 0049 4221 491 821
Fax 0049 4221 491 820

Genie U.K.
Phone 0044 1476 584 333
Fax 0044 1476 584 330

Genie Mexico City
Phone +52 55 5666 5242
Fax +52 55 5666 3241

Genie North America
Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.
Phone +61 7 3456 4444
Fax +61 7 3375 1002

Genie China
Phone +86 21 53853768
Fax +86 21 53852569

Genie Singapore
Phone +65 67533544
Fax +65 67533544

Genie Japan
Phone +81 3 6436 2020
Fax +81 3 5445 1231

Genie Korea
Phone +82 2 558 7267
Fax +82 2 558 3910

Genie Brasil
Phone +55 11 4082 5600
Fax +55 22 4082 5630

Genie Holland
Phone +31 183 581 102
Fax +31 183 581 566

Distributed By: